

For Maintenance and Safety

INDIAN SCOUT OWNER'S MANUAL



2026



WARNING

Read, understand, and follow all of the instructions and safety precautions in this manual and on all product labels.

Failure to follow the safety precautions could result in serious injury or death.



WARNING

Operating, servicing, and maintaining a passenger vehicle or off-road vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle.

For more information, go to P65Warnings.ca.gov/passenger-vehicle.



2026 Rider's Manual

Indian Scout Classic
Indian Scout Bobber
Indian Super Scout
Indian Sport Scout
Indian Sport Scout RT
Indian 101 Scout

Indian Scout Sixty Classic
Indian Scout Sixty Bobber
Indian Sport Scout Sixty

All information contained within this publication is based on the latest product information available at the time of publication. Product improvements or other changes may result in differences between this manual and the motorcycle. Depictions and/or procedures in this publication are intended for reference use only.

No liability can be accepted for omissions or inaccuracies. Indian Motorcycle reserves the right to make changes at any time, without notice and without incurring obligation to make the same or similar changes to motorcycles previously built. Any reprinting or reuse of the depictions and/or procedures contained within, whether whole or in part, is expressly prohibited.

Unless noted, trademarks are the property of Indian Motorcycle International, LLC.

Appareo® is a registered trademark of Appareo Systems, LLC. Apple® and App Store® are registered trademarks of Apple, Inc. BatteryMINDer® is a registered trademark of VDC Electronics, Inc. Bluetooth® is a registered trademark of Bluetooth Sig, Inc. exFAT® is a registered trademark of Microsoft Corporation. Google Play® is a registered trademark of GOOGLE LLC. Kenda® is a registered trademark of Kenda Rubber Industrial Co, Ltd. Marquardt® is a registered trademark of MARQUARDT GMBH CORPORATION. NGK® is a registered trademark of NGK Spark Plug Co., Ltd. Cruisetec®, Night Dragon®, Pirelli®, and Metzeler® are registered trademarks of PIRELLI TYRE C. S. P. A. Ride Command® is a registered trademark of Polaris Industries, Inc. “No Place Is Home” - Welshly Arms - Legendary.

© 2025 Indian Motorcycle International, LLC

9942051 Rev 02

CONGRATULATIONS!

Congratulations on your purchase of a new INDIAN MOTORCYCLE. You have joined an elite family of motorcycle riders who have acquired a celebrated piece of American history by choosing to own an INDIAN MOTORCYCLE.

Your new motorcycle is the end result of true dedication and craftsmanship by our engineering, design and assembly teams. It was designed and manufactured to meet our goal of providing you with a high quality motorcycle that you can ride trouble-free for many years to come. We hope you will take as much pride in riding your new motorcycle as our team did in building it for you.

We urge you to read this rider's manual thoroughly. It contains information essential to safe riding and proper maintenance of your motorcycle.

Your authorized INDIAN MOTORCYCLE dealer knows your motorcycle best and should be consulted for service and assistance. Skilled technicians using advanced equipment and methods are best qualified to perform all major repairs and service your motorcycle may require.

INDIAN MOTORCYCLE LLC complies with all federal, state and local safety and emission regulations for the area of intended sale.

SAFETY SYMBOLS AND SIGNAL WORDS

The following signal words and symbols appear throughout this manual and on your vehicle. Your safety is involved when these words and symbols are used. Become familiar with their meanings before reading the manual.



DANGER indicates a hazardous situation which, if not avoided, **WILL** result in death or serious injury.



WARNING indicates a hazardous situation which, if not avoided, **COULD** result in death or serious injury.



CAUTION indicates a hazardous situation which, if not avoided, **COULD** result in minor to moderate injury.

NOTICE

NOTICE provides key information by clarifying instructions.

IMPORTANT

IMPORTANT provides key reminders during disassembly, assembly, and inspection of components.

Introduction.	7
Safety	19
Reporting Safety Defects	29
Features and Controls	31
4" Display by RIDE COMMAND (If Equipped)	61
Pre-Ride Inspections	81
Operation	95
Maintenance	107
Cleaning and Storage	197
Specifications	203
Warranty	233
Maintenance Log	249

INTRODUCTION

SERVICE AND WARRANTY INFORMATION

Certain maintenance and repair procedures are beyond the scope of this manual. It is strongly recommended that you consult your authorized dealer for assistance with these tasks. Alternatively, you may purchase the *INDIAN MOTORCYCLE Service Manual* from your dealer, which provides in-depth guidance.

Some procedures described in the Service Manual require specialized knowledge, tools, and training. Make sure that you possess the necessary technical skills and equipment before attempting any maintenance or repairs. If you are uncertain about your ability to complete a procedure safely and correctly, or if specialized tools are required, please contact your authorized dealer for professional support.

OPERATING MOTORCYCLE OUTSIDE THE U.S.A.

If you plan to operate your motorcycle in countries other than the USA and Canada:

- Service facilities or replacement parts may not be readily available.
- Unleaded gasoline may not be available. The use of leaded fuels will cause engine damage, damage to your emissions systems and voiding of your warranty.
- Gasoline may have a considerably lower octane rating. Improper fuel can cause engine damage.


IDENTIFICATION NUMBER RECORD

RECORD IMPORTANT IDENTIFICATION NUMBERS BELOW.	
Vehicle Identification Number (VIN) (see page 30)	
Engine Identification Number (see page 8)	
Key Fob Serial Number (if equipped) (located under the key fob battery cover)	
Key Code (if equipped)	

INTRODUCTION

ENGINE IDENTIFICATION NUMBER

The engine number ① is stamped into the bottom of the left crankcase near the sidestand.



RADIO COMPLIANCE STATEMENTS

NOTICE
Some vehicle models contain radio equipment as follows:

USA RADIO COMPLIANCE

This vehicle contains the following radio equipment or components that contain radio equipment:

COMPONENT	COMPONENT ID	MANUFACTURER
Digital Round	RC-3R	Polaris Industries Inc.
Key Fob, Model SK1	4017768	Marquardt® Switches, Inc.
Wireless Control Module (WCM)	2417227	Marquardt® Switches, Inc.
Telematics Control Unit (TCU)	4083664	Appareo®

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

 CAUTION
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radio Frequency Radiation Exposure Information: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 8 in (20 cm) between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

INTRODUCTION

CANADA RADIO COMPLIANCE

This vehicle contains the following radio equipment or components that contain radio equipment:

COMPONENT	COMPONENT ID	MANUFACTURER
Digital Round	RC-3R	Polaris Industries Inc.
Key Fob, Model SK1	4017768	Marquardt® Switches, Inc.
Wireless Control Module (WCM)	2417227	Marquardt® Switches, Inc.
Telematics Control Unit (TCU)	4083664 or 4083665	Appareo®

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Radio Frequency Radiation Exposure Information: This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 8 in (20 cm) between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 8 in (20 cm) de distance entre la source de rayonnement et votre corps. Ce transmetteur ne doit pas être placé au même endroit ou utilisé simultanément avec un autre transmetteur ou antenne.

EUROPEAN UNION (EU) RADIO COMPLIANCE

This vehicle contains the following radio equipment or components that contain radio equipment:

COMPONENT	Digital Round	Key Fob, Model SK1	Wireless Control Module (WCM)	Telematics Control Unit (TCU)
COMPONENT ID	RC-3R	4017768	2417227	4082895
MANUFACTURER	Polaris Industries Inc.	Marquardt® Switches, Inc.	Marquardt® Switches, Inc.	Appareo®
TRANSMITTING FREQUENCY	2402 - 2480 MHz	433.92 - 433.92 MHz	0.02185 - 0.02185 MHz	1900 MHz, 1700 MHz, 850 MHz, 700 MHz
MAX RF TRANSMITTING PWR	0.001 W	38.75 dBµV/m @ 3 m	21.2 dBµV/m @ 300 m	2 W

Hereby, INDIAN MOTORCYCLE LLC declares that the above radio equipment is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

polaris.com/en-us/radio-conformity/

INTRODUCTION

JAPAN RADIO COMPLIANCE

This vehicle contains the following radio equipment or components that contain radio equipment:

COMPONENT	COMPONENT ID	MANUFACTURER
Digital Round	RC-3R	Polaris Industries Inc.
Key Fob, Model SK1	4019469	Marquardt® Switches, Inc.
Wireless Control Module (WCM)	2417572	Marquardt® Switches, Inc.

当該機器には電波法に基づく、技術基準適合証明等を受けた特定無線設備を装着している。

Translation: This equipment contains specified radio equipment that has been certified to the technical regulation conformity certification under the Radio Law.

本無線機器の改造を禁ずる（これに反した場合は当該認証登録番号は無効となる）

Translation: This radio device should not be modified (otherwise the granted designation number will become invalid)

MEXICO RADIO COMPLIANCE

This vehicle contains the following radio equipment or components that contain radio equipment:

COMPONENT	COMPONENT ID	MANUFACTURER
Digital Round	RC-3R	Polaris Industries Inc.
Key Fob, Model SK1	4017768	Marquardt® Switches, Inc.
Wireless Control Module (WCM)	2417227	Marquardt® Switches, Inc.
Telematics Control Unit (TCU)	4083664	Appareo®

IFETEL:

La operación de este equipo está sujeta a las siguientes dos condiciones:

- 1. Es posible que este equipo o dispositivo no cause interferencia perjudicial.
- 2. Este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.



MARQUARDT LABELS

Key Fob PN: 4017768
Wireless Control Module PN: 2417227

INTRODUCTION

Key Fob - IC: 2701A-SK1 WCM - IC: 2701A-SE1	Key Fob - IC: 2701A-SK1 WCM - IC: 2701A-SE1	  203-JN1114
 TA-2022/2712 APPROVED WCM	  	  203-JN1113
Key Fob: Type Approval Number: TRC/36/12316/2023 WCM: Type Approval Number: TRC/34/12317/2023	SK1 - IFT: RLVPOSK19-1418 SE1 - IFT: RLVPOSE19-1419	Key Fob HOMOCOO AGREE PAR L'ARNT MAROC Nombres d'agrement: H900000000ANRT2022 Date d'agrement: 25/10/2022 WCM HOMOCOO AGREE PAR L'ARNT MAROC Nombres d'agrement: H900000000ANRT2022 Date d'agrement: 25/10/2022
Key Fob OMAN - TRA TA-R/14732/22 D172249 WCM OMAN - TRA TA-R/14637/22 D172249	  NR: 2023-074-0484 Key Fob NR: 2023-074-0485 WCM	  Type Accepted ESD-RCE-2334312 Type Accepted ESD-RCE-2334332

	 CIDF19000029	
 H-29682 Key Fob	 H-29683 WCM	 R-C MQU -SK1
 R-C MQU -SE1		
 CCAH23LP4220T0  CCAH23LP4230T3	TRA REGISTERED No: EN16644/22 DEALER No: 0018994/09 Key Fob TRA REGISTERED No: EN14773/22 DEALER No: 0018994/09 WCM	 TA-2022/2730 APPROVED Key Fob
Key Fob - FCC ID: IYZSK1 WCM - FCC ID: IYZSE1		

USA

This device complies with Part 15 of the USA Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications made to this equipment not expressly approved by (manufacturer name) may void the FCC authorization to operate this equipment.

Radiofrequency radiation exposure Information: The radiated output power of the device is far below the FCC radio frequency exposure limits. Nevertheless, the device shall be used in such a manner that the potential for human contact during normal operation is minimized.

CANADA

This device complies with Part 15 of the FCC Rules and with Industry Canada licence-exempt RSS standard. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage, et
2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class [B] digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

EUROPE (EU)

Model: SK1 (Key Fob)

Frequency Range: 433.05 — 434.70 MHz

Max. Transmission Power: < 10 mW

Model SE1 (WCM)

Frequency Range: 31.85 kHz

Max. Transmission Power: < 42 dBμA/m @ 10 m

Manufacturer and Address

Marquardt GmbH
Schloss-Str. 16
78604 Rietheim-Weilheim
Germany

Marquardt GmbH declares that the Product is compliant according to 2014/53/EU.

INTRODUCTION

WARNING

This product contains a lithium button cell. If the button cell is swallowed, severe internal burns can occur within a mere two hours and lead to death. Keep new or removed batteries away from children. If the battery compartment does not close securely, discontinue use and keep away from children. If you think that batteries have been swallowed or are stuck in any part of the body, seek medical help immediately.

The full text of the EU declaration of conformity is available at the following internet address: <https://www.marquardt.com/us/doc/>.

ISRAEL

מספר אישור התאמה אלחוטי של משרד התקשורת הוא 51-88439
אסור להחליף את האנטנה המקורית של המכשיר ולא לעשות בו כל שינוי טכנה אחר.

JORDAN

This device contains RF module approved by TRC.

KUWAIT

See polaris.com/en-us/radio-conformity/.

MALTA

See polaris.com/en-us/radio-conformity/.

SOUTH KOREA

송신기 주파수 433 MHz - Key Fob/ 21.85KHz - WCM
[frequency]

[Class B Equipment]

B급 기기 (가정용 방송통신기자재)

이 기기는 가정용(B급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

[Translation: This equipment is suitable for electromagnetic equipments for home (Class B) and it can be used in all areas.]

[RF Warnings on Equipments]

해당 무선 설비는 운용 중 전파혼신 가능성이 있음

[Translation: This radio equipment has possibility of radio interference during operation.]

[RF Warnings on User Guides]

해당 무선 설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없음

[Translation: This radio equipment cannot provide services related to safety of lives as it has possibility of radio interference during operation.]

TAIWAN

低功率電波輻射性電機管理辦法

第十二條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通

信；經發現有干擾現象時，應改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

[NCC Warning Statement Article 12 Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery. Article 14 The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists.]

MEXICO

SK1 - IFT: RLVPOSK19-1418

SE1 - IFT: RLVPOSE19-1419

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

SAFETY

ABOUT THE RIDER'S MANUAL

WARNING

Failure to follow all recommended precautions and procedures could result in serious injury or death. Always heed all safety precautions and follow all operation, inspection and maintenance procedures outlined in this manual.

All references to RIGHT, LEFT, FRONT or REAR are from the operator's perspective when seated in a normal riding position. If you have questions about the operation or maintenance of your motorcycle after you've read this manual, please see your authorized dealer. To locate the nearest authorized INDIAN MOTORCYCLE dealer, visit the INDIAN MOTORCYCLE website at indianmotorcycle.com.

Carefully read and understand the information found in the Safety chapter beginning on this page. To keep your motorcycle in peak condition on the road or in storage, understand and follow the procedures outlined in the Maintenance chapter beginning on page 107.

Bring the manual along when you ride. Following the precautions and procedures in the manual will add to your enjoyment and help keep you safe. If you lose or damage this manual, please purchase a new one through any authorized INDIAN MOTORCYCLE dealer. This rider's manual should be considered part of the motorcycle and should remain with the motorcycle when ownership changes.

SAFE RIDING PRACTICES

WARNING

Improper use of this motorcycle can result in serious injury or death. To minimize the risk, read and understand the information contained in this section before operating the motorcycle. This section contains safety information specific to the INDIAN MOTORCYCLE, as well as information about general motorcycle safety. Anyone who rides the motorcycle (operators and passengers) must follow these safety precautions.

MOTORCYCLING HAS INHERENT RISKS

You can minimize those risks, but you can't eliminate them completely. Even if you're an experienced motorcycle operator or passenger, read all of the safety information in this manual before operating the motorcycle.

- Take a rider education course from a qualified instructor. The course will help you develop or refresh your expertise in safe riding habits through instruction and riding.
- Read and understand all information in this rider's manual.
- Observe all maintenance requirements specified in this manual. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer.

DESIGN CHARACTERISTICS AFFECT HOW YOU SHOULD RIDE THE MOTORCYCLE

- The motorcycle is designed for on-road use with one rider (and one passenger if the motorcycle is equipped with a passenger seat and pegs). *Never exceed the GVWR or the GAWR.* Refer to the Specifications chapter, or the Manufacturing Information / VIN label on the motorcycle frame for model-specific information.
- Riding off-road, riding with more than one passenger, or carrying weight exceeding the maximum weight rating can make handling difficult, which could cause loss of control.
- During the first 500 miles (800 km) of operation, follow all break-in procedures as outlined on page 95. Failure to do so can result in serious engine damage.
- If your motorcycle is equipped with saddlebags, a windshield or a passenger backrest, be prepared to reduce operating speed to maintain stability.

FOLLOW THESE GENERAL SAFE RIDING PRACTICES

- Before each ride, perform the pre-ride inspections. Failure to do so may result in damage to the motorcycle or an accident.
- Until you're thoroughly familiar with the motorcycle and all of its controls, practice riding where there is little or no traffic. Practice riding at a moderate speed on various road surfaces and in different weather conditions.
- Know your skills and limits, and ride within them.

- Allow only licensed, experienced operators to ride your motorcycle, and then only after they have become familiar with its controls and operation. Make sure all riders read and understand this rider's manual before riding.
- Do not ride when you're fatigued, ill or under the influence of alcohol, prescription drugs, over-the-counter drugs or any other drugs. Fatigue, illness, alcohol and drugs can cause drowsiness, loss of coordination and loss of balance. They can also affect your awareness and judgment.
- If your motorcycle operates abnormally, correct the problem immediately. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.
- Ride defensively, as if you are invisible to other motorists, even in broad daylight. *A motorist's failure to see or recognize a motorcycle is the leading cause of automobile/motorcycle accidents.* Ride where you're clearly visible to other motorists, and observe their behavior carefully.
- Be especially cautious at intersections, as these are the most likely places for an accident.
- To prevent loss of control, keep your hands on the handlebars and your feet on the footrests.
- Be aware that a highway bar is not designed to protect the rider from injury in a collision.
- Obey the speed limit and adjust your speed and riding technique based on road, weather and traffic conditions. As you travel faster, the influence of all other conditions increases, which can affect the motorcycle's stability and increase the possibility of losing control.

- Do not move or operate the motorcycle with the steering locked (if equipped), as the severely restricted steering could result in loss of control.
- Reduce speed when:
 - The road has potholes or is otherwise rough or uneven.
 - The road contains sand, dirt, gravel or other loose substances.
 - The road is wet, icy or oily.
 - The road contains painted surfaces, manhole covers, metal grating, railway crossings or other slippery surfaces.
 - The weather is windy, rainy or otherwise causing slippery or rapidly changing conditions.
 - Traffic is heavy, congested, not allowing sufficient space between vehicles or otherwise not flowing smoothly.
 - You are being passed in either direction by a large vehicle that may produce a wind blast in its wake.
 - Visibility changes due to changes in conditions such as rain, fog, dust, etc.
- When approaching a curve, choose a speed and lean angle that allows you to pass through the curve in your own lane without applying the brakes. Excessive speed, improper lean angle or braking in a curve can cause loss of control.
- Ground clearance is reduced when the motorcycle leans. Do not allow components to contact the road surface when leaning the motorcycle in a curve, as this could cause loss of control.
- Do not tow a trailer. Towing a trailer can make the motorcycle hard to handle.
- Retract the sidestand fully before riding. If the sidestand is not fully retracted, it could contact the road surface and cause loss of control.
- To maximize braking effectiveness, *use the front and rear brakes together*. Be aware of the following braking facts and practices:
 - The rear brake provides 40% of the motorcycle's stopping power, at most. Use the front and rear brakes together.
 - To avoid skidding, apply the brakes gradually when the road is wet or rough, or contains loose or other slippery substances.
 - If possible, avoid applying the brakes while making a turn. Motorcycle tires have less traction during turns, so braking will increase the possibility of skidding. Bring the motorcycle to the upright position before applying the brakes.
 - With new pads and rotors, brake performance will be less effective. Avoid using brakes harshly, unless in an emergency, to allow pads to mate with the rotors. Brake efficiency will gradually increase during this seating period.

PROTECTIVE APPAREL

IMPORTANT

Wear protective apparel to decrease the risk of injury and increase riding comfort.

- Always wear a helmet that meets or exceeds established safety standards. Approved helmets in the USA and Canada bear a U.S. Department of Transportation (DOT) label. Approved helmets in Europe, Asia and Oceania bear the ECE 22.05 label. The ECE mark consists of a circle surrounding the letter E, followed by the distinguishing number of the country which has granted approval. The approval number and serial number will also be displayed on the label. Laws in some areas *require* that you wear an approved helmet. Head injuries are the leading cause of fatalities in accidents involving motorcycles. Statistics prove that an approved helmet is the most effective protection in preventing or reducing head injuries. The helmet should fit snugly, be securely fastened, have no obvious defects, and have not previously been involved in an accident/crash.
- Wear eye protection to protect eyes from wind or airborne particles and objects. Wearing a face shield can help protect your face in an accident/crash and protect face from wind or airborne particles or objects. Laws in some areas *require* that you wear eye protection. We recommend that you wear approved Personal Protective Equipment (PPE) bearing markings such as VESC 8, V-8, Z87.1, or CE. Make sure protective eyewear is kept clean.
- All riders should wear bright or light-colored and/or reflective clothing to improve visibility to other motorists. *A motorist's failure to see or recognize a motorcycle is the leading cause of automobile/motorcycle accidents.*
- Wear gloves, a jacket, heavy boots and long pants to prevent or reduce injury from abrasions, lacerations or burns should the motorcycle fall. Wear boots with low heels, as high heels can catch on pedals or footrests. The combination of boots and pants should completely cover legs, ankles and feet, protecting skin from engine and exhaust system heat.
- Do not wear loose, flowing clothing or long boot laces, as they can catch on handlebars, levers or footrests, or they can become entangled in the wheels, causing loss of control and serious injury.
- Long-term exposure to wind and engine noise can cause permanent hearing loss. Properly worn hearing protective devices such as earplugs can help prevent hearing loss. Check local laws or the rules of the riding area you are in before wearing hearing protection to make sure its use is permitted.

CARRYING A PASSENGER



WARNING

Do not carry a passenger unless the motorcycle is equipped with passenger seat and passenger footrests.

- Do not exceed the GROSS VEHICLE WEIGHT RATING (GVWR) or the GROSS AXLE WEIGHT RATING (GAWR) for your motorcycle. Refer to the Specifications chapter of this manual or the Manufacturing Information / VIN label on the motorcycle frame for model-specific information.
- Direct the passenger to hold onto you or to the passenger hand strap with both hands and to keep both feet on the passenger footrests. Do not carry a passenger who cannot place both feet firmly on the passenger footrests. A passenger who is not holding on properly, or who cannot reach the passenger footrests, can shift their body erratically, which can make the motorcycle hard to handle and cause loss of control.
- Before riding, make sure your passenger knows safe riding procedures. Discuss any safety information unfamiliar to your passenger. A passenger who is unaware of safe riding procedures may distract you or make movements that make the motorcycle hard to handle.
- Adjust your riding style to compensate for the differences in handling, acceleration and braking caused by the additional weight of the passenger. Failure to do so can cause loss of control.
- For riding comfort and to ensure proper ground clearance, adjust the rear shock preload.

CARRYING CARGO

Use the following guidelines when attaching cargo or accessories to the motorcycle. Where applicable, these guidelines also refer to the contents of any accessories.

- Keep cargo and accessory weight to a minimum, and keep items as close to the motorcycle as possible to minimize a change in the motorcycle's center of gravity. Changing the center of gravity can cause loss of stability and handling and could cause loss of control.
- Do not exceed the GROSS VEHICLE WEIGHT RATING (GVWR) or the GROSS AXLE WEIGHT RATING (GAWR) for your motorcycle.
- Distribute weight evenly on both sides of the motorcycle. Maintain even weight distribution by checking accessories and cargo to make sure they're securely attached to the motorcycle before riding and whenever you take a break from riding. Uneven weight distribution or sudden shifting of accessories or cargo while you're riding may cause difficult handling, loss of control and driving hazards for other motorists (if cargo falls from the motorcycle).
- For riding comfort and to ensure proper ground clearance, adjust rear shock preload. See page 147 for details.
- Do not attach large or heavy cargo such as sleeping bags, duffel bags or tents to the handlebars, front fork area or front fender. Cargo or accessories placed in these areas can cause instability (due to improper weight distribution or aerodynamic changes) and could cause loss of control.

SAFETY

- Do not exceed the maximum cargo weight limit of any accessory (see accessory instructions and labels). Do not attach cargo to an accessory not designed for that purpose. Either circumstance could result in an accessory failure that could cause loss of control.
- Always obey posted speed limits.
- Do not attach anything to the motorcycle unless specifically designed for that purpose by INDIAN MOTORCYCLE.

SADDLEBAGS

Whenever operating with saddlebags or while carrying cargo:

- Never ride at excessive speeds. Saddlebags and cargo, combined with the lifting or buffeting effects of wind, can make the motorcycle unstable and cause loss of control.
- Distribute weight evenly on each side of the motorcycle.
- Do not exceed the individual weight limit of each saddlebag.
- NEVER EXCEED GROSS VEHICLE WEIGHT RATING (GVWR) or the GROSS AXLE WEIGHT RATING (GAWR), regardless of whether or not the saddlebags are loaded to capacity. Exceeding the weight rating can reduce stability and handling and cause loss of control.

USE OF ACCESSORIES

Because INDIAN MOTORCYCLE cannot test and make specific recommendations concerning every accessory or combination of accessories sold, the operator is responsible for determining that the motorcycle can be safely operated with any accessories or additional weight. Use the following guidelines when choosing and installing accessories:

- Do not install accessories that impair operator visibility or the stability, handling or operation of the motorcycle. Before installing an accessory, make sure that it does not:
 - reduce ground clearance when the motorcycle is either leaned or in a vertical position;
 - limit suspension or steering travel or your ability to operate controls;
 - displace you from your normal riding position;
 - obscure lights or reflectors.
- Bulky, heavy or large accessories can cause instability (due to the lifting or buffeting effects of wind) and loss of control.
- Do not install electrical accessories that exceed the capacity of the motorcycle's electrical system. Never install higher wattage light bulbs than those supplied as original equipment. An electrical failure could result and cause hazardous loss of engine power or lights, or damage to the electrical system. See page 189 for details.
- Use only genuine INDIAN MOTORCYCLE accessories designed for your model.
- Do not exceed the GROSS VEHICLE WEIGHT RATING (GVWR) or the GROSS AXLE WEIGHT RATING (GAWR) for your motorcycle.

MODIFICATIONS

Modifying the motorcycle by removing any equipment or by adding equipment not approved by the manufacturer may void your warranty. Some modifications may not be legal in your area of operation. If in doubt, contact your authorized INDIAN MOTORCYCLE dealer.



Modifications could make the motorcycle unsafe to ride and could result in serious injury to operator or passenger, as well as damage to the motorcycle.

PARKING THE MOTORCYCLE

When leaving the motorcycle unattended, turn the engine off. If your motorcycle is equipped with a keyed ignition, remove the ignition key to prevent unauthorized use.

Park the motorcycle where people are not likely to touch the hot engine or exhaust system or place combustible materials near these hot areas. Do not park near a flammable source such as a kerosene heater or an open flame, where hot components could ignite combustible materials.

Park the motorcycle on a firm, level surface. Sloped or soft surfaces may not support the motorcycle. If you must park on a slope or soft surface, follow the precautions outlined on page 105.

SAFETY

FUEL AND EXHAUST SAFETY

Always heed these fuel safety warnings when refueling or servicing the fuel system.

WARNING

Gasoline is highly flammable and explosive under certain conditions.

- Always exercise extreme caution whenever handling gasoline.
- Always turn off the engine before refueling.
- Always refuel outdoors or in a well-ventilated area.
- Open the fuel cap slowly. Do not overfill the tank. Do not fill the tank neck.
- Do not smoke or allow open flames or sparks in or near the area where refueling is performed or where gasoline is stored.

WARNING

Gasoline and gasoline vapors are poisonous and can cause serious injury.

- Do not swallow gasoline, inhale gasoline vapors, or spill gasoline. If you swallow gasoline, inhale more than a few breaths of gasoline vapor, or get gasoline in your eyes, see a physician immediately.
- If gasoline spills on your skin or clothing, immediately wash it off with soap and water and change clothing.
- Exhaust gases contain carbon monoxide, a colorless, odorless gas that can cause loss of consciousness or death in a short time.
- Never start the engine or let it run in an enclosed area.
- Never inhale exhaust gases.

SAFETY MAINTENANCE



WARNING

Failure to perform safety maintenance as recommended can result in difficult handling and loss of control, which could result in serious injury or death. Always perform the safety maintenance procedures as recommended in this manual. Perform maintenance and repairs promptly. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.


- Before each ride, perform the pre-ride inspections. See page 81.
- Perform all periodic maintenance at the recommended intervals outlined in the Periodic Maintenance Table.
- Always maintain proper tire pressure, tread condition and wheel and tire balance. Inspect tires regularly and replace worn or damaged tires promptly. Use only approved replacement tires. See the Specifications chapter.
- Always ensure proper steering head bearing adjustment. Regularly inspect the rear shock absorber and the front forks for fluid leaks or damage. Make any necessary repairs promptly. See page 147.
- Clean the motorcycle thoroughly to reveal items in need of repair.
- Fasteners must meet original specifications for quality, finish and type to ensure safety. Use only genuine INDIAN MOTORCYCLE replacement parts, and ensure that all fasteners are tightened to the proper torque.

SAFETY


TRANSPORTING THE MOTORCYCLE

If you must transport the motorcycle:

- Use a truck or trailer. Do not tow the motorcycle with another vehicle, as towing will impair the motorcycle's steering and handling.
- Position and restrain the motorcycle in an upright position.
- Do not restrain the motorcycle using the handlebars.
- Put tie-down straps (from the front) up and over the lower triple clamp ①, using care to not interfere with the wiring and brake lines.



- For added stability, tie-down straps can also be routed around the foot peg mount(s) ②. It is not recommended to route the tie-down straps around the shift lever / linkage or foot pegs. Place the tie-down straps as wide apart as possible on the truck or trailer bed for best stability.



- Do not engage the side stand during truck or trailer transportation.

ELECTROMAGNETIC INTERFERENCE

This vehicle complies with UNECE Regulation No. 10 requirements, which is equivalent to Canadian ICES-002.

GROSS VEHICLE WEIGHT RATING (GVWR)



Exceeding the gross vehicle weight rating of your motorcycle can reduce stability and handling and could cause loss of control. NEVER exceed the GVWR of your motorcycle.

The *maximum load capacity* of your motorcycle is the maximum weight you may add to your motorcycle *without exceeding the GVWR*. This capacity is determined by calculating the difference between your motorcycle's GVWR and wet weight.

Refer to the Specifications chapter of this manual or the Manufacturing Information / VIN label on the motorcycle frame for model-specific information.

When determining the weight you will be adding to your motorcycle, and to ensure you do not exceed the maximum load capacity, include the following:

- Operator body weight
- Passenger body weight
- Weight of all rider's apparel and items in or on apparel

REPORTING SAFETY DEFECTS (CANADA)

To report a safety defect to Transport Canada, you may either fill out an online defect complaint form at their website (English: tc.gc.ca/recalls,

French: tc.gc.ca/rappels) or contact their Defect Investigations and Recalls Division by calling toll-free 1-800-333-0510 (Canada) or 819-994-3328 (Ottawa-Gatineau area / International).

- Weight of any post-production accessories and their contents
- Weight of any additional cargo on the motorcycle

REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect that could result in a crash or cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying INDIAN MOTORCYCLE in writing.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your INDIAN MOTORCYCLE dealer or INDIAN MOTORCYCLE.


To contact NHTSA, or obtain other information about motor vehicle safety, you may either call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153), visit the NHTSA website at [safercar.gov](https://www.safercar.gov), or write to:

ADMINISTRATOR, NHTSA
1200 New Jersey Avenue, SE
West Building
Washington, DC 20590

SAFETY



SAFETY AND INFORMATION LABELS

Labels are model-specific and market-specific. Your motorcycle may not contain all of the labels shown.



- ① Vehicle Identification Number (VIN)
- ② Operator Warning / Fuel Recommendation
- ③ Vehicle Emission Control Information (VECI) / Noise Emission Control Information (NECI) (if equipped)
- ④ Evaporative Emission Control (EVAP) Decal (if equipped)

FEATURES AND CONTROLS SCOUT CLASSIC



① Driver's Seat

② Air Box (under fuel tank)

③ Fuel Tank

④ Mirror

⑤ Right Front Turn Signal

⑥ Headlight

⑦ Front Fork

⑧ Rear Brake Pedal

⑨ Driver's Footrest

⑩ Muffler

⑪ Right Rear Turn Signal

⑫ Tail and Brake Light

⑬ Left Front Turn Signal

⑭ Ignition Switch or Power Switch

⑮ Battery (under seat)

⑯ Left Rear Turn Signal

⑰ Coolant Recovery Bottle

⑱ Sidestand

⑲ Gear Shifter

⑳ Radiator

㉑ USB (if equipped)



㉒ Battery Charge Port / Heated Gear Plug
(behind the ignition switch cover)

FEATURES AND CONTROLS

SCOUT BOBBER

NOTICE

Images are for reference only. Your model might differ slightly.



① Driver's Seat

⑤ Right Front Turn Signal

⑨ Driver's Footrest

⑬ Ignition Switch or Power Switch

⑰ Sidestand

⑳ Battery Charge Port / Heated Gear Plug (behind the ignition switch cover)

② Air Box (under fuel tank)

⑥ Headlight

⑩ Muffler

⑭ Battery (under seat)

⑱ Gear Shifter

③ Fuel Tank

⑦ Front Fork

⑪ Right Rear Turn Signal / Tail and Brake Light

⑮ Left Rear Turn Signal / Tail and Brake Light

⑲ Radiator

④ Mirror

⑧ Rear Brake Pedal


⑫ Left Front Turn Signal

⑯ Coolant Recovery Bottle

㉔ USB (if equipped)

CONSOLE

- ① Clutch Lever
- ② Left Control
- ③ Right Control
- ④ Instrument Cluster
- ⑤ Front Brake Master Cylinder
- ⑥ Front Brake Lever
- ⑦ Throttle Grip
- ⑧ Fuel Cap




FEATURES AND CONTROLS

SWITCH LOCATIONS


LEFT CONTROL

ANALOG GAUGE EQUIPPED MODELS




- ① Cruise Control Switch (If Equipped)
- ② Turn Signal / Hazard Signal
- ③ Horn Switch
- ④ High / Low Beam and Flash to Pass

RIDE COMMAND EQUIPPED MODELS



- ① Cruise Control Switch
- ② Turn Signal / Hazard Signal
- ③ Horn Switch
- ④ High / Low Beam and Flash to Pass
- ⑤ Back Button
- ⑥ 5-Way Toggle Switch

RIGHT CONTROL



- ⑤ Engine Stop / Run / Start Switch
- ⑥ Right Trigger Switch

SWITCH SYMBOLS

SYMBOL	SWITCH	DESCRIPTION
	Horn Switch	Press the horn switch to sound the horn. See page 38.
	High Headlight Beam Switch	The high headlight beam switch activates the high headlight beam. See page 37.
	Low Headlight Beam Switch	The low headlight beam switch activates the low headlight beam. Press down momentarily to activate Flash to Pass. See page 37.
	Turn Signal Switch	Move the switch to the left to activate the left turn signals. Move the switch to the right to activate the right turn signals. A signal will deactivate automatically when speed or distance reach predetermined levels. To cancel a signal manually, move the switch to the center position and push it inward. <i>Momentary Feature: Move the turn signal switch left or right and hold it in that position for at least one second. The momentary feature will activate and the signal will then cancel when the switch is released. See page 38.</i>
	Emergency Flasher Switch (Hazard Switch)	The hazard switch activates and cancels the emergency flashers. Press and hold on the center of the switch to activate emergency flashers. See page 38. To activate, move press

FEATURES AND CONTROLS

SYMBOL	SWITCH	DESCRIPTION
		and hold switch while in the center position until hazards activate. To cancel, press and release switch while in the center position.
	Back Switch (if equipped)	Use the back switch to back out of menus, decline dialog boxes.
	Stop Switch	Press the bottom of the switch (RUN) to allow the engine to start and run. Press the top of the switch (STOP) to stop the engine. See page 39.
	Starter Switch	Use the starter switch to start the engine. The engine stop / run / start switch must be in the RUN position. See page 39.
	Right-Hand Trigger Switch	On models equipped with analog gauge, use the right-hand trigger switch to cycle through the multi-function display. On models equipped with a Ride Command display, use the right-hand switch to navigate through menus. See page 75.


SWITCH FUNCTIONS

HIGH / LOW HEADLIGHT BEAM SWITCH

The headlights automatically come on when the engine starts. The high / low headlight beam switch ① toggles the headlight between high beam and low beam.

NOTICE

Image is for reference only. Your model might differ slightly.



To momentarily flash headlights (Flash to Pass), press and hold the left-hand trigger switch. To activate high beams for an extended period of time, push the trigger forward until it clicks into place. Pull the lever back to the neutral position to return to low beams.


FEATURES AND CONTROLS

TURN SIGNAL / HAZARD SIGNAL SWITCH

The power switch must be ON to activate the flashers. When the flashers are active, all four turn signals flash. Flashers will continue to operate whether the power switch is in ON or OFF.

NOTICE

Image is for reference only. Your model might differ slightly.




Press and hold the turn signal / hazard signal switch ② to activate the flashers. Press the switch again to cancel the flashers.

HORN SWITCH

Press the horn switch ③ to sound the horn.

NOTICE


Image is for reference only. Your model might differ slightly.



ENGINE STOP / RUN / START SWITCH

Use the engine stop / run / start switch ⑤ to turn the engine on or off quickly.

Read the engine starting procedures before starting the engine.
See page 97.



- Press the top of the switch (STOP) to interrupt the circuits and stop the engine. The engine should not start or run when the switch is in the STOP position.
- Press the bottom of the switch (RUN) to complete the circuits and allow the engine to start and run.
- Momentarily hold the switch down in the RUN position to initiate the start of the engine.

TIP


The headlights and any accessories plugged into power ports will remain on until the power switch is turned off.

IGNITION / LIGHT KEY SWITCH

Motorcycle riders must remain as visible as possible at all times. To aid in this, the headlight must be on at all times while operating. The headlights automatically operate when the engine is running. Do not modify the ignition/light switch wiring to circumvent the automatic headlight feature.

The ignition / light key switch controls the electrical functions of the motorcycle. The switch is located on the ignition cover on the left side of the motorcycle.

FEATURES AND CONTROLS



Before starting the engine, read the instructions for starting the engine. See page 97.

Turn the ignition switch to the OFF position and remove the ignition key when leaving the motorcycle unattended.

SYMBOL	DESCRIPTION
①	OFF
②	RUN

Some models are equipped with a power switch ③ that utilizes a key fob ④.



If the motorcycle is moving and the engine is running, press and hold the power switch for three seconds or more to disable all electrical power.

KEYLESS IGNITION

WARNING



Keep the key fob and key fob battery out of reach of children. Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.

STARTING KEY FOB OPERATION:

When the electrical system is activated with the power switch, the key fob must be within range. If the key fob is not detected, the security light will flash. The electrical system will automatically shut down.

The starter motor will not engage during this time. If a key fob is not available, your personal identification number (PIN) can be entered using the turn signal switches, or on the Ride Command display screen (if equipped), to unlock the security system. See page 189.

DRIVING KEY FOB OPERATION:

After starting the engine, the Wireless Control Module (WCM) will verify that the key fob is within range again when shifting from neutral into gear. The security light may turn on during this check. The WCM will not search for the key fob again after the vehicle has moved. If the key fob is lost during riding, the PIN will be needed to restart the vehicle.

If the key fob is not detected when shifting into gear:

- The horn will sound and the security light will flash.
- The engine will then turn off.
- The electrical system will then automatically shut down.

KEY FOB STORAGE:

The key fob should not be stored near devices that can interfere with radio waves, such as cell phones, power supplies, or magnets, during operation.

FEATURES AND CONTROLS

INSTRUMENT CLUSTER

The instrument cluster includes the speedometer, indicator lamps, and a Multi-Function Display (MFD).



- ① Speedometer
- ② Indicator Lamps
- ③ Multi-Function Display (MFD)

SPEEDOMETER

The speedometer displays forward vehicle speed in either miles per hour or kilometers per hour.

INDICATOR LAMPS

LAMP	INDICATES	CONDITION
	High Beam	The headlight switch is set to high beam. This indicator will flash if there is a problem with the low or high beam light.
	Chassis Fault	The alert symbol illuminates when a chassis fault occurs. This alert symbol will also illuminate if there is a low battery charge or low oil pressure. This light will be accompanied by the MFD showing: battery icon (Low Battery Voltage) or LoW P (Low Oil Pressure).
	Turn Signals	One arrow flashes when the corresponding turn signal is activated. Both arrows flash when the hazard signal is activated. <i>If there is a problem in the signal system, the lamps will flash at twice the normal rate.</i>
	ABS Not Activated	The indicator flashes until the anti-lock system activates, which occurs when vehicle speed exceeds 3 mph (5 km/h). When the lamp is illuminated, the anti-lock brakes will not activate,

LAMP	INDICATES	CONDITION
		but the conventional brake system will continue to operate normally. The lamp will also illuminate if an ABS fault is detected.
	Neutral	The transmission is in neutral and the power switch is ON.
	Traction Control	The indicator flashes until the traction control system activates, which occurs when vehicle speed exceeds 3 mph (5 km/h). This lamp flashes when traction control is actively limiting rear wheel slip. The lamp illuminates and remains on when traction control is disabled. The traction control fault indicator illuminates when the traction control system has experienced abnormal operation and will remain on as long as the fault condition exists.
	Check Engine	<i>If this lamp illuminates while the engine is running, see your dealer promptly.</i> The light will remain on if the tilt sensor shuts down

FEATURES AND CONTROLS

LAMP	INDICATES	CONDITION
		the engine. If abnormal sensor or engine operation is detected the light will remain on as long as the fault condition exists. Retrieve the error codes for diagnosis. If a misfire is detected, the check engine lamp will begin to flash and fuel will be cut to the affected cylinder(s). See page 49.
	Engine Overheat	The engine overheat light will illuminate when the engine temperature exceeds normal operating temperature.
MPH	Vehicle Speed	When standard mode is selected, speed displays in miles per hour.
km/h		When metric mode is selected, speed displays in kilometers per hour.

MFD TELL-TALES

LAMP	INDICATES	CONDITION
	Low Oil Pressure	The Low Oil Pressure lamp illuminates when oil pressure drops below a safe operating pressure while the engine is running. If this lamp illuminates while the engine is running above idle speed, turn the engine off as soon as safely possible and check the oil level. <i>If the oil level is correct and the lamp remains on after the engine is restarted, turn the engine off immediately. See your authorized INDIAN MOTORCYCLE dealer or other qualified dealer.</i>
	Battery Voltage	The Battery Voltage lamp illuminates if high or low battery voltage is detected, or if there is a charging system fault. Turn non-essential accessories off to conserve power. Make sure the charging system is operating properly. See page 195. This lamp also illuminates with the security light and/or power switch when the key fob battery is low (if equipped).

LAMP	INDICATES	CONDITION
MPH	Vehicle Speed	When standard mode is selected, speed displays in miles per hour.
km/h		When metric mode is selected, speed displays in kilometers per hour.
	Cruise Control Status	When the <i>Dial Icon</i> is visible, cruise control is enabled, but not set. The <i>Arrow Icon</i> becomes visible when cruise control is set to the desired speed. <i>Read the safety and operation procedures before using cruise control. See page 103.</i>
	Security	The security indicator illuminates when the security system is activated.

FEATURES AND CONTROLS

MULTI-FUNCTION DISPLAY (MFD) MODES

With the ignition switch on, use the right-hand trigger switch to toggle through the modes of the multi-function display and to change settings in the display.

The following display modes are available:

- Odometer
- Trip Odometer (Trip 1, Trip 2)
- Engine Speed
- Gear Indicator
- Battery Voltage
- Ambient Temperature
- Heated Grip Level (If Equipped)
- Ride Modes (If Equipped)
- Traction Control (If Equipped)
- MPG Average
- Fuel Range

ODOMETER

The odometer displays total distance traveled.

TRIP ODOMETER

The trip odometer displays total distance traveled since being reset. To reset, toggle to the trip odometer, then press and hold the right-hand trigger switch until the trip odometer resets to zero.

ENGINE SPEED

Engine speed displays in revolutions per minute (RPM).

GEAR INDICATOR

The vehicle's current gear position is displayed on the MFD.

BATTERY VOLTAGE

Battery voltage displays real-time, regulated charge voltage supplied to the battery. The voltage level may fluctuate depending on electrical load and engine RPM.

AVERAGE FUEL ECONOMY

Average Fuel Economy displays the vehicle's average fuel economy as of the last time the mode was reset. To reset, press and hold the right hand trigger while viewing the fuel economy display.

OUTSIDE TEMPERATURE

The temperature area displays the temperature of the air immediately surrounding the motorcycle.

RIDE MODES (IF EQUIPPED)

You can choose between three ride modes, Rain, Standard, or Sport for an experience customized to your riding style. The throttle map for each ride mode was designed with a specific application in mind, resulting in one motorcycle with three distinct personalities.

RAIN

Rain mode provides a smoother throttle respond ideal for riding when conditions are wet.

STANDARD

Standard mode features a crisp throttle response and well-balanced power delivery for responsive passing power and predictable, slow-speed handling.

SPORT

Sport mode is designed for situations when instant response is needed. Sport mode quickens the throttle response and has a more aggressive power delivery for increased acceleration.

TIP

Rain mode is power limited. INDIAN MOTORCYCLE recommends Rain mode for all riders under wet conditions as well as general use for new riders and those who are still familiarizing themselves with their motorcycle.

CHANGING RIDE MODES

- 1. Cycle MFD with right hand control trigger to RIDE MD option.
- 2. Hold the right hand trigger switch for 3 seconds to enter into the RIDE MD menu.
- 3. Single press the right hand trigger switch to cycle through the ride mode options (RAIN, STND, SPORT).

NOTICE

The ride mode will not change unless the throttle is in a neutral position.

- 4. Hold the right hand trigger switch for 3 seconds on desired ride mode.

TRACTION CONTROL (IF EQUIPPED)

To turn traction control on / off:

- 1. Cycle MFD with right-hand control trigger to Tc CtrL.
- 2. Hold the right-hand trigger switch for 3 seconds to enter into the Traction Control Menu.
- 3. Single press the right hand trigger switch to cycle to ON or OFF.
- 4. Hold the right- hand trigger switch for 3 seconds on desired setting.
- 5. CONFIRM will display, hold the right-hand trigger for 3 seconds to confirm.

FEATURES AND CONTROLS

DISPLAY UNITS (STANDARD / METRIC)

The display can be changed to display either standard or metric units of measurement.

	STANDARD DISPLAY	METRIC DISPLAY
Distance	Miles	Kilometers
Temperature	Fahrenheit	Celsius
Time	12-Hour Clock	24-Hour Clock

1. Turn the ignition off.
2. Wait 10 seconds.
3. Press and *hold* the right-hand trigger switch while turning the ignition key to the ON position or powering on the motorcycle by pushing the power switch.
4. When the display flashes the distance setting, tap the right-hand trigger switch to advance to the desired setting.
5. Press and *hold* the right-hand trigger switch to save the setting and advance to the next display option.
6. Repeat the procedure to change the remaining display settings.

CLOCK

NOTICE

The clock must be reset any time the battery has been disconnected or discharged.

1. Use the right-hand trigger switch to toggle to the odometer display.
2. Press and *hold* the right-hand trigger switch until the hour segment flashes. Release the switch.
3. With the segment flashing, tap the right-hand trigger switch to advance to the desired setting.
4. Press and *hold* the right-hand trigger switch until the next segment flashes. Release the switch.
5. Repeat steps 3–4 twice to set the 10-minute and 1-minute segments. After completing the 1-minute segment, step 4 will save the new settings and exit the clock mode.

DIAGNOSTIC FUNCTIONALITY

Certain conditions will cause the battery indicator to illuminate and an error message to display in the screen. If this occurs, please see your authorized dealer.

MESSAGE	LOCATION	INDICATES
LO	DC Voltage Screen	Voltage remains below 11.0 volts for more than 10 seconds
OV	DC Voltage Screen	Voltage remains above 15.0 volts for more than 10 seconds
ERROR	All	Checksum error (gauge malfunction)

OVER TEMPERATURE DISPLAY AND WARNING INDICATOR

If the engine coolant temperature approaches unsafe operating conditions while the engine is running, the engine overheat indicator will illuminate. Stop the engine as soon as safely possible. Check the coolant level. Check the radiator for debris. Check cooling fan operation. If the warning continues to display after restarting the engine, stop the engine immediately

MISFIRE DETECTION

If a misfire is detected, the check engine indicator lamp will begin to flash and fuel will be cut to the affected cylinder(s). The check engine indicator lamp will continue to flash until the ignition switch has been moved to the off position. Restarting the engine will clear the flashing indicator and restore fuel to both cylinders. If another misfire occurs, the check engine indicator lamp will resume flashing and fuel will once again be cut to the affected cylinder(s). After the 3rd misfire, P0314 misfire fault is determined and set, the check engine light will remain on and fuel will be cut to the affected cylinder(s). If this occurs, your INDIAN MOTORCYCLE dealer can assist.

FEATURES AND CONTROLS


BATTERY CHARGE PORT / HEATED GEAR PLUG

The Battery Charge Port / Heated Gear Plug ① is located behind the ignition switch cover and a maintenance charger can be connected to it for extended periods (for example, winter storage).




CAUTION

Wait until engine components have cooled before handling the gear plug.



THROTTLE CONTROL GRIP

The throttle control grip is located on the right handlebar. Use the throttle control grip to control engine speed.



While seated in the proper riding position:


- Roll the grip rearward ① to open the throttle (increase engine speed and power).
- Roll the grip forward ② to close the throttle (decrease engine speed and power).
- Roll the grip forward, past idle position, to cancel cruise control.

The control grip is spring loaded. When you release the grip, the throttle returns to the idle position.

CLUTCH LEVER

The clutch lever ① is located on the left handlebar. Disengage the clutch before shifting gears. For smooth clutch operation, pull the lever quickly and release it in a brisk but controlled manner.

- To disengage the clutch, pull the lever toward the handlebar.
- To engage the clutch, release the lever in a brisk but controlled manner.



MIRRORS

IMPORTANT

Repositioning the bar-end side mirrors to the “down” position could result in scratching or damage to the fuel tank / badge finish if not properly adjusted.

Your motorcycle is equipped with convex mirrors. Objects seen in a mirror may be closer than they appear. Always adjust the mirrors before you ride.

To adjust the mirrors, sit on the motorcycle in the anticipated riding position. Adjust the mirrors so that you can see a small portion of your shoulders in each mirror.

FEELER PEGS


Your bike is equipped with small feeler pegs extending from the end of both footpegs to help protect against damage. A wear notch has been etched near the base of both feeler pegs. Once either feeler peg has been eroded up to the wear notch, a replacement feeler peg is recommended.

FEATURES AND CONTROLS

GEAR SHIFT LEVER

The gear shift lever ① is located on the left side of the motorcycle. Operate the lever with your foot.


- Press downward on the toe lever to shift to a lower gear.
- Lift upward on the toe lever to shift to a higher gear.
- Release the lever after each gear shift.
- See page 100 for gear shifting procedures.



SADDLEBAGS (SUPER SCOUT MODELS)

REMOVAL


1. Open the saddlebag lid by pulling down on the rubber handle.



2. Remove the two screws and two washers from the inside of the saddlebag.

NOTICE

Saddlebag lid hidden for image clarity.



NOTICE

Be careful not to scratch the rear fender in the next step. Also, be cautious as the rear fender might become loose.

INSTALLATION

1. Gently install the saddlebag onto the vehicle.

NOTICE

Be careful not to scratch the rear fender.

2. Install the two washers and two screws inside of the saddlebag. Torque screws to specification.

TORQUE


Screws:
18 ft-lbs (25 N·m)

NOTICE

Saddlebag lid hidden for image clarity.

3. Gently lift the saddlebag away from the vehicle.

FEATURES AND CONTROLS




3. Simply let the saddlebag lid drop to close the saddlebag lid. The lid auto latches onto the latch plate.



SADDLEBAGS (SPORT SCOUT RT MODELS)

REMOVAL


1. Unlock the latch on the rear side of the saddlebag lid and lift open the lid to gain access.



2. Remove the two screws from the inside of the saddlebag.

NOTICE

Be careful not to scratch the rear fender in the next step. Also, be cautious as the rear fender might become loose.



3. Gently lift the saddlebag away from the vehicle.

FEATURES AND CONTROLS

INSTALLATION

1. Gently install the saddlebag onto the vehicle.

NOTICE

Be careful not to scratch the rear fender.

2. Install the two screws inside of the saddlebag. Torque screws to specification.

TORQUE

Screws:
18 ft-lbs (25 N·m)

3. Close the saddlebag lid.


WINDSHIELD (IF EQUIPPED)

1. Place the windshield assembly onto each front fork leg.


NOTICE

The windshield needs to be deflected slightly in order to get the windshield mounts seated onto each front fork leg.

2. Start the hooks on both sides of the windshield.



3. Close the levers on both sides of the windshield.



4. Optional: Install the M6 bolts ① for theft protection. The bolts prevent the hooks from being removed from the slots. The clamps can be opened but not removed from the forks.



TIP

The M6 bolts can be installed and removed with the INDIAN MOTORCYCLE uni-tool, located under the seat.

FEATURES AND CONTROLS

SIDESTAND

All models are equipped with a sidestand ① that has a safety switch to prevent operation of the motorcycle if the sidestand is deployed.

WARNING

An improperly retracted sidestand could contact the ground and cause a loss of control resulting in serious injury or death. Always retract the sidestand fully before operating the motorcycle.


To park the motorcycle, swing the end of the sidestand downward and away from the motorcycle until it is fully extended. Always turn the handlebars to the left for maximum stability. Lean the motorcycle to the left until the sidestand firmly supports the motorcycle.

CAUTION

If the motorcycle weight is not resting on the sidestand, it will not lock. In this situation, any movement of the motorcycle could cause the sidestand to retract slightly. If the sidestand is not in the full forward position when the motorcycle weight is rested on it, the motorcycle could fall over, possibly causing injury and damage to the motorcycle.


To retract the sidestand, straddle the motorcycle and bring it to the fully upright position. Swing the end of the sidestand upward and toward the motorcycle until it is fully retracted.

See page 105 for parking instructions, including parking on slopes and soft surfaces.



STEERING LOCK (IF EQUIPPED)

To lock the steering, park the motorcycle and turn the engine off. Turn the handlebars fully to the left. Place the ignition key (or key fob key, if equipped) in the steering lock and turn the key counter-clockwise to lock the forks. Remove the key.




WARNING

Do not move or operate the motorcycle with the steering locked, as the severely restricted steering could result in loss of control.

BRAKES

FRONT BRAKE LEVER

The front brake lever ① is located on the right handlebar. This lever controls only the front brakes. The front brakes should be applied simultaneously with the rear brakes. To apply the front brake, pull the lever toward the handlebar. See page 102 for braking procedures.




FEATURES AND CONTROLS

REAR BRAKE PEDAL

The rear brake pedal ① is located on the right side of the motorcycle. Press downward on the rear brake pedal to apply the rear brake.

WARNING

Resting your foot on the brake pedal will cause excessive and premature wear of brake pads and reduced braking efficiency, which could result in serious injury or death.



See page 102 for braking procedures.

4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

OVERVIEW



For the latest information about your INDIAN MOTORCYCLE Ride Command display, including software updates, go to: ridecommand.indianmotorcycle.com.

NOTICE

Using the display for an extended period of time while the vehicle's engine is off can drain the battery.

⚠ WARNING

Do not enter information while operating your vehicle. Failure to pay attention to operating your vehicle could result in loss of control, injury, or death. You assume all risks associated with using this device. Read your User Guide.

⚠ WARNING

Driving while distracted can result in loss of vehicle control, crash, and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.

Before riding with your new display, do the following:

4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

- Read this entire manual.
- Familiarize yourself with the features and operations of the display while the vehicle is stationary.
- Download the INDIAN MOTORCYCLE Ride Command app from the Apple App Store® or Google Play® store and create your personalized account.
- Check indianmotorcycle.com/en-us/owners-manuals/ for the latest updates to the owner's manual.

DEVICE OPERATING REQUIREMENTS

Phone functionality is dependent on the capabilities of your cell phone.

NOTICE

Some cell phones or operating systems will not work as shown in this manual.

CARE AND MAINTENANCE

To clean the display shell, use a soft cloth with mild soap and water. Do not use harsh or abrasive cleaners. For best results, use a micro-fiber towel to clean the screen. Window cleaner or alcohol may also be used.

NOTICE

Immediately clean off any gasoline that splashes onto the display.

GETTING STARTED OVERVIEW



- ① Touchscreen Buttons
- ② Indicator Lamps
- ③ Turn Signal Indicators

- ④ Current Gear
- ⑤ Speedometer
- ⑥ Icon Bar

INDICATOR LAMPS

LAMP	INDICATES	CONDITION
	High Beam	The headlight switch is set to high beam. This indicator will flash if there is a problem with the low or high beam light.
	Low Battery Voltage	This lamp illuminates when battery voltage is low. Turn non-essential accessories off to conserve power. Make sure the charging system is operating properly. See page 195. This lamp also illuminates with the security light and/or power switch when the key fob battery is low.
	Security	The security indicator illuminates when the security system is activated.
	ABS Not Activated	The indicator flashes until the anti-lock system activates, which occurs when vehicle speed exceeds 3 mph (5 km/h). When the lamp is illuminated, the anti-lock brakes will not activate,

LAMP	INDICATES	CONDITION
		but the conventional brake system will continue to operate normally.
	Traction Control	The indicator flashes until the traction control system activates, which occurs when vehicle speed exceeds 3 mph (5 km/h). This lamp flashes when traction control is actively limiting rear wheel slip. The lamp illuminates and remains on when traction control is disabled. The traction control fault indicator illuminates when the traction control system has experienced abnormal operation and will remain on as long as the fault condition exists.
	Cruise Control Status	<i>Amber Lamp:</i> Cruise control is enabled, but not set. When flashing, a cruise control related fault exists. <i>Green Lamp:</i> Cruise control is set to the desired speed. <i>Read the safety and operation procedures before using cruise control.</i> See page 103.

4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

LAMP	INDICATES	CONDITION
	Low Fuel	This lamp illuminates when approximately .5 gal (1.9 L) of fuel remains in the fuel tank. The LCD Display will switch into a Low Fuel Mileage Counter Mode to provide the rider with mileage tracking from the time the indicator was activated.
	Neutral	The transmission is in neutral and the power switch is ON.
	Check Engine	<i>If this lamp illuminates while the engine is running, see your dealer promptly.</i> The light will remain on if the tilt sensor shuts down the engine. If abnormal sensor or engine operation is detected the light will remain on as long as the fault condition exists. Retrieve the error codes for diagnosis. If a misfire is detected, the check engine lamp will begin to flash and fuel will be cut to the affected cylinder(s).

LAMP	INDICATES	CONDITION
	Chassis Fault	The alert symbol illuminates if a chassis fault occurs.
	Sidestand Light	The sidestand light will turn on anytime the sidestand is down.

RIDE COMMAND BUTTONS

BUTTON	FUNCTION
Screen Cycle 	Press the Screen Cycle button to toggle through available display screens.
Controls 	Press the Controls button to access vehicle and display settings.

BUTTON	FUNCTION
App Tray 	Press the App Tray button to access the Settings and Phone screens.
Back 	Press the Back button to back out of menu screens.

ICON BAR



- ① Traction Control (if equipped)

② Headset Connection

③ Cell Signal Strength
- ④ Cruise Control

⑤ Ride Mode

4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

DISPLAY SCREENS

Press the Screen Cycle button ①, or the trigger switch on the right-hand control, to cycle through the available display screens.



DISPLAY SCREENS	FUNCTION
Gauge Screen	Displays important information, such as speedometer, tachometer, gear, vehicle direction, ambient temperature, odometer, and fuel level.
Bike Information	Displays bike information, such as ambient temperature, battery voltage, fuel economy, and fuel range.
Ride Information	Displays ride information, such as ride time, distance, elevation, and trip odometer.
Maps and Navigation	Provides access to maps and turn-by-turn navigation.
Audio	Select audio source and control audio playback.
Controls	Select ride mode and change display brightness.

DISPLAY SCREEN

The Display Screen displays important ride data and vehicle information, such as vehicle speed, current gear, fuel level, and more.

DISPLAY SCREEN THEMES

There are two Display Screen themes to choose from, **Standard** and **Analog Sport**. The Display Screen themes can be changed in the Settings menu. Simply tap on the display to switch back and forth between screens.



- ① Speedometer
- ② Tachometer
- ③ Current Gear
- ④ Vehicle Direction
- ⑤ Ambient Temperature
- ⑥ Odometer
- ⑦ Fuel Level

4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

Standard

The Standard theme resembles a classic analog dial-face, with a traditional speedometer design.



Analog Sport

For a slightly cleaner look, the Analog Sport theme displays the speedometer as a numeric value rather than a meter.



BIKE INFORMATION

The Bike Information screen displays important information about your vehicle.



- ① Ambient Temperature
- ② Engine Temperature
- ③ Fuel Economy
- ④ Battery Voltage
- ⑤ Fuel Range

RIDE INFORMATION

The Ride Information screen displays important ride information, such as your current ride time, total distance traveled, and more.

MAPS AND NAVIGATION

The Maps and Navigation screen allows access to Ride Command's many navigation features. From the maps and navigations screen you can find directions, look up addresses, search for gas stations, and pinpoint other points of interest. Once selected, the display will provide turn-by-turn directions to your destination.



- ① Ride Time
- ② Time Moving/Stopped
- ③ Reset Trip Odometer
- ④ More Information
- ⑤ Distance Traveled
- ⑥ Total Elevation Change
- ⑦ Select Trip Meter



4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

MUSIC

The Music screen allows you to access music stored on your smart-phone or other music device. You can pair your device using Bluetooth®, or by connecting it to the display's USB port.



- ① Select Source
- ② Track Information
- ③ Track Length
- ④ Repeat Track
- ⑤ Menu
- ⑥ Track Control
- ⑦ Shuffle

CONTROLS

From the Controls screen you can select your ride mode and adjust the display brightness.



- ① Ride Mode
- ② Display Brightness
- ③ Close

RIDE COMMAND RIDE MODES

You can choose between three ride modes: Rain, Standard, or Sport for an experience customized to your riding style.

The throttle map for each ride mode was designed with a specific application in mind, resulting in one motorcycle with three distinct personalities.



NOTICE

For the ride mode or traction control status to change the throttle must be fully disengaged. If you change the ride mode while the throttle is engaged, a spinning icon will appear indicating that the ride mode has not yet changed. Once the throttle is disengaged the icon will disappear and the ride mode will change.

RAIN

Rain mode provides a smoother throttle response ideal for riding when conditions are wet.

STANDARD

Standard mode features a crisp throttle response and well-balanced power delivery for responsive passing power and predictable, slow-speed handling.

SPORT

Sport mode is designed for situations when instant response is needed. Sport mode quickens the throttle response and has a more aggressive power delivery for increased acceleration.

TIP

Rain mode is power limited. INDIAN MOTORCYCLE recommends Rain mode for all riders under wet conditions as well as general use for new riders and those who are still familiarizing themselves with their motorcycle.

4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

SETTINGS

The Settings Screen displays important details about your vehicle and allows you to personalize your touchscreen display.

The Settings Screen can be accessed by pressing the App Tray button ①, then selecting the settings button on the screen.

The settings menu is comprised of four categories: Information, General, Time, and Vehicle.



INFORMATION

From the Information settings menu you can view the following:

- Vehicle Identification Number (VIN)
- Mileage
- Installed Software Version
- Oil Change Interval

GENERAL SETTINGS

From the General settings menu you can do the following:

- Themes (Day/Night/Auto)
- Manage Bluetooth® Devices
- Change the Language
- Set the Speed Units of Measure (MPH or KPH)
- Set the Temperature Units (F or C)
- Update Software

TIME

From the Time Settings you can do the following:

- Set the Time Format (12 hour or 24 hour)
- Enable GPS Time (automatically sets the time to the time zone you are currently in)
- Set Time (if GPS Time is not enabled)

NOTICE

The clock is sourced from the GPS chip and periodically requires GPS lock to function correctly.

NOTICE

Clock reading will be non-existent or inaccurate after disconnecting battery and will require a new GPS sync to function properly.

VEHICLE

From the Vehicle Settings you can do the following:

- Oil Life/ Service Reset
- Access Vehicle Diagnostics

APP TRAY

Press the App Tray hard button ① to cycle through the available app screens.



4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

SETTINGS

From the Settings Menu you can view important details about your vehicle and personalize your touchscreen display. The settings menu is comprised of four categories: Information, General, Time, and Vehicle.

PHONE

If the Ride Command display is connected to a phone using Bluetooth®, the Phone screen will be available from the App Tray. From the phone screen you can make and answer calls, and view text messages.



RIDE COMMAND HAND CONTROLS

5-WAY TOGGLE SWITCH




Use the 5-way toggle switch ① to do the following:

- Press and hold to display the Controls
- Navigate through the menu gauge / menu screens
- Enter / Select
- Change the gauge style

Press and hold the 5-way toggle switch up / down / left or right to bring up the media control overlay. When the media overlay is visible on the screen, use the 5-way toggle to control feedback.

- Press left / right to navigate tracks
- Press up / down control the volume
- Press center to mute / unmute

TRIGGER SWITCH



The trigger switch ① is located on the reverse side of the right switch cube and is used to toggle through the Ride Command display screens. Press and hold the switch to display the App Tray.

BLUETOOTH® PAIRING

The INDIAN MOTORCYCLE Ride Command touchscreen display can be connected to a smart-phone and a headset simultaneously.

NOTICE

Always pair the smart-phone first, followed by accessories.

To pair a device, do the following:

1. From the Bluetooth® Devices settings screen, the Phone screen, or the Music screen, tap on the Add Device button to bring up the pairing prompt.
2. Put your Bluetooth® device into pairing mode.
3. Select the name of the device you want to pair from the touchscreen display to finish the pairing process.
4. Confirm pairing (if applicable). Depending on the device you are pairing to the display you may be prompted to confirm pairing.

4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)

UPDATE SOFTWARE

For the latest software for INDIAN MOTORCYCLE Ride Command, go to:

ridecommand.indianmotorcycle.com.

The display software can be updated by connecting a USB stick containing the latest software version to the USB port located under the fuel tank. See page 78. The Update Software menu in Settings will list any available updates on the USB stick. Choose the correct version and wait for the update to complete before removing the USB stick. The touchscreen display will automatically restart when software is updated.

NOTICE

A USB 2.0 or USB 3.0 flash drive formatted to either FAT-32 or exFAT® is required to successfully perform an update. The display will not recognize flash drives that do not meet these requirements.

IMPORTANT

Do not remove power from the display during the update process.

OVER THE AIR UPDATES

NOTICE

Over the air updates are only available on models equipped with a Telematics Control Unit (TCU).

If your model is equipped with a TCU, the motorcycle will automatically download software updates from the cloud when the motorcycle is powered on and a TCU connection is available. All downloads occur in the background and can be resumed if the connection is interrupted or if the motorcycle is turned off.

HOW TO INSTALL SOFTWARE

Once new software has been downloaded to your display, you will be prompted with a notification.

To install new software, do the following:

1. Navigate to the General Settings tab in the Settings menu.
2. Press the “Install” button.

NOTICE

The following conditions must be met for the installation to initiate: the battery voltage must be greater than 12.5 V, the wheel speed must be at 0 mph, and the RPMs must equal 0.

NOTICE

The display will restart after the installation has successfully completed.

NOTICE

Critical updates will be installed automatically. A notification will display once the update is complete.

UPDATE MAPS

For the latest maps for INDIAN MOTORCYCLE Ride Command, go to:

ridecommand.indianmotorcycle.com.

NOTICE

The display will automatically restart after a software and map update.

NOTICE

For map updates, a 32GB or greater USB drive formatted to exFAT® is required.

3. After the update had been completed, release notes will be provided on the software update screen.

4" DISPLAY BY RIDE COMMAND (IF EQUIPPED)


USB PORT

The USB Port makes it easy to power devices, such as phones, audio sources, or GPS units, in addition to allowing you to stream music through the LCD display to your Bluetooth® headset. On models equipped with a INDIAN MOTORCYCLE Ride Command display, the USB port is also used to update the display software. For the latest software for INDIAN MOTORCYCLE Ride Command, go to:

ridecommand.indianmotorcycle.com.


IMPORTANT

Due to harsh riding environments, INDIAN MOTORCYCLE recommends using a USB device with retention features.



TIP

To prevent damage to or from the USB cable ①, route the cable underneath the gusset cover ② as shown.



RIDE COMMAND+

Your vehicle may come equipped with RIDE COMMAND+ technology, which gives you access to your vehicle's custom information including Vehicle Health, Vehicle Locator and Issue Diagnostics (if equipped) along with a variety of features via the INDIAN MOTORCYCLE mobile app. You will need a cellular connection to view these features.

To learn more about RIDE COMMAND+, including equipped or compatible vehicles, specific features, and to access the RIDE COMMAND+ User Guide, visit ridecommand.indianmotorcycle.com or scan the QR code:



Disclaimer: RIDE COMMAND+ features vary by region.

PRE-RIDE INSPECTIONS OVERVIEW

To keep your motorcycle in safe operating condition, always perform the recommended pre-ride inspections before each ride. This is especially important before making a long trip and when removing the motorcycle from storage.



WARNING

Failure to perform the recommended pre-ride inspections could result in component failure while riding, which could result in serious injury or death. Always perform the pre-ride inspections before each ride. When inspection reveals the need for adjustment, replacement or repair, perform the service promptly, or see your authorized INDIAN MOTORCYCLE dealer or other qualified dealer for service.



WARNING

Read the entire Features and Controls chapter of this manual before riding your motorcycle. A complete understanding of the features and capabilities of your motorcycle is essential to its safe operation. Anything less may result in serious injury or death.

You must be familiar with all instruments and controls to perform the pre-ride inspections.

NOTICE

During the pre-ride inspections you may use products that are potentially hazardous, such as oil or brake fluid. When using any of these products, always follow the instructions and warnings on the product packaging.

When inspections reveal the need for adjustment, replacement, or repair:

- refer to the Maintenance chapter of this manual
- refer to the *INDIAN MOTORCYCLE Service Manual*
- or see your authorized INDIAN MOTORCYCLE dealer or other qualified dealer

ELECTRICAL INSPECTIONS

Turn the ignition key to the ON position or power on the motorcycle by pushing the power switch and move the stop/run switch to RUN before performing the following electrical inspections. Turn the ignition key to the OFF position or power off the motorcycle by pushing the power switch after completing these inspections. If inspection of any electrical item reveals component failure, repair or replace the component before operating the motorcycle.

PRE-RIDE INSPECTIONS


ITEM	INSPECTION PROCEDURE
Headlamp	The headlights automatically operate whenever the engine is running. Once the headlamp illuminates, switch to high beam. Verify that the high beam indicator comes on and that lamp brightness increases.
Taillight / Brakelight	Verify that the taillight and license plate light illuminate. Verify that the taillight lamps increase in brightness when the front brake lever is applied and also when the rear brake pedal is applied.
Turn Signals	Move the turn signal switch to the left. Verify that front and rear left turn signals flash, as well as the corresponding light on the indicator panel. Move the switch to the center position and push it inward to cancel the signal. Verify that the signals and the indicator light stop flashing. Repeat the procedure for the right turn signals.
Hazard Warning Flashers	Press and hold the hazard warning flashers switch for 1-2 seconds to activate the hazard warning flashers. Verify that all four turn signals flash, as well as the lamps on the indicator panel. Turn the hazard warning flashers off. Verify that all signals and indicator lamps stop flashing.
Horn	Press the horn switch. Verify that the horn sounds loudly.
Neutral Indicator	Place the transmission in neutral. Verify that the neutral indicator lamp illuminates and that the letter "N" displays in the gear position display.

ITEM	INSPECTION PROCEDURE
Low Oil Pressure Indicator	Start the engine. Verify that the low oil pressure indicator is not illuminated.
Engine Stop / Run / Start Switch	Start the engine. Move the stop/run switch to the STOP position. Verify that the engine stops. Attempt to restart the engine to verify that the engine WILL NOT start.

GENERAL INSPECTIONS

ITEM	INSPECTION PROCEDURE
Engine Oil	Check the oil level. See page 83.
Fuel	Check the fuel level. See page 91.
Coolant Level	Check the coolant level in the recovery bottle. See page 92.
Fluid Leaks	Check the vehicle and the ground/floor for any fuel, oil, coolant or hydraulic fluid leaks.
Tires	Inspect condition, pressure and tread depth. See page 84.
Brake Operation	Inspect pedal and lever movement.
Brake Fluid Levels	Check front and rear brake fluid levels. See page 85 and page 87.
Brake Components	Inspect hoses and connections.
Throttle	Inspect hand grip and throttle movement.

ITEM	INSPECTION PROCEDURE
Clutch	Check lever operation and freeplay.
Front Suspension	Check for leaks, debris and damage.
Steering	Check for smooth operation by turning handlebars full left and full right.
Rear Suspension	Check mounting and inspect for leaks.
Rear Drive Belt	Check for wear or damage. See page 145.
Sidestand	Verify smooth operation, inspect pivot bolt and spring.
Fasteners	Inspect for loose, damaged or missing fasteners.
Mirrors	Adjust for proper rear view.



1. With the motorcycle in an upright (vertical) position, let the warm engine idle for 30 seconds.
2. Stop the engine.
3. Place the motorcycle on a level area and hold it in an upright (centered) position.

ENGINE OIL LEVEL CHECK

Due to the semi-dry sump lubrication system, the engine oil level shown in the oil sight glass will fluctuate with movement of the motorcycle from a vertical position and with the temperature of the oil. To get an accurate oil level reading, follow all inspection procedures closely.

IMPORTANT

Engine **MUST BE AT OPERATING TEMPERATURE** when checking oil level. Check oil after riding or after idling a cold engine for 5-10 minutes.

PRE-RIDE INSPECTIONS

4. Inspect the oil level by looking at the oil sight glass. The oil level should be between the FULL ② and ADD ③ marks.
5. Do not overfill. If the oil level is low, remove the engine oil fill plug ① and add INDIAN MOTORCYCLE Synthetic Blend 15W-60 Engine Oil. Repeat steps 1- 4 until the reading is within the safe operation range.

CAUTION

Oil level will NOT be accurate if checked on a cold engine. DO NOT ADD oil to raise level to middle of sight glass on a cold engine, as this can result in overfilling.

NOTICE

Do not overfill! The correct approximate volume is between the FULL and ADD marks.

TIRES

WARNING

Operating the motorcycle with incorrect tires, incorrect tire pressure or excessively worn tires could cause loss of control or accident. Under inflation can cause a tire to overheat and result in a tire failure. Only use tires approved by INDIAN MOTORCYCLE for the model of the motorcycle. See your dealer for more information. Use of unapproved or an improperly mixed front and rear tire can result in decreased handling performance and stability, potentially leading to reduced control of the motorcycle. Always maintain proper tire pressure as recommended in the rider's manual and on safety labels.

TIRE PRESSURE

Improper tire pressure can result in irregular tire wear, tire failure, reduced fuel economy and a poor riding experience. It can also affect handling and stopping ability.

Slow tire pressure loss over time is normal for a functional tire. Always inspect tire pressure and condition before each ride.

Check tire pressure before riding, when the tires are cold. This will provide the most accurate reading, as riding warms the tires and increases tire air pressure. Tires remain warm for at least 3 hours after a ride. Do not adjust tire pressure immediately after riding. As tires cool, the pressure will drop and result in underinflation. Always check and adjust tire pressure when tires are cold.

Using a good quality pocket-style gauge, adjust tire pressure to the recommended pressure. See page 168.

TIRE CONDITION


Inspect the tire sidewalls, road contact surface and tread base. If inspection reveals cuts, punctures, cracks or other wear or damage, replace the tire before riding. Only use tires approved by INDIAN MOTORCYCLE for the model of the motorcycle. See your dealer for more information. Use of unapproved or an improperly mixed front and rear tire can result in decreased handling performance and stability, potentially leading to reduced control of the motorcycle.

TIRE TREAD DEPTH

Measure the tread depth near the center of the tread on both tires. See page 168. Replace any tire with a tread depth of less than 1/16 inch (1.6 mm).

FRONT BRAKE FLUID LEVEL

1. Straddle the motorcycle and bring it to the fully upright position. Position the handlebars so that the fluid reservoir is level.
2. View the fluid level through the sight glass ①. The fluid should be clear. Replace cloudy or contaminated fluid.



3. The fluid level should be above the minimum indicator mark next to the sight glass.

PRE-RIDE INSPECTIONS

4. If the fluid level is low, inspect brake pads as outlined in the Brake Disc Inspection/Cleaning section. If pads are not worn beyond the service limit, inspect the brake system for leaks. Check for signs of brake fluid leaks around hoses, fittings, reservoir, and brake calipers.
5. Add brake fluid if necessary. See page 160.

FRONT BRAKE LEVER


1. Pull the front brake lever toward the handlebar and hold it. The lever should move freely and smoothly. The lever should feel firm and continue to feel firm until released.
2. Release the lever. It should return to its rest position quickly when released.
3. If the front brake lever fails to perform as stated, service the brake lever before riding.

REAR BRAKE PEDAL

1. Press downward on the rear brake pedal. It should move freely and smoothly. The pedal should feel firm and continue to feel firm until released.
2. Release the pedal. It should return to its rest position quickly when released.
3. If the rear brake pedal fails to perform as stated or travels too far before beginning to engage the brake, service the brakes before riding.

BRAKE PEDAL ADJUSTMENT

1. Loosen the jam nut ① on the rear master cylinder push rod.



2. Rotate the push rod to adjust the pedal height up or down.

3. Once adjusted, verify that you have at least 6 mm of thread engagement between the push rod and the clevis.
4. Torque the brake pedal jam nut to specification.

TORQUE

Brake Pedal Jam Nut:
80 in-lbs (9 N·m)


⚠ WARNING

After pad installation or any brake system repair, safely elevate the wheel, apply and release the brake pedal or lever 2-3 times and release. Verify the wheel turns freely without drag. If brake drag is evident, do not operate the motorcycle. Inspect the vehicle to determine the cause and then repair as necessary.

REAR BRAKE FLUID LEVEL

The rear brake fluid reservoir is located near the rear brake pedal. View the reservoir level from the right side of the vehicle.

1. Position the motorcycle on level ground in the fully upright position.
2. View the brake fluid through the reservoir sight glass ①.



3. The fluid should be clear. Replace cloudy or contaminated fluid.
4. The fluid level should be above the minimum indicator mark on the reservoir sight glass ①. Add the recommended brake fluid as needed. See page 158.

PRE-RIDE INSPECTIONS

BRAKE LINES


Inspect all brake hoses and connections for dampness or stains from leaking or dried fluid. Tighten any leaking connections to the proper torque values and replace components as necessary. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

WARNING

Brake fluid leaks or low brake fluid levels could cause brake system failure, which could result in serious injury or death. Do not operate the vehicle with low brake fluid levels or when leaks are evident (dampness or stains from dried fluid). See your authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

MECHANICAL CLUTCH

1. Squeeze the clutch lever ① toward the handlebar and release it. It should move freely and smoothly, and it should return to the rest position quickly when released. If the lever fails to perform as stated, service the clutch lever before riding.



2. Freeplay (gap) is the amount of lever movement from the rest position to the point of cable resistance. Clutch lever freeplay should be 0.02–0.059 in (0.5–1.5 mm). Measure the gap between the clutch lever and the lever housing ②. See page 155. Adjust clutch lever freeplay if necessary.

NOTICE


The starter interlock switch is dependent on the clutch lever freeplay being set correctly to ensure activation of the clutch safety switch.

SHIFT PEDAL ADJUSTMENT

1. Loosen the jam nuts ①.
2. Rotate the linkage rod ② until the desired angle is reached.

NOTICE

Some components are hidden for image clarity.


**IMPORTANT**

The shift linkage rod must be threaded into each pivot end a minimum of seven complete turns.

PRE-RIDE INSPECTIONS

IMPORTANT

Make sure the dots ③ are properly aligned.



3. Torque the shift rod jam nuts to specification.

TORQUE

Shift Rod Jam Nuts:
88 in-lbs (10 N·m)

⚠ CAUTION

Do not remove and reposition the shift arm on the shift shaft to adjust gear shift pedal height. Dots on shift shaft and shift arm must be aligned for gears to shift correctly.

THROTTLE

Rotate the throttle control grip. It should rotate smoothly from the rest position to the completely open position. It should return to the rest position quickly when released.

FRONT SUSPENSION

Inspect the front forks for oil leaks or damage, and verify smooth suspension operation. See page 151 for details.

REAR SUSPENSION

Check the rear shock absorber mounting and inspect for leaks. See your dealer for service if you discover leaks or malfunction of any kind. See page 147 and page 148 for details.

⚠ WARNING


Inadequate ground clearance could result in components contacting the ground, causing loss of control and serious injury or death. Always ensure ground clearance is at specification.

REAR DRIVE BELT

- 1. Check the drive belt teeth for stones or other debris.
- 2. Inspect drive belt condition. See page 145. If you discover cracks, broken teeth or frayed edges, replace the drive belt before riding. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

FUEL LEVEL

For the most accurate reading, sit on the motorcycle and bring it to the upright position before turning it on.



The segments of the fuel gauge ① show the level of fuel in the fuel tank. When the last segment clears, a low fuel warning is activated. All segments including the fuel icon will flash. Refuel promptly.

SIDESTAND

- 1. On level ground, straddle the motorcycle and bring it to the fully upright position.
- 2. Move the sidestand up to the stored position and down to the fully extended position several times. It should move smoothly and quietly. Make sure the return spring holds the sidestand tightly in place when the sidestand is in the stored position. Adjust or replace a loose spring.
- 3. Inspect the sidestand pivot bolt for looseness or wear. Tighten or replace a loose or worn bolt.

FASTENERS

- 1. Inspect the entire motorcycle chassis and engine for loose, damaged or missing fasteners.
- 2. Tighten loose fasteners to the proper torque. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

NOTICE
Always replace stripped, damaged or broken fasteners before riding. Use genuine INDIAN MOTORCYCLE fasteners of equal size and strength.


PRE-RIDE INSPECTIONS

COOLANT LEVEL INSPECTION



Allow the vehicle to cool before performing any maintenance on the cooling system. Failure to do so could result in burns to skin.


Check the coolant level when the bike is held upright on a level surface, not on sidestand. The bike should be cold and off for at least 4 hours before checking the coolant level. Remove the recovery bottle dipstick ① and wipe it with a clean cloth. Fully install the dipstick until it touches off on the coolant bottle to ensure an accurate measurement. Remove the dipstick and check the coolant level. The coolant level should be between the ADD and FULL COLD marks on the dipstick.



NOTICE

The recovery bottle is vented to prevent overfilling. Coolant will vent onto the ground if overfilled.

If the coolant level is low, add fluid until the level is within the ADD and FULL COLD marks. Do not fill past the FULL COLD mark.



OPERATION OVERVIEW

The Operation chapter of this manual describes how to ensure maximum performance and longevity through the proper care and operation of your motorcycle.

Important areas covered by the Operation chapter include:

- Engine Break-In
- Fueling
- Starting the Engine
- Shifting Gears
- Accelerating
- Braking
- Stopping the Engine
- Parking

NOTICE

Even if you are an experienced motorcycle operator or passenger, read all of the safety information in this manual before operating the motorcycle.

IMPORTANT

Failure to properly follow the engine break-in procedures outlined in this manual can result in serious damage to the engine. Follow all break-in procedures carefully. Avoid full throttle operation and other conditions that may place an excessive load on the engine during the break-in period.

BREAK-IN MAINTENANCE

Perform the break-in maintenance procedures when the motorcycle's odometer registers 500 miles (800 km). Please see your authorized dealer for this service.

Performing the break-in maintenance will help ensure optimum engine performance for the entire service life of the engine. Your dealer will change engine oil, inspect all fluids and serviceable components, ensure that all fasteners are tightened and make other adjustments as needed.

ENGINE BREAK-IN

The engine break-in period for your motorcycle is the first 500 miles (800 km) of operation. During this break-in period, critical engine parts require special wear-in procedures so they seat and mate properly. Read, understand and follow all break-in procedures to ensure the long-term performance and durability of your engine.

The more cautiously you treat your motorcycle during the break-in period, the more satisfied you will be with its performance later on. Overloading the engine at low RPM and/or running the engine prematurely at high RPM may result in damage to the engine components.

Observe the following precautions during the break-in period:

OPERATION


- Upon initial start-up, do not allow the engine to idle for long periods as overheating can occur.
- Avoid fast starts with wide open throttle. Drive slowly until the engine warms up.
- Avoid running the engine at extremely low RPM in higher gears (lugging the engine).
- Drive within the recommended operating speeds and gears.

OPERATING SPEEDS AND GEARS

ODOMETER		BREAK-IN PROCEDURE
MILES	KM	
0-90	0-145	Do not operate for extended periods above 1/3 throttle or at any one throttle position. Vary engine speed frequently.
91-300	146-483	Do not operate for extended periods above 1/2 throttle or at any one throttle position. Vary engine speed frequently.
301-500	484-800	Do not operate for extended periods above 3/4 throttle.
At 500	At 800	Perform the break-in maintenance outlined in the Maintenance chapter of this manual. Break-in maintenance should be performed by a dealership. Break-in maintenance must include inspection, adjustments, fastener tightening and an engine oil and filter change. Performing break-in maintenance at the required odometer reading helps ensure peak engine performance, minimal exhaust emissions and maximum service life of the engine.

FUELING

Always dismount the motorcycle and refuel on level ground with the sidestand down. Review the fuel warnings. Use only the recommended fuel. See page 230. Hold the nozzle while filling. Do not rest the weight of the nozzle and hose on the filler neck. Do not leave the nozzle unattended.



WARNING

Overflows or spilled gasoline could contact a hot engine or exhaust system and cause a fire, which could result in serious injury or death. Do not allow gasoline to contact hot components.

 WARNING

Always remove the fuel cap slowly and fill the fuel tank slowly to prevent spillage. Do not overfill the fuel tank. Leave space in the tank to allow for the fuel to expand.

1. Turn the fuel cap ① counter-clockwise to remove it.

NOTICE

If the fuel cap is equipped with a tether, carefully rest fuel cap on the tank so that the rubber bumper is contacting the tank.

2. Insert the fuel nozzle into the fuel tank filler neck.
3. Add fuel to the tank until it closes the opening in the bottom of the filler neck. The tank is full at this level.
4. Always securely install the fuel cap before remounting the motorcycle. To tighten the cap, turn it clockwise until the seal compresses onto the tank, then continue to tighten until the cap ratchets several times.

NOTICE

Fuel can damage painted surfaces and plastic parts. If gasoline spills on the any part of the motorcycle, immediately rinse it off with water or wipe it dry with a clean cloth.

PRIMING THE FUEL SYSTEM

If the motorcycle runs out of fuel, prime the fuel system before attempting to restart the engine.

1. Fill the fuel tank.
2. Turn the ignition key to the ON position or power on the motorcycle by pushing the power switch.
3. Move the engine stop / run / start switch to the RUN position.
4. Allow the fuel pump to run until it stops (about 2 seconds).
5. Move the engine stop / run / start switch to the STOP position.
6. Turn the ignition key to the OFF position or power off the motorcycle by pushing the power switch.
7. Repeat steps 2–6 four to five times.
8. Start the engine.

STARTING THE ENGINE

The starter interlock system allows the engine to be started only when the transmission is in neutral, or when the transmission is in gear with the clutch disengaged (clutch lever pulled in).

1. Perform the pre-ride inspections. See page 81. Properly secure any cargo.
2. Straddle the motorcycle and bring it to the fully upright position. Retract the sidestand.
3. Turn the ignition key to the ON position or power on the motorcycle by pushing the power switch.

OPERATION

4. Move the engine stop / run / start switch to the RUN position.
5. Shift the transmission to neutral.
6. Apply the front brakes. Disengage the clutch (pull the clutch lever fully toward the handlebar).
7. Press and release the starter switch to start the engine. The starter motor will crank until the engine starts, but no more than 8 seconds. If the engine does not start, wait five seconds, then try again.
8. If starting a COOL engine, DO NOT open the throttle while starting. Idle speed is computer controlled and will adjust automatically. Allow the engine to warm up for 1 minute minimum at low RPM after starting. Do not run the engine above 3500 RPM. If starting a WARM engine, DO NOT open the throttle while starting.
9. If either the check engine indicator or the low oil pressure indicator remains on after the engine starts, stop the engine *immediately*. Refer to the low oil pressure indicator information on page 45.

NOTICE

Operating an engine with a misfire or non-firing cylinder can overheat the catalytic converter, which could result in catalytic converter damage and loss of emission control. DO NOT OPERATE the motorcycle if a misfire or non-firing cylinder exists.

10. Leave the throttle closed and allow the engine to idle. Idle speed will gradually slow to normal as the engine reaches operating temperature.

IDLE TIMER SHUTDOWN NOTIFICATION

To prevent overheating, the engine will shut down after running at idle for a prolonged period of time without user input. At any time during the idle countdown timer period, user input to the clutch/brake levers, or throttle, will end the shutdown sequence. Prior to engine shutdown, notifications will be provided to the user.

A flashing amber warning light indicator ① signals the start of the countdown timer. After the time has elapsed and the engine is shut off, the illuminated indicator will remain solid. The engine can be re-started by pressing the starter switch. After starting the engine, the Check Engine indicator should no longer be illuminated.

COLD WEATHER OPERATION

WARNING

Avoid operating in icy or snowy conditions. Use caution when driving in temperatures at or below 40 °F (4 °C). Leave more room to stop, reduce cornering speeds, and accelerate gradually. Failure to do so could result in serious injury or death.

When operating in cold weather at or below 40 °F (4 °C), be advised that:

- The grip on your standard vehicle tires will lessen and reduce traction.
- The dense air from the lower temperatures will allow your vehicle engine to generate more power.
- The engine control program and transmission control program may compensate for lower temperatures and as a result exhibit unexpected behaviors.
- Salt and sand on roadways may reduce the grip on standard vehicle tires and damage the finish on your vehicle. If you must drive on salted/sanded pavement, INDIAN MOTORCYCLE recommends washing frequently and thoroughly to remove any accumulation on your vehicle.



OPERATION


SHIFTING GEARS

WARNING

Forced shifting (with clutch engaged) could cause damage to the engine, transmission and drive train. Such damage could cause loss of control, which could result in serious injury or death.

Always pull the clutch lever fully toward the handlebars to disengage the clutch before shifting gears.

Your motorcycle is equipped with either a five-speed or six-speed transmission. Neutral is located between the first and second gear.



Press downward on the toe lever to shift to a lower gear. Lift upward on the toe lever to shift to a higher gear. Release the clutch lever after each gear shift.

Shifting to neutral is easiest if the motorcycle is rolling slowly. To shift from first gear to neutral, gently lift the toe lever a half stroke.

NOTICE

The transmission is in neutral if you can move the motorcycle forward or rearward freely without disengaging the clutch. If the ignition switch is in the ON position, the neutral indicator illuminates when the transmission is in neutral.

SHIFTING GEARS WHILE STATIONARY

To locate neutral when the motorcycle is stationary, use one of the following techniques to load and unload the transmission:

1. With the clutch disengaged (lever pulled inward), shift into neutral while rocking the motorcycle forward and rearward.
2. With the transmission in first gear, gently release the clutch until it just begins to engage. Apply upward pressure on the toe lever and quickly pull the clutch inward.

NOTICE

There is a Neutral indicator light on the instrument cluster.

SHIFTING GEARS WHILE DRIVING

WARNING

Shifting improperly could cause transmission damage, loss of traction and loss of control, which could result in serious injury or death.

- Reduce speed before downshifting. Always downshift within the recommended shift points.
- Use extreme caution when downshifting on wet, slippery or other low traction surfaces. Release the clutch lever very gradually in these conditions.
- Avoid downshifting in a curve. Downshift before entering the curve.

7. To shift to a higher gear, accelerate smoothly to the recommended shift point. With a quick motion, simultaneously close the throttle completely and disengage the clutch. Raise the toe shift lever until you feel it stop at the next gear. Simultaneously release the clutch lever and open the throttle in one smooth motion.
8. To shift to a lower gear (downshift), simultaneously pull the clutch lever toward the handlebar and close the throttle. Move the toe shift lever downward until you feel it stop at the next gear. Simultaneously release the clutch lever while opening the throttle.

NOTICE

Within the recommended speed ranges, you can downshift to slow the motorcycle or to increase power. You may want to downshift when climbing a hill or passing. Downshifting also helps to decrease speed when combined with closing the throttle.

1. Start the engine. See page 97.
2. With the engine at idle speed, apply the front brakes.
3. Disengage the clutch (pull the clutch lever fully toward the handlebar).
4. Push the toe lever downward until you feel it stop in first gear.
5. Release the brake lever.
6. Simultaneously release the clutch lever while opening the throttle (rolling the throttle control grip rearward) in one smooth motion. As the clutch begins to engage, the motorcycle will move forward.

RECOMMENDED SHIFT POINTS

UPSHIFTING (ACCELERATING)		DOWNSHIFTING (DECELERATING)	
GEAR CHANGE	RECOMMENDED SPEED	GEAR CHANGE	RECOMMENDED SPEED
1 to 2	17 mph (27 km/h)	6 to 5 (if equipped)	40 mph (65 km/h)
2 to 3	24 mph (38 km/h)	5 to 4	35 mph (56 km/h)
3 to 4	35 mph (56 km/h)	4 to 3	29 mph (47 km/h)
4 to 5	41 mph (66 km/h)	3 to 2	20 mph (33 km/h)
5 to 6 (if equipped)	50 mph (81 km/h)	2 to 1	15 mph (24 km/h)

BRAKING

Always allow sufficient stopping distance so that brakes can be applied gradually.

NOTICE

Applying slightly more front brake than rear brake generally provides the best braking performance.

1. To slow the motorcycle with the brakes, close the throttle and apply the front and rear brakes evenly and gradually.

NOTICE

When the anti-lock brakes engage during a braking event, the rider will feel pulsing at the brake lever and / or brake pedal. Continue to apply steady pressure to the brakes for the best stopping performance.

2. As the motorcycle slows, disengage the clutch, or downshift each time vehicle speed reaches a downshift point.

WARNING

Braking improperly could result in loss of control, which could result in serious injury or death. Avoid braking abruptly. Always apply the brakes gradually, especially on wet, slippery or other low traction surfaces. Avoid braking in a curve or turn. Bring the motorcycle to the upright position before applying the brakes.

ACCELERATING

Accelerate by opening the throttle (rolling the throttle control grip rearward). For even acceleration, open the throttle with a smooth, continuous motion. When you reach the recommended speed for upshifting, shift up one gear.



WARNING

Accelerating abruptly could cause your body to shift rearward suddenly, which could result in loss of control. Accelerating abruptly could also cause loss of control on low traction surfaces. Loss of control could result in serious injury or death. Always accelerate gradually, especially on wet, slippery or other low traction surfaces.

STOPPING THE ENGINE

Before stopping the engine, bring the motorcycle to a complete stop. Shift to neutral or disengage the clutch.



WARNING

Stopping the engine with the transmission in gear while the motorcycle is moving could cause loss of rear wheel traction or engine and transmission damage, which could cause loss of control and serious injury or death. Always stop the engine after the motorcycle is fully stopped and the transmission is in neutral. If the engine stops unexpectedly while the motorcycle is moving, pull the clutch and guide the motorcycle to a safe location off the road and away from traffic. Turn the ignition switch off.

1. When fully stopped, shift into neutral.
2. Move the engine stop / run / start switch to the STOP position.
3. Turn the ignition key to the OFF position or power off the motorcycle by pushing the power switch. Remove the ignition key (if equipped).

USING CRUISE CONTROL

The cruise control switches are located on the left hand control. Read this section and understand how to safely operate this feature before using the cruise control.

Cruise control can be activated and adjusted from the left-hand control using the Cruise Control Switch. See page 34.



WARNING

Improper operation of cruise control could cause loss of control and result in serious injury or death. Follow all cruise operation procedures carefully. Never use cruise control when roads are wet or slippery. Do not use cruise control when riding in heavy or congested traffic.

CRUISE CONTROL TIPS

- Cruise control can be set in gears 2-6.
- Vehicle speed must be above 20 mph (32 km/h).
- Set speed will vary slightly in hilly terrain.

OPERATION

- Cruise control will not resume a pre-set speed if the resulting acceleration or deceleration rate is too high or too low. For example, resuming a set speed of 70 mph (113 km/h) from 40 mph (64 km/h), while in 6th gear, may cause cruise to disengage.
- Cruise control will not engage if brake lights are not operating properly.
- The clutch or either brake must have been activated at least once since the engine was started for the cruise control to function.

SET SPEED

1. Press and release the center of the cruise control switch ①. The cruise control indicator will illuminate in the instrument cluster. Cruise control is enabled, but not set.
2. Accelerate to the desired speed and press down on the cruise control switch to activate cruise control. The Cruise Control Set indicator lamp will illuminate. Cruise control is set to the desired speed.

RESUME SPEED

After disengaging the cruise control with the brake, throttle or clutch, press up on the cruise control switch to return to the set speed.

ACCELERATE

While cruise control is engaged, tap up on the cruise control switch to increase speed in approximately 1 mph (1-2 km/h) increments. Press and hold up on the cruise control switch to accelerate to a new set speed (resets when switch is released).

TIP

If you use the throttle to accelerate and then release it, the cruise control will resume the previously set speed.

DECELERATE

While cruise control is engaged, tap and release down on the cruise control switch to decrease speed in approximately 1 mph (1-2 km/h) increments. Press and hold the down on the cruise control switch to decelerate to a new set speed (resets when switch is released), or to the minimum cruise speed of 20 mph (32 km/h).

CANCEL CRUISE CONTROL

To temporarily cancel the cruise control and allow use of the resume feature:

- Apply the brakes, or
- Pull the clutch lever in, or
- Roll the throttle grip forward past the idle position

To cancel the cruise control and erase the set speed from memory, press the cruise on/off switch.

PARKING

Choose a firm level surface to park the motorcycle.

1. When fully stopped, shift into neutral.
2. Stop the engine.
3. Fully extend the sidestand.
4. Turn the handlebars to the left and lean the motorcycle to the left until the sidestand firmly supports the motorcycle.
5. Remove the ignition key.

PARKING ON A SLOPE

If parking on a slope is unavoidable, park with the front wheel uphill from the rear wheel. Place the transmission in first gear and position the motorcycle so that it is stable when it rests on the sidestand.

NOTICE

Always park with the front wheel uphill from the rear wheel when parking on a slope. If the front wheel is downhill from the rear wheel, the sidestand could retract and cause a tipover.

PARKING ON A SOFT SURFACE

If parking on a soft surface is unavoidable, place a sidestand footrest under the foot of the sidestand to provide a firm surface. The sidestand footrest must be strong enough and large enough to support the motorcycle's weight without sinking into the parking surface.

Asphalt becomes soft in hot weather. A sidestand can sink into soft asphalt and the motorcycle may fall. When parking on asphalt in hot weather, use a sidestand footrest.

CAUTION

Hot engine and exhaust components can cause burns to skin and can ignite a fire if exposed to flammable materials. Always park the motorcycle clear of flammable materials and where people are not likely to contact hot components.

MAINTENANCE SERVICE PROCEDURES

Any replacement part that is equivalent in performance and durability may be used in the performance of any maintenance or repairs. However, INDIAN MOTORCYCLE is not liable for these parts or failures or accidents that result from the use of these parts. The owner is responsible for the performance of all required maintenance. Such maintenance may be performed at a service establishment or by any individual. The warranty period begins on the date the motorcycle is delivered to an ultimate purchaser.

Proper maintenance assures the highest level of safety, durability and dependability for your motorcycle. Break-in maintenance is required to ensure warranty coverage and proper emissions system operation.

- Perform the *break-in maintenance procedures* (page 95) when the motorcycle's odometer registers 500 miles (800 km). Please see your authorized dealer for this service.
- Perform the recommended *periodic maintenance* at the intervals specified in the Periodic Maintenance Table.

SAFETY DURING SERVICE PROCEDURES



Failure to follow all recommended precautions and procedures could result in serious injury or death. Always heed all safety precautions and follow all operation, inspection and maintenance procedures outlined in this manual.

- Improperly installed or adjusted components can make the motorcycle unstable or hard to handle. Improperly installed electrical components can cause engine or electrical system failure. In either event, damage or serious injury could result. If you do not have the time, tools and expertise necessary to complete a procedure properly, please see your dealer for service.
- Review the safety-related maintenance information in the Safety Maintenance section.
- Before beginning any maintenance procedure, read the instructions for the entire procedure.
- Always position the motorcycle on a firm level surface before performing service. Make sure the motorcycle will not tip or fall while elevated or while on the sidestand. See the Elevating the Motorcycle section for details.
- Hot engine and exhaust components can cause burns to skin and can ignite a fire if exposed to flammable materials. Always park the motorcycle clear of flammable materials and where people are not likely to contact hot components.
- Wear eye and face protection when using pressurized air.
- Never start the engine or let it run in an enclosed area. Engine exhaust fumes are poisonous and can cause loss of consciousness or death in a short time.
- During some procedures you may use potentially hazardous products such as oil or brake fluid. Always follow the instructions and warnings on the product packaging.

ROAD TESTS

Before returning the motorcycle to regular use after performing service, road test it in a safe environment. Pay special attention to the proper fit and operation of all serviced components. Make any corrections or additional adjustments necessary to ensure safe vehicle performance.

MAJOR MAINTENANCE

Major repairs typically require technical skills and specially designed tools. Emission system service requires special tools and training and should be performed by your dealer. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

PERIODIC MAINTENANCE

Inspect, clean, lubricate, adjust and replace parts as necessary. When inspection reveals the need for replacement parts, use genuine INDIAN MOTORCYCLE parts available from your dealer. Record service and maintenance information in the Maintenance Log beginning on page 249.

Perform maintenance at the intervals specified in the Periodic Maintenance Table. *Vehicles subjected to severe use must be inspected and serviced more frequently.*

SEVERE USE DEFINITION

- high speed operation for extended periods
- low speed operation for extended periods
- operation in dusty or otherwise adverse conditions
- operation in cold weather (temperatures below freezing)
- operation at max RPM for extended periods
- operation at minimum RPM with high load (lugging)
- operation with extreme load or weight

MAINTENANCE

MAINTENANCE INTERVALS

The maintenance interval charts outline required maintenance and inspection based on vehicle miles. Each table states the number of miles that service is required on the vehicle. Some items or components may need to be serviced more often due to severe use. When the vehicle goes beyond 40,000 miles (64,000 km), return to the 500 miles (800 km) chart and start the interval process over.

KEY

XU - Perform these procedures more often for vehicles subjected to severe use.

D - Have an authorized Indian Motorcycle dealer perform these services.

E - Emission Control System Service (California / International)

500 MILES (800 KM) SERVICE

ITEM		REMARKS
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Engine Mount Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
XU	Engine Oil*	Replace / rebuild.
XU	Engine Oil Filter*	Replace / rebuild.
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Check and Re-Torque Exhaust Joints	Perform.
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).

ITEM		REMARKS
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Inspect (tighten, clean, adjust, correct or replace if necessary).
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Lubricate with proper lubricant as directed.
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.
D	Head Light	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Lubricate with proper lubricant as directed.
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).

MAINTENANCE

ITEM		REMARKS
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

2,500 MILES (4,000 KM) SERVICE

ITEM		REMARKS
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Inspect (tighten, clean, adjust, correct or replace if necessary).
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Lubricate with proper lubricant as directed.

ITEM		REMARKS
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.
D	Head Light	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

MAINTENANCE

5,000 MILES (8,000 KM) SERVICE

ITEM		REMARKS
	Air Filter	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Check and Re-Torque Exhaust Joints	Perform.
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Inspect (tighten, clean, adjust, correct or replace if necessary).
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Lubricate with proper lubricant as directed.
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.

ITEM		REMARKS
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Lubricate with proper lubricant as directed.
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

10,000 MILES (16,000 KM) SERVICE

ITEM		REMARKS
	Air Filter	Replace / rebuild.
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).

MAINTENANCE

ITEM		REMARKS
XU	Engine Oil*	Replace / rebuild.
XU	Engine Oil Filter*	Replace / rebuild.
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Check and Re-Torque Exhaust Joints	Perform.
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Replace / rebuild.
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Lubricate with proper lubricant as directed.
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.
D	Head Light	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).

ITEM		REMARKS
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

15,000 MILES (24,000 KM) SERVICE

ITEM		REMARKS
	Air Filter	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).

MAINTENANCE

ITEM		REMARKS
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Inspect (tighten, clean, adjust, correct or replace if necessary).
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Replace / rebuild.
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).

ITEM		REMARKS
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

20,000 MILES (32,000 KM) SERVICE

ITEM		REMARKS
	Air Filter	Replace / rebuild.
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).
XU	Engine Oil*	Replace / rebuild.
XU	Engine Oil Filter*	Replace / rebuild.
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Check and Re-Torque Exhaust Joints	Perform.
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).

MAINTENANCE

ITEM		REMARKS
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Replace / rebuild.
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Lubricate with proper lubricant as directed.
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.
D	Head Light	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).

ITEM		REMARKS
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

25,000 MILES (40,000 KM) SERVICE

ITEM		REMARKS
	Air Filter	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Fuel Filter	Replace / rebuild.
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Inspect (tighten, clean, adjust, correct or replace if necessary).

MAINTENANCE

ITEM		REMARKS
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.

* Replace at specified interval or annually if driven in extreme conditions.

** Replace at specified interval or every 2 years.

30,000 MILES (48,000 KM) SERVICE

ITEM		REMARKS
	Air Filter	Replace / rebuild.
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Replace / rebuild.
XU	Engine Oil*	Replace / rebuild.
XU	Engine Oil Filter*	Replace / rebuild.
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Check and Re-Torque Exhaust Joints	Perform.
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Replace / rebuild.
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Lubricate with proper lubricant as directed.

MAINTENANCE

ITEM		REMARKS
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Replace / rebuild.
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.
D	Head Light	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

35,000 MILES (56,000 KM) SERVICE

ITEM		REMARKS
	Air Filter	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Inspect (tighten, clean, adjust, correct or replace if necessary).
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.
D	Rear Shock, Bushings, and Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).

MAINTENANCE

ITEM		REMARKS
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

40,000 MILES (64,000 KM) SERVICE

ITEM		REMARKS
	Air Filter	Replace / rebuild.
D	Crankcase Ventilation System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Cooling System / Radiator	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Drive Belt	Inspect (tighten, clean, adjust, correct or replace if necessary).

ITEM		REMARKS
	Engine Compression	Inspect (tighten, clean, adjust, correct or replace if necessary).
XU	Engine Oil*	Replace / rebuild.
XU	Engine Oil Filter*	Replace / rebuild.
E	Evaporative Emission Control System (If Equipped)	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Check and Re-Torque Exhaust Joints	Perform.
D	Fuel System	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Spark Plugs	Replace / rebuild.
	Engine Coolant	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Valve Lash Clearance	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Battery	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Fluid**	Replace / rebuild.
XU / D	Brake Pads	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Clutch Lever / Cable Ends	Lubricate with proper lubricant as directed.
	Fasteners	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Brake Lever / Pedal	Lubricate with proper lubricant as directed.
D	Front Fork Oil / Seals**	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Front Forks and Front Axle	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Gear Shift Lever	Lubricate with proper lubricant as directed.

MAINTENANCE

ITEM		REMARKS
D	Head Light	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Rear Shock, Bushings, and Fasteners	Replace / rebuild.
D	Rear Wheel Alignment	Inspect (tighten, clean, adjust, correct or replace if necessary).
	Road Test	Perform.
D	Sidestand / Sidestand Safety Switch	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Steering Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Swing Arm, Rear Axle, Swing Arm Pivot, and Pivot Bearings	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Tires / Wheels	Inspect (tighten, clean, adjust, correct or replace if necessary).
D	Software Update	Check for available software updates on all applicable electrical controllers in Digital Wrench. Update software as required (dealer only). If equipped, visit the INDIAN MOTORCYCLE Ride Command website for the latest map and software updates to the Digital Round display.
* Replace at specified interval or annually if driven in extreme conditions.		
** Replace at specified interval or every 2 years.		

OIL AND FILTER CHANGE

Follow all instructions carefully. Do not overfill.

Change the engine oil at the intervals specified in the Periodic Maintenance Table. Change the oil more frequently if the motorcycle is subjected to severe use, especially operation in cold weather. Always use the recommended oil. See page 230.

NOTICE


Failure to perform frequent oil changes during cold weather operation can result in condensation forming. Freezing condensation can result in plugged oil lines and serious engine damage.

NOTICE

After an oil change, the low oil pressure indicator may illuminate when the engine is started. If this occurs, do not increase RPM above idle speed until the indicator turns off. Operating above idle speed could result in damage to the engine.

1. Change the oil and filter ① when the engine is warm. If the engine is cold, start the engine and allow it to run at idle for at least five minutes.
2. Park the motorcycle with the sidestand down on a firm, level surface. For proper oil drain, use a service lift to ensure the motorcycle is vertically centered.

3. Clean the area around the two drain plugs ②. Place a drain pan under both drain plugs.



CAUTION

Hot oil can cause burns to skin. Do not allow hot oil to contact skin.

4. Remove the drain plugs ②. Allow the oil to drain completely.
5. Install new sealing washers on the drain plugs. The sealing surfaces on drain plugs and engine should be clean and free of burrs, nicks or scratches.

MAINTENANCE

6. Reinstall the drain plugs.

TORQUE

15 ft-lbs (20 N·m)

7. Place a drain pan or shop towels under the oil filter. Using an oil filter wrench, turn the filter counter-clockwise to remove it.
8. Using a clean dry cloth, clean the filter sealing surface on the engine.
9. Lubricate the o-ring on the new filter with a film of fresh engine oil. Check to make sure the o-ring is in good condition.
10. Install the new filter and rotate it clockwise by hand until the filter gasket contacts the sealing surface, then turn it an additional 3/4 to one full turn.
11. Using a funnel, add 3.5-4 qt (3.3-3.8 L) of the recommended oil through the engine oil fill port.
12. With the motorcycle in an upright, centered position, start the engine and allow it to idle for 30 seconds. Stop the engine.
13. Inspect the oil level by looking at the oil sight glass. The oil level should be at or near the full mark on the oil sight glass.
DO NOT OVERFILL!

IMPORTANT

Total engine oil fill volume with oil filter change will be approximately 4.5 qt (4.26 L). Total engine oil fill volume with a new or rebuilt (dry) engine will be approximately 5.25 qt (4.97 L).

14. Refer to page 83 for setting the proper oil level.



CAUTION

If the low oil pressure indicator remains illuminated longer than usual after an oil change, do not increase RPM above idle until indicator lamp goes out or engine may be damaged.

15. Check for leaks around drain plug and oil filter.

NOTICE

Recycle used oil and oil filter in accordance with local regulations.

COOLING SYSTEM

The engine coolant level is controlled by the recovery system. Recovery system components are the recovery bottle, the radiator filler neck, the radiator pressure cap and the connecting hose.

As coolant operating temperature increases, the expanding (heated) excess coolant is forced out of the engine, past the pressure cap, and into the recovery bottle. As engine coolant temperature decreases the contracting (cooled) coolant is drawn back up from the bottle, past the pressure cap, and into the radiator.

Some coolant level drop on new vehicles is normal as the system is purging itself of trapped air. Check the coolant level and maintain as recommended by adding coolant to the recovery bottle.

INDIAN MOTORCYCLE recommends the use of Antifreeze 50/50 Premix. This antifreeze is already premixed and ready to use. Do not dilute with water.

To ensure that the coolant maintains its ability to protect the engine, we recommend that the system be completely drained every five years or 40,000 miles (64000 km), whichever comes first. Please see your dealer for this service.


COOLANT LEVEL INSPECTION



CAUTION

Allow the vehicle to cool before performing any maintenance on the cooling system. Failure to do so could result in burns to skin.

Check the coolant level when the bike is held upright on a level surface, not on sidestand. The bike should be cold and off for at least 4 hours before checking the coolant level. Remove the recovery bottle dipstick ① and wipe it with a clean cloth. Fully install the dipstick until it touches off on the coolant bottle to ensure an accurate measurement. Remove the dipstick and check the coolant level. The coolant level should be between the ADD and FULL COLD marks on the dipstick.




NOTICE

The recovery bottle is vented to prevent overfilling. Coolant will vent onto the ground if overfilled.

MAINTENANCE

If the coolant level is low, add fluid until the level is within the ADD and FULL COLD marks. Do not fill past the FULL COLD mark.



AIR FILTER INSPECTION AND REPLACEMENT


Inspect and replace the air filter at the intervals specified in the Periodic Maintenance Table.

1. Remove the seat. See page 169.
2. Remove the fuel tank. See page 134.


NOTICE

Use care to prevent debris from entering the air box when the filter is removed.

3. Remove and retain the four fasteners ① that secure the filter cover to the airbox.



4. Carefully pry the filter cover up and towards the rear of the motorcycle.



5. Inspect the air filter. Do not attempt to clean the air filter. Replace a soiled or damaged filter with a new filter in the same orientation as the old filter.

NOTICE

Make sure the air filter is fully seated into the filter cover tray.

⚠ CAUTION

A bent, improperly installed filter element, or loose fitting cover may allow debris to enter the engine which may cause premature engine wear.



MAINTENANCE

6. Install and torque the four fasteners to specification.

TORQUE
14 in-lbs (1.6 N·m)

7. Reinstall the fuel tank. See page 139.

8. Reinstall the seat. See page 169.

FUEL FILTER

The fuel filter is attached to the electric fuel pump located inside the fuel tank. See your authorized INDIAN MOTORCYCLE dealer or other qualified dealer for replacement.

FUEL SYSTEM DEPRESSURIZATION

 **WARNING**

Allow engine and exhaust to cool completely before disconnecting fuel line or removing tank. Wear eye protection.

1. Remove the seat. See page 169.
2. Locate the fuel pump fuse.
3. Pull the fuel pump fuse and crank the engine over for 5 seconds to release fuel pressure.
4. Wrap a clean shop towel around the fuel line fitting at the fuel rail.

5. Disconnect the fuel line from the fuel rail. There are two ways to disconnect the quick connect. See Fuel Tank Removal for details.

6. Cover the fuel fittings to keep debris out.

FUEL TANK REMOVAL


 **WARNING**

Allow engine and exhaust to cool completely before disconnecting fuel line or removing tank. Protect fuel tank finish when removing, storing, and installing tank.

Be prepared to place the fuel tank in a secure location with a drain pan positioned to catch any fuel that may leak or drip from disconnected hoses or fittings.

1. Remove the seat. See page 169.
2. Depressurize the fuel system.

3. Remove the two fuel tank console fasteners ① and console ②.




4. On motorcycles equipped with a digital display, move the antenna cover console aside. The antennas can remain attached.

5. Disconnect the fuel tank vent line ③ under the seat.


NOTICE

Cast frame hidden for image clarity.




MAINTENANCE

6. Remove the rear tank cover ④. Apply a trim tool or use a small screwdriver at the arrow location to pry the cover outwards to release the retainer.




7. Remove the two rear fuel tank fasteners ⑤.




8. Place a clean shop towel under the fuel line fitting at the fuel rail.

9. Disconnect the fuel line ⑥ from the fuel rail ⑦.



There are two ways to disconnect the quick connect:

- Option 1: Use a small screwdriver to pry up on the yellow lock tab.




MAINTENANCE


- Option 2: Use your fingers to pull rearward on the release tabs at the bottom of the connector and at the same time, slide the lock tab up while pulling the connector gently away from the fuel rail.

CAUTION

Do not use anything other than fingers or the tools specified to remove the quick connection.



10. Lift the rear of the fuel tank and disconnect the fuel pump electrical connector (8).



11. Lift the rear of the fuel tank and slide it rearward to release from the front isolators.
12. Lift the fuel tank off of the motorcycle.

IMPORTANT

During removal, make sure the fuel line does not get tangled or retained on any components or features that may cause damage. Do not lift the tank away from the motorcycle if fuel line is constrained.

FUEL TANK INSTALLATION

1. Secure the handlebars in the straight ahead position.
2. Apply soapy water or rubber lubricant onto the front tank isolators and lower the fuel tank onto the isolators.
3. While supporting the rear of the fuel tank, route the fuel line inward of the frame tube and connect it to the fuel rail.

IMPORTANT

Verify the fuel line is properly seated and locked into place by listening for an audible “click” and watching the locking tab drop automatically when pressing into place. Pull gently on the quick connector once seated to make sure a proper connection has been made. If the fuel line fails to click, or fails the pull portion of the test above, replace the fuel line.

4. While supporting the fuel tank, connect the fuel pump electrical connector.
5. Install the rear fuel tank fasteners. Torque fasteners to specification.

TORQUE

Rear Fuel Tank Fasteners:
18 ft-lbs (24 N·m)

6. Prime the fuel system to ensure proper installation without fuel leaks. See page 97.

7. Start the motorcycle and inspect and verify no leaks are present.
8. On models equipped with a digital display, move the antenna console, with antennas attached, back into position on the tank.
9. Install the rear tank cover. Make sure any wires under the cover are not pinched.
10. Install the tank console. Torque fasteners to specification.

TORQUE

Tank Console Fasteners:
44 in-lbs (5 N·m)

11. Connect the fuel tank vent line to chassis vent line. Make sure the connection is fully made and the clamp is properly in place. Secure the vent line into the rear tank cover.
12. Install the seat. See page 169.


MAINTENANCE

DRIVE BELT MAINTENANCE

LIFTING THE MOTORCYCLE

WARNING

Failure to properly lift and stabilize motorcycle may allow it to tip or fall, resulting in serious injury or death.



Position motorcycle platform jack beneath engine case, avoiding oil drain plug, and lift motorcycle so front wheel is off ground. Stabilize motorcycle in upright position with tie-down straps (or equivalent). Motorcycle **MUST** be stable prior to performing belt maintenance procedures.

IMPORTANT

Automotive floor jack does not provide adequate stability and is **NOT RECOMMENDED!**

DRIVE BELT TENSION CHECK

IMPORTANT

Perform this procedure to achieve proper belt tension and alignment. Belt tension should be set before performing alignment procedure.

WARNING

A drive belt that is not properly tensioned can cause drive line noise and damage the drive belt, causing possible belt failure and loss of control of the motorcycle.

1. Inspect the drive belt for damage and wear.
2. Make sure the rear wheel is elevated before checking or adjusting the tension.

DRIVE BELT TENSION ADJUSTMENT

IMPORTANT

Perform this procedure to achieve proper belt tension and alignment. Belt tension should be set before performing alignment procedure.

WARNING

A rear axle *not* in alignment can cause drive line noise and damage the drive belt, causing possible belt failure and loss of control of motorcycle.

3. Use the tire valve stem as a reference and perform the following steps:
 - a. Check / record the belt deflection at four different points, 90° apart. Rotate the wheel in a COUNTER-CLOCKWISE rotation as viewed from the belt side of the motorcycle.
 - b. Adjust the belt deflection with the wheel at the tightest point (least deflection).
4. Place a tape measure or ruler next to the drive belt.
5. Slide the o-ring on the belt tension gauge (Special Tool PV-43532) to the 10 lb (4.54 kg) mark.
6. Place the belt tension gauge squarely against the belt at center and keep it at a 90° angle to the belt surface.
7. Push up on the gauge until the o-ring just touches the tool body and compare to specification.

MEASUREMENT

Drive Belt Deflection @ 10 lbs force:
15/32 in (12 mm)


8. If the belt deflects more than specified distance with 10 lb (4.54 kg) of force, proceed to **Drive Belt Adjustment** and tighten the belt. If the belt deflection is less than specified, proceed to **Drive Belt Adjustment** and loosen the belt. If the belt deflection is correct, lower the motorcycle.

MAINTENANCE

1. Make note of adjuster locations ① and ②.

NOTICE


The exhaust is hidden for image clarity.




2. On right side of motorcycle, loosen the axle nut ③. Retighten to **Adjustment Specification**.

TORQUE

Adjustment Specification: 15 ft-lbs (20 N·m)



3. Turn the **LEFT SIDE** adjuster nut ④ to achieve proper belt tension.



4. When belt tension is correct continue to next section and adjust final belt alignment.

DRIVE BELT ALIGNMENT

WARNING


Drive belt misalignment can cause drive line noise and damage drive belt, causing possible belt failure and loss of control of motorcycle.

NOTICE

To minimize change in belt tension, use **RIGHT SIDE** adjuster only to make final adjustments to belt alignment. Be sure to keep axle seated forward against axle adjusters during this procedure.


MAINTENANCE

1. Rotate wheel **BACKWARD**. Tighten **RIGHT SIDE** adjuster nut ① until drive belt comes off inside sprocket flange during backward wheel rotation and is centered in the driven pulley as shown with arrows.



IMPORTANT

Belt should track to center of sprocket tooth surface when properly aligned. Sprocket teeth should be visible on both sides of drive belt.



2. Rotate wheel **FORWARD** and verify sprocket teeth are still visible on both side of drive belt.

3. If necessary, loosen axle nut and **RIGHT SIDE** adjuster until belt moves off left flange and begins to track down center of driven sprocket flange during forward wheel rotation.

NOTICE

It may be necessary to loosen axle nut and tap left end of axle to ensure it moves forward when adjuster is loosened. Axle nut *must* be retightened to **Adjustment Specification** (15 ft-lbs (20 N·m)) before proceeding.

4. Rear wheel alignment is satisfactory when drive belt remains centered on driven sprocket during forward and backward wheel rotation. Sprocket teeth should be visible from both sides of drive belts.
5. Verify drive belt tension is still within specification. (See **Check Drive Belt Tension** section)
6. Tighten rear axle nut to **Final Specification**.

TORQUE

Final Specification: 65 ft-lbs (88 N·m)

7. Pump rear brake pedal several times to reset brake pad distance.
8. Verify wheel rotates smoothly and freely without drag when brake pedal is released.
9. Lower motorcycle.

REAR DRIVE BELT CLEANING

Cleaning the drive belt will maximize belt and sprocket life and minimize drive line noise. Clean the belt at every tire change. Clean the belt more often if riding in dirty, dusty or high debris environments.

1. Mix a few drops of mild dish soap with a cup of warm water.
2. Use a soft nylon brush to clean the belt and sprocket teeth with the soapy water. Clean well in corner areas where road debris and belt dust can collect.
3. Rinse the belt with clear water, then dry thoroughly.

REAR DRIVE BELT CONDITION


Inspect the rear drive belt at the intervals specified in the Periodic Maintenance Table. Shallow cracks on the back side of the belt (side opposite the teeth) should be monitored for other damage but are not cause for belt replacement. The belt should be replaced if it is frayed, has broken teeth, or has cracks extending through the core strands. No matter its condition, the drive belt should be replaced at periodic intervals. See the *INDIAN MOTORCYCLE Service Manual* or an authorized *INDIAN MOTORCYCLE* dealer or other qualified dealer.

Replace the drive belt and both sprockets as a set if the drive belt has over 5,000 miles (8,000 km) of service at the time of damage or failure.



NOTICE





Image is for reference only. Your model might differ slightly.



MAINTENANCE



REAR DRIVE BELT WEAR ANALYSIS

WEAR ANALYSIS	BELT CONDITION
Internal tooth cracks (hairline): OK to run, but monitor condition	
External tooth cracks: Replace belt	


WEAR ANALYSIS	BELT CONDITION
Missing teeth: Replace belt	
Chipping (not serious): OK to run, but monitor condition	
Fuzzy edge cord: OK to run, but monitor condition	
Hook wear: Replace belt	

WEAR ANALYSIS	BELT CONDITION
Stone damage: Replace belt if damage is on edge	
Bevel wear (outboard edge only): OK to run, but monitor condition	

REAR SHOCK PRELOAD (RIDE HEIGHT) INSPECTION

Periodically measure rear shock preload. Have an assistant help with this procedure.

For the most comfortable ride and proper ground clearance, adjust preload if ride height is out of specification.



MAINTENANCE

1. Verify that tire pressure is at specification. See page 168.
2. Load the motorcycle with all intended cargo. Wearing your riding gear, bring the motorcycle to the upright position and sit on the operator's seat. If you plan to carry a passenger, have the passenger (with riding gear) sit on the passenger seat.



WARNING

Do not carry a passenger unless the motorcycle is equipped with passenger seat and passenger footrests.

3. Measure shock preload from upper mount bolt center to lower mount bolt center (eye-to-eye) ①. Perform this measurement on both shocks.
4. Ride height should be set on both shocks. If the measurement differs, adjust the preload.

MODEL	RIDE HEIGHT MEASUREMENT
Scout Bobber (2") Scout Sixty Bobber (2")	10.9 in (278 mm)
Scout Classic (3") Super Scout (3") Sport Scout (3") Scout Sixty Classic (3") Sport Scout Sixty (3")	11.1 in (282 mm)
101 Scout (3" Piggyback)	11.1 in (282 mm)

REAR SHOCK PRELOAD (RIDE HEIGHT) ADJUSTMENT

Special tools are required to perform this procedure. See the *INDIAN MOTORCYCLE Service Manual* or your authorized INDIAN MOTORCYCLE dealer or other qualified dealer.



WARNING


Uneven adjustment may cause poor handling of the motorcycle, which could result in an accident. Always adjust both the left and right shock preload equally, or have your dealer perform the adjustments.

1. Verify that tire pressure is at specification. See page 168.
2. Rest the motorcycle on the sidestand.

3. Ensure threads are clear of all dirt and debris before loosening the lock nut ①. Loosen the lock nut by turning it counter-clockwise (as viewed from the top of shock) with the spanner wrench. The upper spanner nut on the shock is the lock nut. The lower spanner nut is the adjuster nut ②.

⚠ WARNING

Ensure threads on shock body are clean and clear of debris before adjusting the spanner nuts. Before attempting to adjust downward, spin the spanner nuts one full revolution upward and then adjust in the downward position.



4. Spray a light lubricant on the adjuster nut where it contacts the spring. DO NOT allow spray to contact the drive belt.
5. Adjust shock preload by rotating the adjuster nut clockwise (as viewed from the top of shock) to INCREASE preload ③ (raise) or counter-clockwise to DECREASE preload ④ (lower).
6. Recheck the preload measurement after adjusting.
7. Tighten the lock nut securely against the adjuster nut.

REAR SHOCK ADJUSTMENT GUIDE

IMPORTANT

Make sure the rear shock preload is set correctly before changing compression and rebound settings below.

NOTICE

101 Scout models feature a fully adjustable fork and rear suspension components.


NOTICE

Turning the adjusters fully clockwise (+) will result in a “fully-closed” position, while turning the adjusters fully counter-clockwise (-) will result in a “fully-open” position.

MAINTENANCE

REAR SHOCK FACTORY SETTING

	101 SCOUT
Shock Rebound, lower end of shock ①	2 clicks from closed (4 clicks total)
Shock Compression, reservoir end of shock ②	2 clicks from closed (4 clicks total)



SWING ARM/REAR AXLE INSPECTION

1. Sit in the operator's seat and slowly bounce the rear suspension a few times. Make sure the suspension moves freely without binding. Listen for abnormal noises.
2. Elevate and support the motorcycle with the rear tire slightly off the floor. See the Elevating the Motorcycle section for details.


 CAUTION

Make sure the motorcycle is stable when elevated. Personal injury and/or damage to the vehicle may occur if the motorcycle tips or falls.

3. Grasp the rear wheel and attempt to move the wheel side-to-side. If there is movement at the front of the swingarm or in the axle area, see your dealer for service.
4. With the transmission in neutral, slowly rotate the rear wheel. If the wheel does not rotate smoothly, see your dealer for service.

FRONT FORK / SUSPENSION INSPECTION

1. Place the motorcycle on the sidestand and inspect the front forks. If fork oil is present on the outer fork tube ①, *do not ride the motorcycle*. See your dealer for service before operating. If fork oil is present around the fork seal ② or inner fork tube ③, replace the fork seal.



3. Straddle the motorcycle and bring it to the fully upright position. Apply the front brake and push downward (hard) on the handlebars several times. The front suspension should operate smoothly and quietly.
4. Fork oil condition and level affects front suspension performance and internal component wear. Replace fork oil at the intervals specified in the Periodic Maintenance Table. Special tools are required to perform this procedure. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

2. Clean the inner fork tubes to remove bugs, tar or buildup which may cause seal wear or leakage. Inspect the outer surfaces of the inner fork tubes for scratches or damage from foreign objects.

FRONT FORK ADJUSTMENT GUIDE

NOTICE

Turning the adjusters fully clockwise (+) will result in a “fully-closed” position, while turning the adjusters fully counter-clockwise (-) will result in a “fully-open” position.

FRONT FORK FACTORY SETTINGS

	101 SCOUT
Preload (LH Fork) ①	5 turns (<i>in from full open</i>) (10 turns total)
Compression Adjustment (RH Fork) ②	2 turns from open (<i>8 turns total</i>)
Rebound Adjustment (RH Fork) ③	7 clicks from closed (<i>10 clicks total</i>)



STEERING HEAD INSPECTION


1. Elevate and support the motorcycle with the front tire slightly off the floor. See the Elevating the Motorcycle section for details.

CAUTION

Make sure the motorcycle is stable when elevated. Injury may occur if the motorcycle tips or falls.

2. Turn the handlebars from stop to stop. The action should be smooth but not loose. Make sure wires, hoses and control cables do not interfere with smooth steering.
3. Position the front wheel straight ahead. Grasp the front forks near the front axle and attempt to move the wheel front-to-back. If there is front-to-back movement at the steering head, see your dealer for service.
4. If steering binds, feels rough or uneven, or if movement is detected at the steering stem, see your dealer for service.
5. Rotate the front wheel and inspect for smooth rotation of front wheel bearings. If roughness or unusual sounds are present, see your dealer for service.
6. Turn handle bars full right or left and hold against the fork stop. Attempt to move front wheel side-to-side. If movement is observed, see your dealer for service.


CRANKCASE BREATHER HOSES



Inspect the crankcase breather (vent) hoses ① each time the fuel tank is removed to perform air filter service or other maintenance. Inspect both breather hoses along their length and at both ends. Make sure hoses are not restricted, kinked, cracked or otherwise damaged. Replace any worn or damaged hoses.

EVAPORATIVE EMISSION CONTROL SYSTEM (IF EQUIPPED)

1. Inspect all evaporative emission control system hoses and connections. Make sure all connections are tight and clamped properly.
2. The evaporative emissions canister ① is located under the mid frame. Make sure it is securely fastened to the mounting bracket.



MAINTENANCE

3. Inspect the connections at the evaporative emissions canister to make sure they are secure.
4. Inspect the vent connections at the rear of the fuel tank, at the fuel tank, and at the purge valve (behind the right-hand engine cover) to make sure they are secure.

FUEL SYSTEM COMPONENTS

1. Inspect fuel hoses for cracks or damage.
2. Inspect hose connections at the fuel tank and at the fuel rail for dampness or stains from leaks.
3. The fuel system is under pressure and caution must be used when inspecting and servicing the fuel system. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

THROTTLE CONTROL INSPECTION

1. With the engine OFF, rotate the throttle control grip fully open and then release it. It should rotate smoothly from the rest position to the completely open position. It should return to the rest position quickly when released.
2. Service the throttle system if throttle operation is not smooth or if throttle grip does not return properly. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

SIDESTAND LUBRICATION

Periodically lubricate the sidestand bushing. See page 91 for sidestand inspections.


MECHANICAL CLUTCH

MECHANICAL CLUTCH LEVER FREEPLAY

The clutch cable freeplay can be adjusted with either the adjuster above the left-hand V-cover or with the adjuster at the lever perch.


For small freeplay adjustments, utilize the adjuster at the lever perch as follows:

1. Loosen the adjuster dial.
2. Rotate the adjuster fitting until the freeplay is correct.
3. Tighten the adjuster dial against the lever perch. The freeplay should be 0.02-0.059 in (0.5-1.5 mm).



If the perch adjuster has reached its adjustment limit (0.43 in (11 mm) between the adjuster fitting flange and the adjuster dial with the dial tightened against the perch OR the adjuster fitting and dial are bottomed out against the lever perch), then utilize the V-cover adjuster to get the perch adjuster back in range.


1. The V-cover adjuster is located underneath a rubber protective cover ① on the left side of the vehicle above the V-cover. While holding the clutch cable, slide the rubber protective cover forward to reveal the adjuster.



2. Unclip the cable from the rear two clips for easier adjuster access. Make sure the cable is re-clipped and retained after adjustment.


MAINTENANCE

3. Loosen the lock nut. While holding the cable, turn the adjuster nut in or out until the perch adjuster can be positioned in the middle of its range and the freeplay is correct 0.02-0.059 in (0.5-1.5 mm) ②.
4. While holding the cable, tighten the adjuster lock nut securely and slide the protective rubber cover rearward to cover the cable adjuster.
5. Verify that the safety switch activates properly. Safely elevate the rear wheel, and verify the engine does not start in gear with the clutch lever ③ released.



MECHANICAL CLUTCH LEVER LUBRICATION

1. Remove the plastic cap from the pivot pin. Be careful not to scratch the finish during removal.
2. Add clutch lever free play by loosening the perch adjuster dial and screwing the perch adjuster fitting fully into the perch.
3. Remove the clutch lever pivot nut ① and screw ②. Disconnect the clutch cable ③ from the clutch lever.



4. Remove any old grease and dirt from the lever and housing. Lubricate the clutch lever and pivot screw with moly assembly grease or all-purpose grease.

5. Reconnect the clutch cable. Hold the screw down and tighten the nut.

TORQUE

Screw: 49 in-lbs (5.5 N·m)
Nut: 49 in-lbs (5.5 N·m)

6. Adjust clutch lever freeplay. See page 155.

MECHANICAL CLUTCH CABLE LUBRICATION

Lubricate the clutch cable barrel ends at the intervals recommended in the Periodic Maintenance Table.

NOTICE


The clutch cable is factory-lubricated. Additional lubrication could be detrimental to cable performance. Replace the clutch cable assembly if binding or sticking occurs. **DO NOT** lubricate between the cable and sheath.

Verify proper routing and smooth movement. Inspect for damage to the external casing, and inspect exposed cable wire for fraying, kinks or corrosion. Replace any damaged, sticky or sluggish cable.

1. Disconnect the cable at the clutch lever and at the primary cover.
2. Lubricate the upper barrel end ① and the pinion arm pivot joint with all-purpose grease.

NOTICE

Image is for reference only. Your model might differ slightly.



3. Reconnect the cable and adjust freeplay as needed.

BRAKES

REAR BRAKE PEDAL

1. Lubricate the pivot bushing at the intervals recommended in the Periodic Maintenance Table. Also lubricate any time binding is evident. Use all-purpose grease.
2. Inspect brake pads as outlined on page 161.

BRAKE HOSES/CONNECTIONS

Inspect all brake hoses and connections for dampness or stains from leaking or dried fluid. Tighten any leaking connections and replace components as necessary. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

BRAKE FLUID PRECAUTIONS



WARNING

Using the wrong fluid or allowing air or contaminants into the fluid system can damage the system seals or result in a malfunction that could lead to serious injury or death. Use only DOT 4 brake fluid from a sealed container.

Do not operate the front brake with the reservoir cover removed. Fluid could overflow from the reservoir and allow air to enter the system. Air in the brake system could cause the brakes to malfunction.

An over-full reservoir may cause brake drag or brake lock-up, which could result in serious injury or death. Maintain brake fluid at the recommended level. Do not overfill.

NOTICE


Brake fluid will damage painted surfaces and plastic parts. Always clean spilled brake fluid immediately with water and a mild detergent.

REAR BRAKE FLUID

Change the brake fluid at the intervals recommended in the Periodic Maintenance Table. Always add brake fluid from a new, unopened container. Always use the recommended fluid. See page 230.

1. Position the motorcycle on level ground in the fully upright position.
2. The rear brake fluid reservoir is located near the rear brake pedal. View the reservoir from the right side of the vehicle.
3. Wipe the fluid container and the area around the reservoir cover with a clean cloth.
4. If the fluid level is low, inspect brake pads as outlined on page 161. If pads are not worn beyond the service limit, inspect the brake system for leaks.

5. Remove the cover and diaphragm. The fluid level should be above the minimum indicator mark on the reservoir sight glass
①. Add the recommended brake fluid as needed. *Do not overfill.*



6. Reinstall the cover and diaphragm. Tighten the cover screws.


TORQUE

13 in-lbs (1.5 N·m)

7. Wipe away any fluid spills. Check for signs of brake fluid leaks around hoses, fittings, reservoir, and brake calipers.

FRONT BRAKE LEVER

1. To lubricate the front brake lever, unscrew the bottom nut ① and screw ② to access the hinge point ③.



2. Lubricate the pivot pin and brake lever hinge point at the intervals recommended in the Periodic Maintenance Table. Also lubricate any time binding is evident. Use all-purpose grease.
3. Once properly lubricated, reinstall the components in accordance with their proper torque values.

MAINTENANCE

TORQUE

Screw: 4–13 in-lbs (0.5–1.5 N·m)

Nut: 44–62 in-lbs (5–7 N·m)

FRONT BRAKE FLUID


Change the brake fluid at the intervals recommended in the Periodic Maintenance Table.

Do not attempt to change the anti-lock brake system fluid. Please see your dealer for this service.

Always add brake fluid from a new, unopened container. Always use the recommended fluid. See page 230.

1. Position the motorcycle on level ground in the fully upright position. Position the handlebars so that the fluid reservoir is level. Wipe the fluid container and the area around the reservoir cover with a clean cloth.
2. If the fluid level is low, inspect brake pads as outlined on page 161. If pads are not worn beyond the service limit, inspect the brake system for leaks.

3. To add fluid, remove the reservoir cover screws. Remove the cover ①, diaphragm plate ②, and diaphragm ③.



4. The fluid level should be above the minimum indicator mark next to the sight glass ④. Add the recommended brake fluid as needed. *Do not overfill.*

5. Reinstall the diaphragm, diaphragm plate, cover, and screws. Torque screws to specification.

TORQUE

13 in-lbs (1.5 N·m)

6. Wipe away any fluid spills. Check for signs of brake fluid leaks around hoses, fittings, reservoir and brake calipers. Check for deterioration of hoses.

BRAKE PADS

⚠ CAUTION


Allow the brake components to cool before performing any inspections on the brake system. Failure to do so could result in burns to skin.

Inspect each front brake pad on both sides of the front disc or discs, as some models have more than one front disc. Inspect each rear brake pad on both sides of the rear disc.

When checking brake pad friction material thickness, check each brake caliper for dampness or stains from leaking or dried brake fluid. If inspection reveals signs of fluid leakage, do not operate the vehicle. See your dealer for service.

Use an inspection mirror, positioned at the front side of the caliper, to view the friction material.

Replace brake pads when the thinnest point of the friction material has worn to 1.0 mm ①. Please see your dealer for this service.




NOTICE


With new pads and rotors, brake performance will be less effective. Avoid using brakes harshly, unless in an emergency, to allow pads to mate with the rotors. Brake efficiency will gradually increase during this seating period.

BRAKE DISC INSPECTION / CLEANING

1. Inspect brake discs ① for nicks, scratches, cracks or other damage. Inspect the thickness of each brake disc at four or more locations around the disc. If any disc is worn to the minimum thickness at the thinnest point, or if a disc is damaged, see your dealer for replacement.



101 Scout Models




2. Clean discs if minor squeaks develop due to dirt or dust. Apply brake cleaner to a clean shop towel and wipe the discs. DO NOT allow brake cleaner to contact painted or plastic parts. Read all precautions on the label.


② Minimum Thickness:
0.18 in (4.5 mm)

ANTI-LOCK BRAKE SYSTEM (ABS) TONE RING / SENSOR INSPECTION

1. Visually inspect for damaged teeth on the front and rear ABS tone rings ①. Inspect for nicks and dents on the face of the teeth. The teeth edges should be consistent in appearance. If a tone ring is damaged, see your dealer for replacement as soon as possible.



101 Scout Models



2. Inspect for debris adhering to the end of the wheel speed sensors ②. If contamination is observed, or if you are unable to visually inspect, slide a thin towel across the face of the sensor between the sensor and the tone ring to remove any potential debris.

Air Gap Between Sensor and Tone Ring:

1.8 – 2.8mm

WHEEL INSPECTION

Inspect both wheels for cracks or damage and replace damaged wheels promptly. Do not operate the motorcycle if wheels are damaged or cracked. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

WHEEL ALIGNMENT


Inspect rear wheel alignment at regular service intervals, whenever the rear wheel is removed and when the rear drive belt is adjusted. Please see your dealer for this service.

FRONT WHEEL INSTALLATION

ALL MODELS (EXCEPT 101 SCOUT MODELS)

If the front wheel is removed for any reason, it must be reinstalled in the correct rotating direction.

Clean all wheel components before installation. Apply a light coat of all-purpose grease to the axle.



① Right Fork Tube

② Left Fork Tube

③ Axle Bolt
52 ft-lbs (70 N·m)


④ Pinch Bolt
18 ft-lbs (25 N·m)

MAINTENANCE

101 SCOUT MODELS

If the front wheel is removed for any reason, it must be reinstalled in the correct rotating direction.

Clean all wheel components before installation.



① Right Fork Tube

② Left Fork Tube

③ Axle Bolt
59 ft-lbs (80 N·m)

④ Pinch Bolts
18 ft-lbs (25 N·m)

⑤ Front Right Caliper

⑥ Front Left Caliper

⑦ Caliper Bolts
33 ft-lbs (45 N·m)

TIRES

WARNING

Operating the motorcycle with incorrect tires, incorrect tire pressure or excessively worn tires could cause loss of control or accident. Under inflation can cause a tire to overheat and result in a tire failure. Only use tires approved by INDIAN MOTORCYCLE for the model of the motorcycle. See your dealer for more information. Use of unapproved or an improperly mixed front and rear tire can result in decreased handling performance and stability, potentially leading to reduced control of the motorcycle. Always maintain proper tire pressure as recommended in the rider's manual and on safety labels.

TIRE REPLACEMENT

Tires, rims, innertubes and air valves must be correctly matched to wheel rims. Use only the tires approved by INDIAN MOTORCYCLE for the model of the motorcycle. INDIAN MOTORCYCLE-approved tires provide proper clearance between fenders, swingarm, drive belts and other components. See the Specifications chapter for details.

On models equipped with innertubes, innertubes **MUST** be replaced with new innertubes when tires are replaced. Use only the proper size innertubes.

WARNING

Mismatched tires, rims and air valves may result in damage to the tire bead during mounting or may allow the tire to slip off the rim, possibly resulting in tire failure.

TIRE CONDITION

Inspect the tire sidewalls, road contact surface, and tread base for cuts, punctures, and cracking. Replace damaged tires immediately. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

TIRE PRESSURE

Always check and adjust tire pressure when tires are cold. Do not adjust tire pressure immediately after riding. Wait at least 3 hours after riding to check pressure. If pressure checked and adjusted while tires are warm, the pressure will drop as tires cool and result in underinflation.

Adjust tire pressure as recommended for the total weight of your intended load (see chart below). For more information, refer to the manufacturing information label located on the front frame downtube. See page 30.

WARNING

Do not exceed the maximum recommended inflation pressure to seat the bead. Tire or rim failure may result.

MAINTENANCE

TIRE PRESSURE CHART

LOCATION	LOADS UP TO 200 LB (91 KG)	LOADS UP TO VEHICLE'S MAXIMUM LOAD CAPACITY
	RECOMMENDED PRESSURE	
All Models		
Front	36 psi (248 kPa)	36 psi (248 kPa)
Rear	40 psi (276 kPa)	40 psi (276 kPa)

TIRE TREAD DEPTH

Replace any tire with a tread depth of less than 1/16 in (1.6 mm).

Tread wear indicators are located in at least three places on the tread circumference and become visible at a tread depth of approximately 1/16 in (1.6 mm). The tread wear indicators appear as a solid band across the tread.

You may also use a depth gauge or an accurate ruler to measure the depth of the center tire tread on both front and rear tires.

SPARK PLUGS

See your dealer for spark plug inspections and replacement at the intervals recommended in the Periodic Maintenance Table.


SPARK PLUG SPECIFICATIONS	
Spark Plug Type	NGK® LZMAR8CI-10
Spark Plug Torque	9 ft-lbs (12 N·m)

SEAT REMOVAL / INSTALLATION (1-UP MODELS)


NOTICE

When removing the seat, use caution to avoid contact with the fuel tank.

When reinstalling the seat, use caution when you align the seat base grommets to the seat mount darts, to avoid damage to the grommets.




1. Grasp the front edge of the seat and pull up to disengage the front grommet ① from the front dart ②.



MAINTENANCE

2. Lift the seat and pull it slightly forward to disengage the rear grommet ③ from the rear dart ④.



3. To reinstall the seat, make sure the seat base engages the rear dart, then press down firmly on the front edge of the seat to engage the front dart to the grommet.

WARNING


If the seat is not aligned in a straight-ahead position, the grommet is not engaged to the dart. Make sure the grommet is fully engaged to the dart before operating.

SEAT REMOVAL / INSTALLATION (2-UP MODELS)


NOTICE

When removing the seat, use caution to avoid contact with the fuel tank.


When reinstalling the seat, use caution when you align the seat base grommets to the seat mount darts, to avoid damage to the grommets.



1. Grasp the rear of the passenger seat and pull up to disengage the rear grommet ① from the rear dart.




2. Grasp the front of the passenger seat and pull up to disengage the middle grommet ② from the middle dart.



MAINTENANCE

3. Grasp the front of the driver seat and pull up to disengage the front grommet ③ from the front dart.




4. Rotate the seat and slide the seat out of the passenger hand hold strap. The passenger hand hold strap remains attached to the vehicle.
5. To reinstall the seat, make sure the seat base engages the rear dart, then press down firmly on the front of the driver seat to engage the front dart to the grommet. Lastly, press down firmly on the front of the passenger seat to engage the middle dart to the grommet.

WARNING

If the seat is not aligned in a straight-ahead position, the grommet is not engaged to the dart. Make sure the grommet is fully engaged to the dart before operating.

HEADLIGHT CLUB FAIRING REMOVAL


1. Remove the quarter fairing rubber straps away from the vehicle fork, below the turn signal rubber sleeves.



2. Remove the two mount screws from the quarter fairing mount. Remove the quarter fairing from the vehicle.

NOTICE

Hold the quarter fairing in place while removing the mount screws to prevent damage.



MAINTENANCE

INSTALLATION


NOTICE

Make sure the lighting and hand controls are functional. Make sure the wires are returned to their original routing.

IMPORTANT


Improper routing of the wires could affect steering and/or wiring durability.

1. Make sure the quarter fairing is fit adequately around the headlight




2. Hold the quarter fairing onto the bike. Loosely install the two quarter fairing mount screws into the quarter fairing.

DO NOT torque fasteners at this time.



3. Put the quarter fairing rubber straps onto the vehicle fork, below the turn signal rubber sleeves.




MAINTENANCE

4. Torque the two quarter mount screws to specification.

TORQUE
Mount Screws: 11 ft-lbs (15 N·m)

NOTICE
Make sure the wiring is routed correctly in the turn signal rubber sleeves after installation of the quarter fairing.




HEADLIGHT NACELLE

REMOVAL

1. Remove the three screws from each side of the nacelle. Remove the nacelle from the bike.

IMPORTANT
Hold the nacelle in place while removing the screws to prevent damage.



INSTALLATION


TIP

Check the left and right markings on the inside of the mounting brackets prior to installation.

1. Loosely install the nacelle onto the bike with the six screws.
Torque the two outer screws to specification.

TORQUE


Screws:
84 in-lbs (10 N·m)



2. Torque the inner screw to specification.

TORQUE

Screw:
84 in-lbs (10 N·m)




HEADLIGHT AIM INSPECTION

Adjust headlight aim when there is a change in load (rider, cargo, accessories, etc.) and/or after suspension adjustment.


1. Verify that tire pressure is at specification.
2. Verify that rear suspension ride height (preload) is at specification.
3. Position the motorcycle on a level surface with the headlight 32 ft (10 m) from a wall.
4. With the rider, passenger, and luggage (if applicable) on board, bring the motorcycle to the fully upright position.

5. Start the engine and switch the headlight to low beam. Observe the headlight aim on the wall.
6. Make any necessary adjustments to headlight aim, per the diagram table.
7. After adjusting the vertical aim using the low beam, switch to high beam and make sure the area of highest intensity is directly in front of the motorcycle. If not, adjust to the right or left as needed.



NUMBER	DESCRIPTION
①	LED Headlights: 4 in (10 cm) to top cut-off of beam
②	Measure distance = 32.8 ft (10 m)
③	Headlight Center

HEADLIGHT AIM ADJUSTMENT



1. To adjust the headlight vertically, loosen the housing mount fastener ① and pivot the housing upward or downward. Torque the fastener to specification.

TORQUE
35 ft-lbs (47.5 N·m)

2. To adjust the headlight horizontally, loosen the headlight mounting bolt ② and pivot the headlight to the left or right. Use high-beam to center the headlight aim horizontally. Torque the fastener to specification.

TORQUE
18 ft-lbs (24.4 N·m)

HEADLIGHT LAMP REPLACEMENT

The LED headlight is not serviceable. If the headlight becomes damaged or inoperable, the entire headlight assembly must be replaced. See your authorized INDIAN MOTORCYCLE dealer.

LED TAILLIGHT/BRAKE LIGHT REPLACEMENT

The LED taillight and brake lights are not serviceable. If the taillight or a brake light becomes damaged or inoperable, the entire light assembly must be replaced. See your authorized INDIAN MOTORCYCLE dealer or other authorized dealer.

MAINTENANCE

BATTERY

The motorcycle battery is a sealed, maintenance-free battery. Do not remove the battery cap strip for any reason. Keep the battery connections clean and tight at all times.

WARNING

Battery electrolyte is poisonous. It contains sulfuric acid. Serious burns can result from contact with skin, eyes or clothing.

External: Flush with water.

Internal: Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call physician immediately.

Eyes: Flush with water for 15 minutes and get prompt medical attention.

Batteries may produce explosive gases.

- Keep sparks, flame, cigarettes, etc. away.
- Ventilate when charging or using in an enclosed space.
- Always shield eyes when working near batteries
- KEEP OUT OF REACH OF CHILDREN.

BATTERY REMOVAL / INSTALLATION


WARNING

Improperly connecting or disconnecting battery cables can result in an explosion and cause serious injury or death. When removing the battery, always disconnect the negative (black) cable first. When reinstalling the battery, always connect the negative (black) cable last.


CAUTION

To avoid damage to the battery, do not allow the battery terminals or tools to contact the metal surfaces.

1. Remove the seat. See page 169.
2. If equipped, disconnect the WCM connector ① and the LF antenna connector ②.




3. Remove the wire harness ③ from the retention feature on the cover.




MAINTENANCE

4. Remove the two cover bolts ④ and retain. **Tool:** 6mm Hex Socket



5. Disconnect the negative (-) battery terminal screw ⑤ and cable. **Tool:** Phillips Screwdriver or 10mm Hex Socket




TIP

Reinstall the screw into the battery after removal to capture the nut in the battery post.


6. Remove the positive (+) jump start terminal cap ⑥ to aid in removal of the cover.

TIP

Keep the positive (+) jump start terminal cap tethered to the cover so it does not get lost.




7. Lift the battery cover up ⑦ and towards the rear of the motorcycle to disengage the tabs in the front. Set aside to access the battery.



MAINTENANCE


8. Disconnect the positive (+) battery screw ⑧, cable, and positive (+) jump start terminal ⑨ from the battery.



9. Using the battery strap, pull the battery out of battery trays. Once the battery is about 1/2 – 3/4 way out, use your other hand to grab the top of the battery and remove it from the motorcycle.

NOTICE

The battery is heavy. Take care not to drop the battery when removing or installing it. Use the battery strap to aid in reinstalling the battery.



10. Reverse these steps to reinstall the battery.

NOTICE

The battery strap should be used to reinstall the battery. Before you install the battery, make sure the strap is retained to the left-hand battery tray and routed through the slot in the top of the right-hand battery tray.

11. Torque fasteners to specification.

IMPORTANT

Failing to torque the fasteners to specification could create loose connections that can cause electrical problems or potential damage to the battery, and could void the battery warranty.

TORQUE

Battery Terminal Fasteners:
44 in-lbs (5 N·m)

TORQUE

Cover Bolts:
35 in-lbs (4 N·m)

BATTERY CHARGING AND MAINTENANCE


IMPORTANT

Read and follow the safety precautions listed on the battery and the proper battery charging procedures outlined in the manual. It is important to keep the battery charged to prevent a potential void to the battery warranty.

If your motorcycle will not be used for a period of two weeks or longer, a maintenance charger should be connected to the battery using the Battery Charge Port.

The Battery Charge Port / Heated Gear Plug ① is located behind the ignition switch cover and a maintenance charger can be connected to it for extended periods (for example, winter storage).

MAINTENANCE



CAUTION

Before connecting a battery charger to the Battery Charge Port, make sure the vehicle has cooled to ambient temperature. Do not allow cables to rest on hot or sharp surfaces while charging.

AGM BATTERY CHARGER RECOMMENDATIONS

INDIAN MOTORCYCLE recommends using the BatteryMINDER® 2012 AGM - 2 A battery charger (PN 2830438) to charge and maintain AGM batteries. The charger can be found on the Polaris or INDIAN MOTORCYCLE websites, or purchased from your authorized INDIAN MOTORCYCLE dealer.

If you are not using the BatteryMINDER® 2012 AGM - 2 A battery charger, an automatic/constant monitoring AGM battery charger with a charging rate of 2 A or less is recommended to prevent damage to the battery.

Batteries that fall below 12.5 V run the risk of sulfation, a condition whereby sulfate crystals form inside the battery and significantly reduce performance. AGM chargers are designed specifically for charging AGM type batteries and use high frequency pulses to partially reverse sulfation.

IMPORTANT

The use of non-AGM battery chargers may result in a misleading "battery not found" or "open cell" fault message. Make sure you are using the recommended AGM charger when charging AGM type batteries to prevent damage to the battery. Using the wrong charger could damage the battery and potentially void the battery warranty.

AGM BATTERY CHARGING RECOMMENDATIONS

If the motorcycle will not be driven for more than two weeks, maintaining the battery with the BatteryMINDER® 2012 AGM - 2 A battery charger (PN 2830438) is recommended.

Always use the recommended automatic battery charger, and wait for the charger to complete the charge cycle before you disconnect it.

AGM BATTERY MAINTENANCE TIPS

To help prolong battery life, if a power source is not available to use the 12V Battery Charge Port, it is recommended to remove the battery from a vehicle that is stored two months or longer. To maximize the life of stored batteries, they should be kept in a cool / dry location. Batteries will self discharge more rapidly when stored in extreme heat. Batteries should be maintained using the recommended battery charger while in storage.

Batteries which are not connected to a vehicle should be charged every two months.

Batteries will self-discharge more quickly when dirty. Periodic cleaning of the battery terminals using a terminal brush will help maximize battery life. Wash terminals with a solution of one tablespoon baking soda and one cup water. Rinse well with tap water and dry off with clean shop towels. Coat the terminals with dielectric grease or petroleum jelly.

Battery connections should be tightened to the correct torque during installation. This will reduce voltage drop and ensure a reliable connection between the regulator / rectifier and battery.

KEY FOB BATTERY LIFE



WARNING



Keep the key fob and key fob battery out of reach of children. Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.

Key fob battery life is approximately 1-2 years depending on fob type and usage patterns. Battery changes recommended yearly. Multi-Function (Two Button) Key Fob battery life will decrease with frequent use of the LOCK / UNLOCK buttons.

Low Battery Indicators:

- Decreased fob authentication range
- Horn honks 5 seconds after startup
- Security light stays illuminated for up to 20 seconds
- Both Battery Light and Security Light are illuminated

Key Fob performance can be affected by the following conditions:

- Close proximity of ferrous materials (e.g. money clip or pocket knife)
- Key Fob stuck to saddlebag speaker magnet
- Key Fob held in ferrous container (metal cup holder or glasses case)
- Cold temperatures (Key Fob should be kept above 45°F / 7°C)

Key Fob Replacement Battery Part Number: 4014675 or CR2032

JUMP STARTING THE VEHICLE

1. Make sure both vehicles are off.
2. Remove the seat and locate the negative (-) terminal and positive (+) jump start terminal cover.
3. Attach the red jumper cable clamp to the positive (+) jump start terminal of the dead battery.

MAINTENANCE

4. Attach the other red jumper cable clamp to the positive side of the working battery.
5. Attach the other black jumper cable to the negative side of the working battery.
6. Attach the black jumper cable clamp to a ground location on the vehicle with the dead battery.
7. With all of the cables connected, start the motorcycle with the working battery. Let the motorcycle idle for one minute, and then attempt to start the motorcycle with the dead battery.
8. Disconnect the cables in the opposite order as they were installed.
9. Replace the positive (+) jump start terminal cover.

FOB BATTERY DISPOSAL

For disposal, FOB's should not be mixed with general household waste. For proper treatment, recovery and recycling, please take the FOB to designated collection points where it will be accepted free of charge. Disposal of the FOB correctly will help save valuable resources and prevent any potential negative effects on human health and the environment. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.




FUSE REPLACEMENT

NOTICE

Use fuses with the recommended amperage to avoid damage to the electrical system.

The standard fuse box is located under the seat. This fuse box houses all standard service fuses and the automatic circuit breakers. Fuse application and size are provided on a label on the fuse box cover.



1. Remove the seat. See page 169.
2. To release the locking tabs, squeeze the upper and lower cover clips ① and remove the fuse box cover.
3. After replacing a fuse, reinstall the fuse box cover and side cover.

ELECTRICAL PRECAUTIONS

Be aware of the following precautions regarding the electrical system to avoid disruption of electrical signals and possible system malfunction.

- DO use **ONLY** genuine INDIAN MOTORCYCLE parts and accessories designed for your model, and follow the instructions provided.
- DO use the accessory power jack provided (if equipped).
- If it is necessary to provide power to an item that does not use one of the previously mentioned power jacks, connect to the “hot” side of the starter solenoid with an inline fuse, and connect the ground wire to the chassis ground located at the left rear section of the frame under the seat.
- DO NOT splice or cut any wires.
- DO NOT tap in to any power or ground on the motorcycle unless specifically directed to do so by the INDIAN MOTORCYCLE instructions that come with the kit.
- DO NOT back-probe electrical connectors on the vehicle unless directed to do so by the *INDIAN MOTORCYCLE Service Manual*.
- DO NOT power any accessories from the diagnostic connector.

UNLOCKING THE SECURITY SYSTEM (ANALOG GAUGE EQUIPPED MODELS)

Your dealer will provide the master personal identification number (PIN) for the security system. Your dealer may also change the master PIN to a new rider PIN on your behalf.

Record both PINs on page 7.

Change the dealer-provided PIN to a PIN of your own choosing as soon as possible after receiving delivery of your new motorcycle. See page 191.

If a key fob is not available, your rider PIN can be entered using the turn signal switches to unlock the security system. Use the following guide to enter your valid rider PIN.

DIGIT TO ENTER	TURN SIGNAL FEATURE USED	PROCEDURE
The number "0"	CANCEL switch	Press and release
First digit (1-9)	LEFT turn switch	Move and release once per digit value. See example below.
Second digit (1-9)	RIGHT turn switch	
Third digit (1-9)	LEFT turn switch	
Fourth digit (1-9)	RIGHT turn switch	
Example for entering the number 1024: LEFT - CANCEL - LEFT - LEFT - RIGHT - RIGHT - RIGHT - RIGHT		

UNLOCKING THE SECURITY SYSTEM (RIDE COMMAND EQUIPPED MODELS)

Your dealer will provide the master personal identification number (PIN) for the security system. Your dealer may also change the master PIN to a new rider PIN on your behalf.

Record both PINs on page 7.

Change the dealer-provided PIN to a PIN of your own choosing as soon as possible after receiving delivery of your new motorcycle. See page 191.

If a key fob is not available, your rider PIN can be entered using the digital display to unlock the security system.



CHANGING YOUR SECURITY SYSTEM PIN (ANALOG GAUGE EQUIPPED MODELS)

To change your PIN, you must have either the key fob or your existing valid PIN available to gain access to the security system. If the key fob is not detected or is not available and you cannot remember your PIN, please see your INDIAN MOTORCYCLE dealer.

Please read the entire procedure before beginning.

1. Power on the motorcycle by pushing the power switch. Do NOT start the engine. The security light and/or power switch will turn on briefly until the key fob is detected or until the valid, current PIN is entered.
2. Push or hold the turn signal CANCEL switch for 10 seconds until the security light and/or power switch turn on.
3. Enter either the master PIN (see page 7) or your current 4-digit rider PIN within 20 seconds. If the PIN is successfully entered, the security light and/or power switch will remain on and the horn will sound briefly.

NOTICE

If the valid PIN is not entered within 20 seconds, the security light and/or power switch will flash for 10 seconds, then the system will shut down. Return to step 1 to try again.

4. Enter a new 4-digit security PIN of your own choosing. If the PIN is successfully entered, the security light will remain on and the horn will sound briefly. Proceed to step 5.

NOTICE

If the 4-digit PIN is NOT successfully entered within 20 seconds, the security light will flash for 10 seconds, then the system exits the procedure. Return to step 1 to try again.

5. Re-enter the new 4-digit PIN. If this entry matches the first entry, the security light will turn off and the horn will sound briefly. The new rider PIN has been saved. *Record your new rider PIN on page 7.*

NOTICE

If the second entry is not entered within 20 seconds or does not match the first entry, the security light will flash for 10 seconds, then the system exits the procedure. The new PIN was NOT saved. Continue to use your former valid PIN. Return to step 1 to try again.

CHANGING YOUR SECURITY SYSTEM PIN (RIDE COMMAND EQUIPPED MODELS)

To change your PIN, you must have either the key fob or your existing valid PIN available to gain access to the security system. If the key fob is not detected or is not available and you cannot remember your PIN, please see your INDIAN MOTORCYCLE dealer.

MAINTENANCE

Please read the entire procedure before beginning.

1. Tap “Change Passcode” on the display screen.
2. Enter an existing or master PIN by pressing the corresponding numbers on the display screen.
3. When prompted, enter a new PIN into the display screen. When complete, press the arrow button.
4. When prompted, enter the new PIN into the display screen to confirm the PIN.
5. If the PIN has been accepted, the display screen will display a confirmation.

EXHAUST SYSTEM INSPECTION

Check the exhaust system for stains from leaking exhaust gasses. Replace damaged or leaking exhaust gaskets. Check all exhaust system fasteners. Tighten loose clamps and fasteners. Do not overtighten. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

ELEVATING THE MOTORCYCLE



Serious injury or death can occur if the motorcycle tips or falls. Make sure the motorcycle will not tip or fall while elevated or while on the sidestand.

Some procedures require raising the motorcycle to remove weight from the component being inspected. Elevate the motorcycle by placing a stable, flat platform jack or lift mechanism on a firm, flat surface and lifting under the engine crankcase. The platform should be a minimum of 12 in (30 cm) square. DO NOT attempt to lift the motorcycle without proper equipment. Always secure the motorcycle properly before lifting so it cannot tip or fall when elevated.

ROAD TEST

Before returning the motorcycle to regular use, perform a road test in a safe area. Pay special attention to the proper fit and operation of all serviced components.

Make any corrections or additional adjustments promptly to ensure safe, reliable and enjoyable vehicle performance.

FASTENER INSPECTION

1. Inspect the entire motorcycle chassis and engine for loose, damaged or missing fasteners. Tighten loose fasteners to the proper torque. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.
2. Always replace stripped, damaged or broken fasteners before riding. Use genuine INDIAN MOTORCYCLE fasteners of equal size and strength.

FASTENER TORQUES

Some procedures and fastener torques are not listed in this manual. See the *INDIAN MOTORCYCLE Service Manual* or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.

TROUBLESHOOTING

For your personal safety, do not attempt inspection or repairs not fully described in this rider's manual. Contact an authorized dealer for service if you cannot determine the cause of a problem or if the inspection/repair exceeds your mechanical ability or tool resources. Do not perform any inspection or repair with the engine running.

ENGINE CRANKS BUT WILL NOT START

POSSIBLE CAUSE	POSSIBLE REMEDY/ACTION
Low fuel	Verify the fuel level.
Fuel pump does not operate	Turn the engine STOP switch to RUN. Turn the ignition key to the ON position or power on the motorcycle by pushing the power switch. The fuel pump should run momentarily and then stop. Check the fuel pump/ignition circuit breaker.
Battery voltage is too low	Fully charge the battery. See page 185 for details.
Fouled spark plug(s)	Please see your dealer.

STARTER MOTOR CLICKS, DOES NOT TURN OR TURNS SLOWLY

POSSIBLE CAUSE	POSSIBLE REMEDY/ACTION
Engine stop / run / start switch is in the STOP position	Place the switch in the RUN position.
Discharged battery	Fully charge the battery. See page 185 for details.
Loose or corroded battery cables	Inspect the battery cables.
Transmission is in gear	Shift the transmission into neutral or with the sidestand retracted, pull the clutch lever in to disengage the clutch.

MAINTENANCE

ENGINE STARTS BUT MISSES OR RUNS POORLY

NOTICE

Turn the engine OFF before you inspect any of the following items.

POSSIBLE CAUSE	POSSIBLE REMEDY/ACTION
Discharged battery	Fully charge the battery. See page 185 for details.
Loose or corroded battery cables	Inspect the battery cables and connections.
Fouled spark plug(s)	Please see your dealer.
Contaminated fuel	Inspect the fuel for water/contamination. Please see your dealer.
Engine oil level incorrect or wrong oil type	Inspect the level and quality of oil.
Loose, broken, shorted ignition coil wires	Inspect the coil primary wires. Please see your dealer.
Air intake restricted	Inspect the air filter. See the Air Filter section for details.
Intake leaks	Inspect the air box, crankcase breather hoses, throttle body, and intake boot joints.

SHIFTING DIFFICULTIES OR HARD TO FIND NEUTRAL

POSSIBLE CAUSE	POSSIBLE REMEDY/ACTION
Clutch damage	Replace the clutch.
Clutch cable not adjusted properly	See page 155.
Shift linkage not adjusted properly	See page 89.
Incorrect oil or oil in poor condition	Replace the oil with the recommended oil.

ENGINE OVERHEATING

POSSIBLE CAUSE	POSSIBLE REMEDY/ACTION
Debris lodged in radiator guard	Inspect and clean the guard.
Debris lodged in radiator fins	Use a garden hose to flush any debris from the radiator fins. DO NOT use a high pressure washer, which can damage the radiator fins.
Blocked fan	Inspect the fan, remove any blockage.
Fan does not operate	Please see your dealer.
Low coolant	Allow the engine to cool before checking coolant level. See page 131.
Air in cooling system	Please see your dealer.

BATTERY CHARGING RATE LOW OR BATTERY DISCHARGES

POSSIBLE CAUSE	POSSIBLE REMEDY/ACTION
Loose/corroded charging circuit connection	Check/clean the battery cable connections. Check/clean the charging circuit connections. Please see your dealer.
Accessory load exceeds charge rate	Limit the accessory operation when the engine is off.
Improperly wired accessory (current draw)	Please see your dealer to check charging system output and current draw.

BRAKE NOISE / POOR BRAKE PERFORMANCE

NOTICE

See your dealer if brake performance does not return after these inspections.

POSSIBLE CAUSE	POSSIBLE REMEDY/ACTION
Dust/dirt on brake disc(s)	Clean the disc. See page 162.
Worn pads or disc/brake disc damage	Inspect the pads and discs. See page 162.
Brake fluid level low or fluid contaminated	Inspect the fluid level/fluid condition. See page 158 and page 160.

ANTI-LOCK BRAKE LIGHT REMAINS ILLUMINATED OR ILLUMINATES INTERMITTENTLY

POSSIBLE CAUSE	POSSIBLE REMEDY/ACTION
Blown fuse	Check the fuses. See page 188.
Loose or damaged tone ring	Inspect the tone ring for looseness or chipped teeth.
Debris lodged in components	Inspect the wheel speed sensor and tone ring for debris.
Damage caused by debris	Inspect the wheel speed sensor for cracked housing.
Damaged components	See the <i>INDIAN MOTORCYCLE Service Manual</i> or an authorized INDIAN MOTORCYCLE dealer or other qualified dealer.
Improper wheel speed sensor gap	See page 163. Please see your dealer for adjustment.

CLEANING AND STORAGE

CLEANING PRODUCTS

This section provides tips on the very best way to clean, polish and preserve every surface of your beautiful new INDIAN MOTORCYCLE. We recommend the use of our new INDIAN MOTORCYCLE cleaning and polishing products and accessories, which have been specially designed to offer the best care possible for your INDIAN MOTORCYCLE.

In addition to the products recommended in this section for cleaning and polishing, INDIAN MOTORCYCLE also has specialty products for:

- enhancing black and silver engines
- cleaning engines, tires and wheels
- removing brake dust

After cleaning the motorcycle, inspect for damage to the painted surfaces. Chips or scratches should be repaired promptly to prevent corrosion.

For Matte Clear Coat Finish Care, see page 198.

For Gloss Clear Coat Finish Care, see page 198.

For more information, or for answers to your cleaning and detailing questions, please see your INDIAN MOTORCYCLE dealer.

WASHING THE MOTORCYCLE

IMPORTANT

Do not use pressurized water to wash the motorcycle. Water may seep in and deteriorate wheel bearings, brake caliper assemblies, brake master cylinders, electrical connectors, steering head bearings, suspension pivots, forks, shocks, and transmission seals. Do not direct any water stream at air intakes, exhaust outlets, electrical connectors or audio system speakers. Electrical components may be damaged by water. Do not allow water to contact electrical components or connectors.

- Before washing your Indian Motorcycle, make sure the exhaust pipes are cool. Cover each pipe opening with a plastic bag secured with a strong rubber band. Check that the spark plugs, spark plug wire caps, oil fill cap and fuel caps are properly seated.
- Do not use abrasive cleaners.
- Rinse off as much dirt and mud as possible with water running at low pressure. Use as little water as possible when washing near the air intake or the exhaust pipe openings. Dry these components thoroughly before operating your motorcycle.
- Clean the front fork tubes thoroughly to reduce fork seal wear and leakage.
- After washing, remove the rubber bands and plastic bags from the exhaust pipes. Start the engine and let it idle for a few minutes.
- Make sure the brakes are functioning properly before riding.

CLEANING AND STORAGE

WINDSHIELD CARE (IF EQUIPPED)

Clean the windshield with a soft cloth and plenty of warm water. Dry with a soft clean cloth. Remove minor scratches with a high-quality polishing compound designed for use on polycarbonate surfaces.

IMPORTANT

Brake fluid and alcohol will permanently damage the windshield and some types of thread-locking agents. Do not use glass cleaners, water or soil repellents, and petroleum or alcohol based cleaners on the windshield, as these products can damage the windshield.

MATTE CLEAR COAT FINISH CARE

Matte finish products are prone to trapping dirt, oils and other contaminants. Always clean this type of finish with warm water and a mild dish-washing detergent. Use a soft sponge to gently rub the surface, then rinse with clean warm water. For stubborn stains such as grease or oil, use a citrus-based cleaner. Spray the cleaner onto the area and rub gently with a soft sponge. Allow the cleaner to sit for a couple of minutes, then rinse well with clean warm water. Repeat as needed.

IMPORTANT

Never use a polishing/buffing wax or any sponge that has an abrasive surface when cleaning a matte finish. These products will buff the matte surface of the finish and result in a glossy finish. Never clean matte finishes with a pressure washer, as this will further imbed contaminants into the clear coat and may damage labels and decals.

GLOSS CLEAR COAT FINISH CARE

The clear coat finish system used on all Indian Motorcycle models provides superior protection against the elements. To maximize the benefits of this system, use the following guide to care for the gloss finish on your motorcycle.

- During the first 30 days, when the finish is still fresh, clean the motorcycle with a water rinse only.
- Do not wax the motorcycle for the first 60 days. Doing so can cause loss of the gloss. After 60 days, use only waxes designed for new clear coat finishes.
- Do not use pressurized water to wash the motorcycle. When paint is still fresh, pressurized water could damage the finish. If using a pressure washer is unavoidable, keep the spray nozzle at least 24 in (60 cm) away from the surface of the motorcycle.
- Wash your motorcycle often, especially when exposed to salty, dusty, acidic or alkaline environments.
- Use warm or cool water and a soft cloth for cleaning.
- Use soaps that are non-abrasive and have a neutral pH (non acidic/non alkaline detergents).
- Do not use solvent-based solutions.

- Do not use a dry cloth to remove dust.
- Do not use a stiff bristle brush, which can scratch the surface.
- Do not wash with extremely hot water.
- Do not wash the motorcycle while the surface is hot and avoid washing the motorcycle in the hot sun. Minerals in the water may be difficult to remove once dried on the surface of the motorcycle.
- Do not allow spilled gasoline, motor oil or brake fluid to stand on the paint. Remove these substances immediately by rinsing with water. Use a soft cloth to absorb any remaining residue and dab dry.
- To remove bug remnants or road tar, use only products that are specifically designed for this purpose. Follow the product manufacturer's recommendations to prevent potential damage to the finish. Follow with a wash using the methods described in this section.
- Always brush away any ice or snow, do not scrape off.
- Chips or scratches should be repaired promptly to prevent corrosion.

STORAGE AREA PREPARATION

Choose a dry, well-ventilated storage location, inside a garage or other structure if possible. The location should have a firm, flat surface and allow enough space for the motorcycle.

WARNING

Gasoline is highly flammable and explosive under certain conditions. Do not store the motorcycle in any area (in home or garage) where it could be near open flames, pilot lights, sparks or electric motors. Do not smoke in the storage area.

To best preserve tire condition:

- The storage area should have a relatively constant and moderate temperature.
- The storage surface should be free of oil and gasoline.
- The motorcycle should not be near a radiator or other heat source, or any type of electric motor.

FUEL STABILIZER

Store the bike with a full tank of non-oxygenated fuel. If non-oxygenated is unavailable, a commercial oxygenated fuel is acceptable. Note that most oxygenated fuels contain ethanol. Since ethanol is hygroscopic, oxygenated fuel will absorb water vapor during storage. Completely filling the fuel tank minimizes the exposure and absorption of water vapor during seasonal storage. Treat the fuel with a fuel stabilizer, Polaris Advanced Fuel Treatment additive 2881416 or equivalent.

TIRE INFLATION

Inflate the tires to normal pressure. See page 84 and page 168 for details.

CLEANING AND STORAGE

ENGINE PROTECTION

Change the engine oil. See page 128 for details.

COOLING SYSTEM

Check the coolant level and maintain as recommended by adding coolant to the recovery bottle. See page 131 for details.

BATTERY CARE

1. Remove the battery. See page 180 for details.
2. Clean the battery terminals first with a wire brush to remove any loose deposits.
3. Wash the posts and the ends of the battery cables with a solution of one part baking soda to 16 parts water. Rinse with clean water and wipe dry.
4. Apply a thin film of dielectric grease to the posts and cable connectors.
5. Clean the outside of the battery with a solution of mild detergent and warm water.
6. Store the battery in a dry area with a temperature of 32–90 °F (0–32 °C).
7. While in storage, fully charge the battery once a month. See page 185 for details.

MAINTENANCE DURING STORAGE

During extended storage periods, maintain tire pressure and battery voltage at the recommended levels.

RODENTS

Mice and other rodents are often the worst enemy of a stored motorcycle. If the motorcycle will be stored in an area where mice are a concern (particularly in rural areas, barns, sheds, etc.) be sure to take extra measures to deter their infestation. This may include placing a screen mesh over any intake or exhaust openings (just be sure to remember to remove them when you take the motorcycle from storage).

PARK AND COVER THE MOTORCYCLE

1. Park the motorcycle in its storage location. Block the frame to take some of the weight off the front and rear wheels.

NOTICE

Starting the motorcycle periodically during storage is NOT recommended. Water vapor is a by-product of the combustion process, and corrosion may result unless the engine is operated long enough to bring the oil and exhaust system to normal operating temperature.

2. Secure a plastic bag over the (cooled) exhaust outlets to prevent moisture from entering the exhaust system.
3. Cover the motorcycle with a cover made from a durable, breathable material designed for storage. Covering the motorcycle helps protect it from dust and other airborne materials. The cover must be of a breathable material to prevent moisture from building up on the motorcycle which can cause oxidation of metal surfaces.

REMOVAL FROM STORAGE

1. Install a fully charged battery.
2. Check the oil level. If the motorcycle was stored in an area subject to wide swings in temperature and humidity (such as outdoors), change the engine oil before starting the engine.

IMPORTANT
During storage, temperature and humidity changes can cause condensation to form in the crankcase and mix with engine oil. Running the engine with oil that contains condensation can cause engine damage.

- | |
|---|
| During storage, temperature and humidity changes can cause condensation to form in the crankcase and mix with engine oil. Running the engine with oil that contains condensation can cause engine damage. |
|---|
3. Inspect the storage area for signs of fluid leaks. Identify and perform service to any leaking components.
 4. Remove any intake or exhaust mesh covers installed for rodent protection.
 5. Make sure the fuel tank is at least 3/4 full.
 6. Perform the pre-ride inspections. See page 81.
 7. Perform a road test. See page 108.
 8. Wash and polish the motorcycle. Wax, polish, or apply protectant to the appropriate components.

SPECIFICATIONS

SCOUT CLASSIC

WEIGHT

Dry Weight (without fuel / fluids)	536 lb (243 kg)
Wet Weight (with fuel / fluids)	555 lb (252 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	433 lb (197 kg)

CAPACITIES

Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (per side) (conventional)	10.7 oz 315 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)

Overall Length	91.3 in (2318 mm)
Overall Width	Including Mirrors: 36.1 in (916 mm) Excluding Mirrors: 35.8 in (910 mm)
Overall Height	Excluding Mirrors: 43.1 in (1096 mm)
Seat Height	Un-Laden: 26.8 in (680 mm) Laden: 25.7 in (654 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.4 in (113 mm)
Rake (frame) / Trail	29° / 4.8 in (122 mm)

ENGINE

Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	76 cid (1250 cc)
Compression Ratio	12.5:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	4.094" x 2.898" (104 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 60 mm
Exhaust System	2 into 1

SPECIFICATIONS

ENGINE	
Rev Limit	8500 RPM
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Slip-Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	6 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	1.125:1
6th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 5 Up
Final Drive Type	Belt Drive, 146-Tooth

DRIVE SYSTEM	
Drive Sprocket	29-Tooth
Driven Sprocket	66-Tooth
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	4.286:1
6th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	41 mm
Rear Suspension Type / Travel	Dual Shocks / 3 in (76 mm)
Swingarm	Steel
Front Brakes	Single / 298 mm Rotor / 2 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps), Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	

WHEELS AND TIRES	
Front Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Wire 40-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Wire 40-Spoke

WHEELS AND TIRES	
Front Tire Type / Size	Pirelli® Night Dragon® 130 / 90B16 67H Alternative: Kenda® K673 130 / 90B16 73H
Rear Tire Type / Size	Pirelli® Night Dragon® 150 / 80B16 77H Alternative: Kenda® K673 150 / 80B16 71H

SPECIFICATIONS

SCOUT BOBBER

WEIGHT	
Dry Weight (without fuel / fluids)	522 lb (237 kg)
Wet Weight (with fuel / fluids)	542 lb (246 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	446 lb (203 kg)

CAPACITIES	
Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (per side) (conventional)	10.7 oz 315 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)	
Overall Length	86.9 in (2206 mm) With Center License Plate: 89.0 in (2260 mm)
Overall Width	Including Mirrors: 36.6 in (930 mm) Excluding Mirrors: 33.7 in (855 mm)
Overall Height	Excluding Mirrors: 42.2 in (1071 mm)
Seat Height	Un-Laden: 26.2 in (665 mm) Laden: 25.6 in (649 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.3 in (109 mm)
Rake (frame) / Trail	29° / 4.9 in (124 mm)

ENGINE	
Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	76 cid (1250 cc)
Compression Ratio	12.5:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	4.094" x 2.898" (104 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 60 mm
Exhaust System	2 into 1

ENGINE	
Rev Limit	8500 RPM
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	6 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	1.125:1
6th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 5 Up
Final Drive Type	Belt Drive, 146-Tooth

DRIVE SYSTEM	
Drive Sprocket	29-Tooth
Driven Sprocket	66-Tooth
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	4.286:1
6th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	41 mm
Rear Suspension Type / Travel	Dual Shocks / 2 in (51 mm)
Swingarm	Steel
Front Brakes	Single / 298 mm Rotor / 2 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

SPECIFICATIONS

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps), Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	
WHEELS AND TIRES	
Front Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Front Tire Type / Size	Pirelli® MT60RS 130 / 90B16 67H Alternative: Kenda® K673 130 / 90B16 73H
Rear Tire Type / Size	Pirelli® MT60RS 150 / 80B16 77H Alternative: Kenda® K673 150 / 80B16 71H

SUPER SCOUT

WEIGHT	
Dry Weight (without fuel / fluids)	571 lb (259 kg)
Wet Weight (with fuel / fluids)	589 lb (268 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	399 lb (181 kg)

CAPACITIES	
Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (per side) (conventional)	10.7 oz 315 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)	
Overall Length	89.0 in (2260 mm)
Overall Width	Including Mirrors: 36.1 in (916 mm) Excluding Mirrors: 35.8 in (910 mm)
Overall Height	Excluding Mirrors: 43.1 in (1096 mm)
Seat Height	Un-Laden: 26.8 in (680 mm) Laden: 25.7 in (654 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.4 in (113 mm)
Rake (frame) / Trail	29° / 4.8 in (122 mm)

ENGINE	
Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	76 cid (1250 cc)
Compression Ratio	12.5:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	4.094" x 2.898" (104 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 60 mm
Exhaust System	2 into 1
Rev Limit	8500 RPM

SPECIFICATIONS

ENGINE	
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	6 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	1.125:1
6th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 5 Up
Final Drive Type	Belt Drive, 146-Tooth
Drive Sprocket	29-Tooth

DRIVE SYSTEM	
Driven Sprocket	66-Tooth
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	4.286:1
6th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	41 mm
Rear Suspension Type / Travel	Dual Shocks / 3 in (76 mm)
Swingarm	Steel
Front Brakes	Single / 298 mm Rotor / 2 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps), Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	
WHEELS AND TIRES	
Front Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Wire 40-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Wire 40-Spoke
Front Tire Type / Size	Pirelli® MT60RS 130 / 90B16 67H Alternative: Kenda® K673 130 / 90B16 73H
Rear Tire Type / Size	Pirelli® MT60RS 150 / 80B16 77H Alternative: Kenda® K673 150 / 80B16 71H

SPECIFICATIONS

SPORT SCOUT

WEIGHT	
Dry Weight (without fuel / fluids)	527 lb (239 kg)
Wet Weight (with fuel / fluids)	547 lb (248 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	441 lb (201 kg)

CAPACITIES	
Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (per side) (conventional)	10.7 oz 315 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)	
Overall Length	86.9 in (2206 mm) With Center License Plate: 89.0 in (2260 mm)
Overall Width	Including Mirrors: 37.6 in (956 mm) Excluding Mirrors: 33.7 in (855 mm)
Overall Height	Excluding Mirrors: 45.5 in (1155 mm)
Seat Height	Un-Laden: 26.8 in (680 mm) Laden: 25.7 in (654 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.4 in (113 mm)
Rake (frame) / Trail	29° / 4.8 in (122 mm)

ENGINE	
Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	76 cid (1250 cc)
Compression Ratio	12.5:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	4.094" x 2.898" (104 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 60 mm
Exhaust System	2 into 1

ENGINE	
Rev Limit	8500 RPM
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	6 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	1.125:1
6th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 5 Up
Final Drive Type	Belt Drive, 146-Tooth

DRIVE SYSTEM	
Drive Sprocket	29-Tooth
Driven Sprocket	66-Tooth
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	4.286:1
6th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	41 mm
Rear Suspension Type / Travel	Dual Shocks / 3 in (76 mm)
Swingarm	Steel
Front Brakes	Single / 298 mm Rotor / 2 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

SPECIFICATIONS

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps), Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	
WHEELS AND TIRES	
Front Wheel Size / Type	19 in (482.6 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Front Tire Type / Size	Metzeler Cruisetec® 130 / 60B19 61H
Rear Tire Type / Size	Metzeler Cruisetec® 150 / 80B16 77H

SPORT SCOUT RT

WEIGHT	
Dry Weight (without fuel / fluids)	549 lb (249 kg)
Wet Weight (with fuel / fluids)	568 lb (258 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	420 lb (192 kg)

CAPACITIES	
Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (per side) (conventional)	10.7 oz 315 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)	
Overall Length	86.9 in (2206 mm) With Center License Plate: 89.0 in (2260 mm)
Overall Width	Including Mirrors: 37.6 in (956 mm) Excluding Mirrors: 33.7 in (855 mm)
Overall Height	Excluding Mirrors: 45.5 in (1155 mm)
Seat Height	Un-Laden: 26.8 in (680 mm) Laden: 25.7 in (654 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.4 in (113 mm)
Rake (frame) / Trail	29° / 4.8 in (122 mm)

ENGINE	
Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	76 cid (1250 cc)
Compression Ratio	12.5:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	4.094" x 2.898" (104 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 60 mm
Exhaust System	2 into 1

SPECIFICATIONS

ENGINE	
Rev Limit	8500 RPM
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	6 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	1.125:1
6th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 5 Up
Final Drive Type	Belt Drive, 146-Tooth

DRIVE SYSTEM	
Drive Sprocket	29-Tooth
Driven Sprocket	66-Tooth
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	4.286:1
6th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	41 mm
Rear Suspension Type / Travel	Dual Shocks / 3 in (76 mm)
Swingarm	Steel
Front Brakes	Single / 298 mm Rotor / 2 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps), Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	

WHEELS AND TIRES	
Front Wheel Size / Type	19 in (482.6 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Front Tire Type / Size	Metzeler Cruisetec® 130 / 60B19 61H
Rear Tire Type / Size	Metzeler Cruisetec® 150 / 80B16 77H

SPECIFICATIONS

101 SCOUT

WEIGHT	
Dry Weight (without fuel / fluids)	529 lb (240 kg)
Wet Weight (with fuel / fluids)	549 lb (249 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	439 lb (200 kg)

CAPACITIES	
Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (inverted)	Left Hand Fork: 13.9 oz 412 cm ³ Right Hand Fork: 11.5 oz 340 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)	
Overall Length	86.9 in (2206 mm) With Center License Plate: 89.0 in (2260 mm)
Overall Width	Including Mirrors: 37.6 in (956 mm) Excluding Mirrors: 33.7 in (855 mm)
Overall Height	Excluding Mirrors: 45.5 in (1155 mm)
Seat Height	Un-Laden: 26.8 in (680 mm) Laden: 25.7 in (654 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.4 in (113 mm)
Rake (frame) / Trail	29° / 4.8 in (122 mm)

ENGINE	
Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	76 cid (1250 cc)
Compression Ratio	12.5:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	4.094" x 2.898" (104 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 60 mm
Exhaust System	2 into 1

SPECIFICATIONS

ENGINE	
Rev Limit	8500 RPM
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	6 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	1.125:1
6th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 5 Up
Final Drive Type	Belt Drive, 146-Tooth

DRIVE SYSTEM	
Drive Sprocket	29-Tooth
Driven Sprocket	66-Tooth
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	4.286:1
6th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	43 mm
Rear Suspension Type / Travel	Dual Piggyback Shocks / 3 in (76 mm)
Swingarm	Steel
Front Brakes	Dual / 320 mm Rotor / 4 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

SPECIFICATIONS

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps), Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	
WHEELS AND TIRES	
Front Wheel Size / Type	19 in (482.6 mm) x 3.5 in (88.9 mm) Cast 5-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Cast 5-Spoke
Front Tire Type / Size	Metzeler Cruisetec® 130 / 60B19 61H
Rear Tire Type / Size	Metzeler Cruisetec® 150 / 80B16 77H

SCOUT SIXTY CLASSIC

WEIGHT	
Dry Weight (without fuel / fluids)	531 lb (241 kg)
Wet Weight (with fuel / fluids)	551 lb (250 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	457 lb (208 kg)

CAPACITIES	
Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (per side) (conventional)	10.7 oz 315 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)	
Overall Length	91.3 in (2318 mm)
Overall Width	Including Mirrors: 36.1 in (916 mm) Excluding Mirrors: 35.8 in (910 mm)
Overall Height	Excluding Mirrors: 43.1 in (1096 mm)
Seat Height	Un-Laden: 26.8 in (680 mm) Laden: 25.7 in (654 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.4 in (113 mm)
Rake (frame) / Trail	29° / 4.8 in (122 mm)

ENGINE	
Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	61 cid (1000 cc)
Compression Ratio	11.0:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	3.661" x 2.898" (93 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 54 mm
Exhaust System	2 into 1
Rev Limit	8500 RPM

SPECIFICATIONS

ENGINE	
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	5 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 4 Up
Final Drive Type	Belt Drive, 146-Tooth
Drive Sprocket	29-Tooth
Driven Sprocket	66-Tooth

DRIVE SYSTEM	
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	41 mm
Rear Suspension Type / Travel	Dual Shocks / 3 in (76 mm)
Swingarm	Steel
Front Brakes	Single / 298 mm Rotor / 2 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps),

ELECTRICAL	
	Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	

WHEELS AND TIRES	
Front Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Wire 40-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Wire 40-Spoke
Front Tire Type / Size	Pirelli® Night Dragon® 130 / 90B16 67H Alternative: Kenda® K673 130 / 90B16 73H
Rear Tire Type / Size	Pirelli® Night Dragon® 150 / 80B16 77H Alternative: Kenda® K673 150 / 80B16 71H

SPECIFICATIONS

SCOUT SIXTY BOBBER

WEIGHT	
Dry Weight (without fuel / fluids)	Standard Trim: 516 lb (234 kg) Limited Trim: 522 lb (237 kg)
Wet Weight (with fuel / fluids)	Standard Trim: 536 lb (243 kg) Limited Trim: 543 lb (246 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	Standard Trim: 452 lb (206 kg) Limited Trim: 448 lb (204 kg)

CAPACITIES	
Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (per side) (conventional)	10.7 oz 315 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)	
Overall Length	86.9 in (2206 mm) With Center License Plate: 89.0 in (2260 mm)
Overall Width	Including Mirrors: 33.9 in (861 mm) Excluding Mirrors: 33.7 in (855 mm)
Overall Height	Excluding Mirrors: 42.2 in (1071 mm)
Seat Height	Un-Laden: 26.2 in (665 mm) Laden: 25.6 in (649 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.3 in (109 mm)
Rake (frame) / Trail	29.4° / 4.9 in (124 mm)

ENGINE	
Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	61 cid (1000 cc)
Compression Ratio	11.0:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	3.661" x 2.898" (93 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 54 mm
Exhaust System	2 into 1

ENGINE	
Rev Limit	8500 RPM
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	5 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 4 Up
Final Drive Type	Belt Drive, 146-Tooth
Drive Sprocket	29-Tooth

DRIVE SYSTEM	
Driven Sprocket	66-Tooth
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	41 mm
Rear Suspension Type / Travel	Dual Shocks / 2 in (51 mm)
Swingarm	Steel
Front Brakes	Single / 298 mm Rotor / 2 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

SPECIFICATIONS

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps), Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	

WHEELS AND TIRES	
Front Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Wire 40-Spoke Alternative: 16 in (406.4 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Wire 40-Spoke Alternative: 16 in (406.4 mm) x 3.5 in (88.9 mm) Cast 8-Spoke

WHEELS AND TIRES	
Front Tire Type / Size	Pirelli® Night Dragon® 130 / 90B16 67H Alternative: Kenda® K673 130 / 90B16 73H
Rear Tire Type / Size	Pirelli® Night Dragon® 150 / 80B16 77H Alternative: Kenda® K673 150 / 80B16 71H

SPORT SCOUT SIXTY

WEIGHT	
Dry Weight (without fuel / fluids)	529 lb (240 kg)
Wet Weight (with fuel / fluids)	549 lb (249 kg)
Gross Vehicle Weight Rating (GVWR)	988 lb (449 kg)
Gross Axle Weight Rating (GAWR)	Front: 371 lb (168 kg) Rear: 675 lb (306 kg)
Maximum Load Capacity (riders, cargo, accessories)	457 lb (208 kg)

CAPACITIES	
Engine Oil	With Oil Filter Change: 4.5 qt (4.26 L) With New / Rebuilt Engine: 5.25 qt (4.97 L) Recommended: SAE 15W60
Fuel	3.4 gal (13.0 L) Recommended: 91 Octane or 95 RON minimum
Fuel Reserve (fuel light on)	0.5 gal (1.9 L)
Fork Oil (per side) (conventional)	10.7 oz 315 cm ³
Radiator Coolant	0.5 gal (1.9 L)

DIMENSIONS (DIMENSIONS AND SPECIFICATIONS MAY VARY WITH FEATURES, OPTIONS AND ACCESSORIES)	
Overall Length	86.9 in (2206 mm) With Center License Plate: 89.0 in (2260 mm)
Overall Width	Including Mirrors: 33.6 in (854 mm) Excluding Mirrors: 33.4 in (848 mm)
Overall Height	Excluding Mirrors: 46.5 in (1181 mm)
Seat Height	Un-Laden: 26.8 in (680 mm) Laden: 25.7 in (654 mm)
Wheelbase	61.5 in (1562 mm)
Ground Clearance	4.4 in (113 mm)
Rake (frame) / Trail	29° / 4.8 in (122 mm)

ENGINE	
Engine Type	Liquid Cooled V-Twin (60 Degrees)
Displacement	61 cid (1000 cc)
Compression Ratio	11.0:1
Valve Train	DOHC, 4 Valves Per Cylinder, Graded Buckets
Bore and Stroke	3.661" x 2.898" (93 mm x 73.6 mm)
Fuel System / Throttle Body Bore	Closed Loop Fuel Injection / 54 mm
Exhaust System	2 into 1

SPECIFICATIONS

ENGINE	
Rev Limit	8500 RPM
Idle RPM	1250 RPM +/- 50 RPM Fully Warm
Lubrication System	Dry Sump
Spark Plug / Gap	NGK® LZMAR8CI-10 / 0.039 in (1.0 mm)

DRIVE SYSTEM	
Primary Drive	Gear Drive Wet Clutch
Crank Gear	46 Teeth
Clutch Gear	77 Teeth
Clutch Type	Assist, Wet, Multi-Plate
Primary Reduction Ratio	1:674:1
Transmission Type	5 Speed / Constant Mesh / Foot Shift
1st Gear Ratio	2.769:1
2nd Gear Ratio	1.882:1
3rd Gear Ratio	1.500:1
4th Gear Ratio	1.273:1
5th Gear Ratio	0.966:1
Gear Shift Pattern	1 Down / 4 Up
Final Drive Type	Belt Drive, 146-Tooth
Drive Sprocket	29-Tooth

DRIVE SYSTEM	
Driven Sprocket	66-Tooth
Final Drive Ratio	2.276:1
Overall Gear Ratio	
1st Gear	10.550:1
2nd Gear	7.171:1
3rd Gear	5.714:1
4th Gear	4.849:1
5th Gear	3.678:1

CHASSIS	
Front Suspension Type / Travel	Telescopic Fork / 4.7 in (120 mm)
Front Fork Tube Diameter	41 mm
Rear Suspension Type / Travel	Dual Shocks / 3 in (76 mm)
Swingarm	Steel
Front Brakes	Single / 298 mm Rotor / 2 Piston Caliper
Rear Brakes	Single / 298 mm Rotor / 1 Piston Caliper

ELECTRICAL	
Stator	660W @ 5000 RPM
Battery	12 volt, 21.1 amp-hour, 320 CCA (cold cranking amps), Maintenance Free AGM
Voltage Regulator	14.5 volts / 55 amp
Lamps	
Headlight	Non-Serviceable Reflective LED
Tail / Brake Light	Non-Serviceable LED
Turn Signals	
License Plate Light	
Speedometer & Indicator Lights	
Position Bulb	
WHEELS AND TIRES	
Front Wheel Size / Type	19 in (482.6 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Rear Wheel Size / Type	16 in (406.4 mm) x 3.5 in (88.9 mm) Cast 8-Spoke
Front Tire Type / Size	Metzeler Cruisetec® 130 / 60B19 61H
Rear Tire Type / Size	Metzeler Cruisetec® 150 / 80B16 77H

SPECIFICATIONS

FUEL RECOMMENDATION

For best performance, use only unleaded gasoline with a 91 pump octane minimum (R+M/2 Method) or 95 RON minimum. **DO NOT USE E-85 GASOLINE OR GASOLINE CONTAINING METHANOL.** Using E85 or gasoline/methanol blends can result in poor starting and driveability, engine damage and damage to critical fuel system components.

- *Gasoline containing up to 10% Ethanol can be used.*

In the event that the recommended premium unleaded gasoline is not available and low octane fuel must be used, fill the fuel tank only partially with unleaded regular gasoline, then fill the tank fully with premium unleaded gasoline as soon as possible.



ENGINE OIL RECOMMENDATION

We recommend the use of INDIAN MOTORCYCLE Synthetic Blend 15W-60 Engine Oil for your motorcycle. This oil is formulated with synthetic-based oil and premium engine additives which have physical properties that meet API SM and ILSAC GF-4 specifications.

Do not blend oil additives with engine oil.

If oil must be added in an emergency and the recommended oil is not available, choose only a high-quality 15W-60 motorcycle oil. Change back to the recommended oil at the first opportunity.

Engine oil for this vehicle needs to be JASO MA compliant.

NOTICE

Use of non-recommended lubricants can result in engine damage. Damage resulting from the use of non-recommended lubricants is not covered by warranty.

FORK OIL

We recommend the use of INDIAN MOTORCYCLE Fork Oil for your motorcycle.

BRAKE FLUID

We recommend the use of INDIAN MOTORCYCLE DOT 4 Brake Fluid for both brake master cylinders. *DO NOT use DOT 5 silicone fluid.*

TIRES



WARNING

Operating the motorcycle with incorrect tires, incorrect tire pressure or excessively worn tires could cause loss of control or accident. Under inflation can cause a tire to overheat and result in a tire failure. Only use tires approved by INDIAN MOTORCYCLE for the model of the motorcycle. See your dealer for more information. Use of unapproved or an improperly mixed front and rear tire can result in decreased handling performance and stability, potentially leading to reduced control of the motorcycle. Always maintain proper tire pressure as recommended in the rider's manual and on safety labels.

WARRANTY

INDIAN MOTORCYCLE WARRANTY POLICY

LIMITED WARRANTY

INDIAN MOTORCYCLE LLC, 1900 Highway 71, Spirit Lake, IA 51360 (INDIAN MOTORCYCLE) gives a LIMITED WARRANTY on all components of your INDIAN MOTORCYCLE against defects in material or workmanship. This warranty covers parts and labor charges for repair or replacement of defective parts and begins on the date of purchase by the original retail purchaser. This warranty is transferable to another owner during the warranty period through an authorized INDIAN MOTORCYCLE dealer, but any such transfer will not extend the original term of the warranty.

This warranty will be in effect for a period of:

TWENTY-FOUR (24) MONTHS for privately used motorcycles.

SIX (6) MONTHS for commercially used motorcycles or motorcycles that at any point during the warranty period were the subject of commercial rent.

The product is used commercially when it is used in connection with any work or employment that generates income, or is licensed for a commercial purpose during any part of the warranty period.

The duration of this warranty may vary in your jurisdiction based upon local laws and regulations.

REGISTRATION

At the time of sale, the Warranty Registration Form must be completed by your dealer and submitted to INDIAN MOTORCYCLE within ten days of purchase. Upon receipt of this registration, INDIAN MOTORCYCLE will record the registration for warranty. No verification of registration will be sent to the purchaser as the copy of the Warranty Registration Form will be your proof of warranty coverage. If you have not signed the original registration and received the customer copy, please contact your dealer immediately. **NO WARRANTY COVERAGE WILL BE ALLOWED UNLESS YOUR MOTORCYCLE IS REGISTERED WITH INDIAN MOTORCYCLE.** Initial dealer preparation and set-up of your motorcycle is very important in ensuring trouble-free operation. Purchasing a vehicle in the crate or without proper dealer set-up will void your warranty coverage.

WARRANTY

WARRANTY COVERAGE AND EXCLUSIONS: LIMITATIONS OF WARRANTIES AND REMEDIES

This INDIAN MOTORCYCLE limited warranty excludes any failures that are not caused by a defect in material or workmanship. THIS WARRANTY DOES NOT COVER CLAIMS OF DEFECTIVE DESIGN. This warranty also does not cover acts of God, accidental damage, normal wear and tear, abuse or improper handling. This warranty also does not cover any motorcycle, component, or part that has been altered structurally, modified, neglected, improperly maintained, or used for purposes other than for which it was designed.

This warranty excludes damages or failures resulting from: improper lubrication; improper engine timing; improper fuel; surface imperfections caused by external stress, heat, cold or contamination; operator error or abuse; improper component alignment, tension, adjustment or altitude compensation; snow, water, dirt or other foreign substance ingestion/contamination; improper maintenance; modified components; use of aftermarket or unapproved components, accessories, or attachments; unauthorized repairs; or repairs made after the warranty period expires or by an unauthorized repair center.

This warranty excludes damages or failures caused by abuse, accident, fire, or any other cause other than a defect in materials or workmanship and provides no coverage for consumable components, general wear items, or any parts exposed to friction surfaces, stresses, environmental conditions and/or contamination for which they were not designed or not intended, including but not limited to the following items:

- Wheels and tires
- Suspension components
- Brake components
- Seat components
- Clutches and components
- Steering components
- Batteries
- Light bulbs/Sealed beam lamps
- Filters
- Lubricants
- Bushings
- Sealants
- Coolants
- Bearings
- Finished and unfinished surfaces
- Fuel Injectors/Throttle body components
- Engine components
- Drive belts
- Hydraulic components and fluids
- Circuit breakers/Fuses
- Electronic components
- Spark plugs

LUBRICANTS AND FLUIDS

1. Mixing oil brands or using non-recommended oil may cause engine damage. We recommend the use of INDIAN MOTORCYCLE engine oil.
2. Damage or failure resulting from the use of non-recommended lubricants or fluids is not covered by this warranty.

This warranty provides no coverage for personal loss or expense, including mileage, transportation costs, hotels, meals, shipping or handling fees, motorcycle pick-up or delivery, replacement rentals, loss of vehicle use, loss of profits, or loss of vacation or personal time.

The exclusive remedy for breach of this warranty shall be, at INDIAN MOTORCYCLE's option, repair or replacement of any defective materials, components, or products. THE REMEDIES SET FORTH IN THIS WARRANTY ARE THE ONLY REMEDIES AVAILABLE TO ANY PERSON FOR BREACH OF THIS WARRANTY. INDIAN MOTORCYCLE SHALL HAVE NO LIABILITY TO ANY PERSON FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY DESCRIPTION, WHETHER ARISING OUT OF EXPRESS OR IMPLIED WARRANTY OR ANY OTHER CONTRACT, NEGLIGENCE, OR OTHER TORT OR OTHERWISE. THIS EXCLUSION OF CONSEQUENTIAL, INCIDENTAL, AND SPECIAL DAMAGES IS INDEPENDENT FROM AND SHALL SURVIVE ANY FINDING THAT THE EXCLUSIVE REMEDY FAILED OF ITS ESSENTIAL PURPOSE.

THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS EXCLUDED FROM THIS LIMITED WARRANTY. ALL OTHER IMPLIED WARRANTIES (INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY) ARE LIMITED IN DURATION TO THE ABOVE 24 MONTH/6 MONTH WARRANTY PERIOD, AS APPLICABLE. INDIAN MOTORCYCLE DISCLAIMS ALL EXPRESS WARRANTIES NOT STATED IN THIS WARRANTY. SOME STATES DO NOT PERMIT THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR ALLOW LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU IF INCONSISTENT WITH CONTROLLING STATE LAW.

WARRANTY

HOW TO OBTAIN WARRANTY SERVICE

If your motorcycle requires warranty service, you must take it to an INDIAN MOTORCYCLE Servicing Dealer. When requesting warranty service you must present your copy of the Warranty Registration Form to the dealer. (THE COST OF TRANSPORTATION TO AND FROM THE DEALER IS YOUR RESPONSIBILITY). INDIAN MOTORCYCLE suggests that you use your original selling dealer; however, you may use any INDIAN MOTORCYCLE Servicing Dealer to perform warranty service.

IN THE COUNTRY WHERE YOUR MOTORCYCLE WAS PURCHASED:

Warranty or Service Bulletin repairs must be done by an authorized INDIAN MOTORCYCLE dealer. If you move or are traveling within the country where your motorcycle was purchased, Warranty and Service Bulletin repairs may be requested from any authorized INDIAN MOTORCYCLE dealer.

OUTSIDE THE COUNTRY WHERE YOUR MOTORCYCLE WAS PURCHASED:

If you are traveling temporarily outside the country where your motorcycle was purchased, you should take your motorcycle to an authorized INDIAN MOTORCYCLE dealer. You must show the dealer photo identification from the country of the selling dealer's authorized location as proof of residence. Upon residence verification, the servicing dealer will be authorized to perform the warranty repair.

IF YOU MOVE:

If you move to another country, be sure to contact INDIAN MOTORCYCLE Customer Assistance and the customs department of the destination country before you move. Vehicle importation rules vary considerably from country to country. You may be required to present documentation of your move to INDIAN MOTORCYCLE in order to continue your warranty coverage. You may also be required to obtain documentation from INDIAN MOTORCYCLE in order to register your motorcycle in your new country. You should warranty register your motorcycle at a local INDIAN MOTORCYCLE dealer in your new country immediately after you move to continue your warranty coverage and to ensure that you receive information and notices regarding your motorcycle.

IF YOU PURCHASE FROM A PRIVATE PARTY:

If you purchase an INDIAN MOTORCYCLE from a private party, to be kept and used outside of the country in which the motorcycle was originally purchased, all warranty coverage will be denied. You must nonetheless register your motorcycle under your name and address with a local INDIAN MOTORCYCLE dealer in your country to ensure that you receive safety information and notices regarding your motorcycle.

EXPORTED VEHICLES

EXCEPT WHERE SPECIFICALLY REQUIRED BY LAW, THERE IS NO WARRANTY OR SERVICE BULLETIN COVERAGE ON THIS VEHICLE IF IT IS SOLD OUTSIDE THE COUNTRY OF THE SELLING DEALER'S AUTHORIZED LOCATION. This policy does not apply to vehicles that have received authorization for export from INDIAN MOTORCYCLE. Dealers may not give authorization for export. You should consult an authorized dealer to determine this vehicle's warranty or service coverage if you have any questions. This policy does not apply to vehicles registered to government officials or military personnel on assignment outside the country of the selling dealer's authorized location. This policy does not apply to Safety Bulletins.

NOTICE

If your vehicle is registered outside of the country where it was purchased and you have not followed the procedure set above, your vehicle will no longer be eligible for warranty or service bulletin coverage of any kind, other than safety bulletins. Vehicles registered to government officials or military personnel on assignment outside of the country where the vehicle was purchased will continue to be covered by the Limited Warranty.

Please work with your dealer to resolve any warranty issues. Should your dealer require any additional assistance, they will contact the appropriate person at INDIAN MOTORCYCLE.

MOTORCYCLE NOISE REGULATION

Tampering with noise control systems is prohibited. Federal law prohibits the following acts or causing thereof:

- The removal or rendering inoperative by any person other than for the purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- The use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are:

- Removal or puncturing of the muffler, baffles, header pipes, or any other component which conducts exhaust gasses.
- Removal or puncturing of any part of the intake system.
- Lack of proper maintenance.
- Replacing any moving part of the vehicle, or parts of the exhaust system or intake system, with parts other than those specified by the manufacturer.

WARRANTY

This product should be checked for repair or replacement if the motorcycle noise has increased significantly through use. Otherwise, the owner may become subject to penalties under state and local ordinances.

NOISE EMISSION WARRANTY

INDIAN MOTORCYCLE warrants that this exhaust system, at the time of sale, meets all applicable U.S. EPA Federal noise standards. This warranty extends to the first person who buys this exhaust system for purposes other than resale, and to all subsequent buyers.

Warranty claims should be directed to:

- *An authorized INDIAN MOTORCYCLE dealer, or*
- *INDIAN MOTORCYCLE LLC, 6325 Sandburg Road, Suite 800, Golden Valley, MN 55427*

EMISSIONS CONTROL SYSTEM WARRANTY

INDIAN MOTORCYCLE COMPANY - EMISSION CONTROL SYSTEM WARRANTY STATEMENT ***YOUR WARRANTY RIGHTS AND OBLIGATIONS***

The California Air Resources Board and INDIAN MOTORCYCLE are pleased to explain the emission control system warranty on your 2015 or later INDIAN MOTORCYCLE. In California, new motor vehicles must be designed, built and equipped to meet the state's stringent anti-smog standards. INDIAN MOTORCYCLE must warrant the emission control system on your motorcycle for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your motorcycle. Your emission control system may include parts such as the fuel-injection system, the ignition system, catalytic converter and engine computer. Also included may be hoses, belts, connectors and other emission related assemblies. Where a warrantable condition exists, INDIAN MOTORCYCLE will repair your motorcycle at no cost to you, including diagnosis, parts and labor.

MANUFACTURER'S WARRANTY COVERAGE

Class III motorcycles (280cc and larger): for a period of use of five (5) years or 30,000 kilometers (18,641 miles), whichever first occurs.

If an emission-related part on your motorcycle is defective, the part will be repaired or replaced by INDIAN MOTORCYCLE. This is your emission control system DEFECTS WARRANTY.

MANUFACTURER'S WARRANTY COVERAGE (KOREA)

Class III motorcycles (280cc and larger): for a period of use of two (2) years or 35,000 kilometers (21,747 miles), whichever first occurs.

If an emission-related part on your motorcycle is defective, the part will be repaired or replaced by INDIAN MOTORCYCLE. This is your emission control system DEFECTS WARRANTY.

OWNER'S WARRANTY RESPONSIBILITIES

As the motorcycle owner, you are responsible for the performance of the required maintenance listed in your Rider's manual. INDIAN MOTORCYCLE recommends that you retain all receipts covering maintenance on your motorcycle, but INDIAN MOTORCYCLE cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance. You are responsible for presenting your motorcycle to an INDIAN MOTORCYCLE dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days. As the motorcycle owner, you should be aware that INDIAN MOTORCYCLE may deny your warranty coverage if your motorcycle or part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact INDIAN MOTORCYCLE LLC, 6325 Sandburg Road, Suite 800, Golden Valley, MN 55427, or the California Air Resources Board, 4001 Iowa Ave, Riverside, CA 92507.

INDIAN MOTORCYCLE warrants that each new 2015 and later INDIAN MOTORCYCLE that includes as standard equipment a headlight, taillight and stoplight, and is street legal:

- A. is designed, built and equipped so as to conform at the time of initial retail purchases with all applicable regulations of the United States Environmental Protection Agency, and the California Air Resources Board; and
- B. is free from defects in material and workmanship which cause such motorcycle to fail to conform with applicable regulations of the United States Environmental Protection Agency or the California Air Resources Board for a period of use, depending on the engine displacement, of 12,000 kilometers (7,456 miles), if the motorcycle's engine displacement is less than 170 cubic centimeters; of 18,000 kilometers (11,185 miles), if the motorcycle's engine displacement is equal or greater than 170 cubic centimeters but less than 280 cubic centimeters; or of 30,000 kilometers (18,641 miles), if the motorcycle's engine displacement is 280 cubic centimeters or greater; or 5 (five) years from the date of initial retail delivery, whichever occurs first.

WARRANTY

I. COVERAGE

Warranty defects shall be remedied during customary business hours at any authorized INDIAN MOTORCYCLE dealer located within the United States of America in compliance with the Clean Air Act and applicable regulations of the United States Environmental Protection Agency and the California Air Resources Board. Any part or parts replaced under this warranty shall become the property of INDIAN MOTORCYCLE.

In the State of California only, emission-related warranted parts are specifically defined by the state's Emission Warranty Parts List. These warranted parts are: carburetor and internal parts; intake manifold; fuel tank; fuel injection system; spark advance mechanism; crankcase breather; air cutoff valves; fuel tank cap for evaporative emission controlled vehicles; oil filler cap; pressure control valve; fuel/vapor separator; canister; igniters; breaker governors; ignition coils; ignition wires; ignition points; condensers, and spark plugs if failure occurs prior to the first scheduled replacement; and hoses, clamps, fittings and tubing used directly in these parts. Since emission related parts may vary from model to model, certain models may not contain all of these parts and certain models may contain functionally equivalent parts. In the State of California only, Emission Control System emergency repairs, as provided for in the California Administrative Code, may be performed by other than an authorized INDIAN MOTORCYCLE dealer. An emergency situation occurs when an authorized INDIAN MOTORCYCLE dealer is not reasonably available, a part is not available within 30 days or a repair is not complete within 30 days. Any replacement part can be used in an emergency repair. INDIAN MOTORCYCLE will reimburse the owner for expenses, including diagnosis, not to exceed INDIAN MOTORCYCLE's suggested retail price for all warranted parts replaced and labor charges based on INDIAN MOTORCYCLE'S recommended time allowance for the warranty repair and the geographically appropriate hourly labor rate. The owner may be required to keep receipts and failed parts in order to receive compensation.

II. LIMITATIONS

The Emission Control System Warranty shall not cover any of the following:

A. Repair or replacement required as a result of:

- Accident
- Misuse
- Repairs improperly performed or replacements improperly installed
- Use of replacement parts or accessories not conforming to INDIAN MOTORCYCLE specifications which adversely affect performance and/or
- Use in competitive racing or related events.

B. Inspections, replacement of parts, and other services and adjustments necessary for required maintenance.

C. Any motorcycle on which the odometer mileage has been changed so that actual mileage cannot be readily determined.

WARRANTY

III. LIMITED LIABILITY

- A. The liability of INDIAN MOTORCYCLE under this Emission Control System Warranty is limited solely to the remedying of defects in material or workmanship by an authorized INDIAN MOTORCYCLE dealer at its place of business during customary business hours. This warranty does not cover inconvenience or loss of use of the motorcycle or transportation of the motorcycle to or from the INDIAN MOTORCYCLE dealer. INDIAN MOTORCYCLE SHALL NOT BE LIABLE FOR ANY OTHER EXPENSES, LOSS OR DAMAGE, WHETHER DIRECT, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY ARISING IN CONNECTION WITH THE SALE OR USE OF OR INABILITY TO USE THE INDIAN MOTORCYCLE FOR ANY PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.
- B. NO EXPRESS EMISSION CONTROL SYSTEM WARRANTY IS GIVEN BY INDIAN MOTORCYCLE EXCEPT AS SPECIFICALLY SET FORTH HEREIN. ANY EMISSION CONTROL SYSTEM WARRANTY IMPLIED BY LAW, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS LIMITED TO THE EXPRESS EMISSION CONTROL SYSTEM WARRANTY TERMS STATED IN THIS WARRANTY. THE FOREGOING STATEMENTS OF WARRANTY ARE EXCLUSIVE AND IN LIEU OF ALL OTHER REMEDIES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.
- C. No dealer is authorized to modify this INDIAN MOTORCYCLE Limited Emission Control System Warranty.

IV. LEGAL RIGHTS

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

V. THIS WARRANTY IS IN ADDITION TO THE INDIAN MOTORCYCLE LIMITED MOTORCYCLE WARRANTY

VI. ADDITIONAL INFORMATION

Any replacement part that is equivalent in performance and durability may be used in the performance of any maintenance or repairs. However, INDIAN MOTORCYCLE is not liable for these parts. The owner is responsible for the performance of all required maintenance. Such maintenance may be performed at a service establishment or by any individual. The warranty period begins on the date the motorcycle is delivered to an ultimate purchaser.

INDIAN MOTORCYCLE LLC

6325 Sandburg Road, Suite 800

Golden Valley, MN 55427

ATTN: Warranty Department

WARRANTY

HOW THE CALIFORNIA EMISSIONS WARRANTY ON EMISSIONS-RELATED PARTS MUST FUNCTION AS PRESCRIBED IN 13 CCR § 2036

1. Any warranted part which is not scheduled for replacement as required maintenance in the Owner's Manual must be warranted for the warranty period. If any such part fails during the warranty period, it must be repaired or replaced by INDIAN MOTORCYCLE according to subsection (4) below. Any such part repaired or replaced under warranty must be warranted for the remaining warranty period.
2. Any warranted part which is scheduled only for regular inspection in the Owner's Manual must be warranted for the warranty period. A statement in such written instructions to the effect of "repair or replace as necessary" shall not reduce the period of warranty coverage. Any such part repaired or replaced under warranty shall be warranted for the remaining warranty period.
3. Any warranted part which is scheduled for replacement as required maintenance in the Owner's Manual must be warranted for the period of time or mileage, whichever first occurs, prior to the first scheduled replacement point for that part. If the part fails before the first scheduled replacement point, the part shall be repaired or replaced by INDIAN MOTORCYCLE according to subsection (4) below. Any such part repaired or replaced under warranty shall be warranted for the remainder of the period prior to the first scheduled replacement point for the part.
4. Repair or replacement of any warranted part under the warranty provisions of this article must be performed at no charge to the motorcycle owner, at a warranty station, except in the case of an emergency when a warranted part or a warranty station is not reasonably available to the motorcycle owner. In an emergency, repairs may be performed at any available service establishment, or by the owner, using any replacement part. INDIAN MOTORCYCLE must reimburse the owner for his or her expenses including diagnostic charges for such emergency repair or replacement, not to exceed INDIAN MOTORCYCLE's suggested retail price for all warranted parts replaced and labor charges based on INDIAN MOTORCYCLE's recommended time allowance for the warranty repair and the geographically appropriate hourly labor rate. A motorcycle owner may reasonably be required to keep receipts and failed parts in order to receive compensation for warranted repairs reimbursable due to an emergency.
5. Notwithstanding the provisions of subsection (4) above, warranty services or repairs must be provided at all INDIAN MOTORCYCLE dealerships which are franchised to service the subject motorcycles.
6. The motorcycle owner must not be charged for diagnostic labor which leads to the determination that a warranted part is in fact defective, provided that such diagnostic work is performed at a warranty station.

7. INDIAN MOTORCYCLE is liable for damages to other vehicle components proximately caused by a failure, under warranty, of any warranted part.
8. Throughout the motorcycle's warranty period, INDIAN MOTORCYCLE must maintain a supply of warranted parts sufficient to meet the expected demand for such parts. The lack of availability of such parts or the incompleteness of repairs within a reasonable time period, not to exceed 30 days from the time the motorcycle is initially presented to the warranty station for repair, shall constitute an emergency for purposes of subsection (4).
9. Any replacement part may be used in the performance of any maintenance or repairs. Any replacement part designated by INDIAN MOTORCYCLE may be used in warranty repairs provided without charge to the motorcycle owner. Such use will not reduce the warranty obligations of INDIAN MOTORCYCLE, except that INDIAN MOTORCYCLE will not be liable under this article for repair or replacement of any replacement part which is not a warranted part (except as provided under subsection (7)).
10. Any add-on or modified part exempted by the Air Resources Board from the prohibitions of Vehicle Code section 27156 may be used on a motorcycle. Such use, in and of itself, will not be grounds for disallowing a warranty claim made in accordance with this article. INDIAN MOTORCYCLE is not liable under this article to warrant failures of warranted parts caused by the use of an add-on or modified part.

EXCLUSION

1. The repair or replacement of any warranted part otherwise eligible for warranty coverage described above, shall be excluded for such warranty coverage if INDIAN MOTORCYCLE demonstrates that the motorcycle has been abused, neglected, or improperly maintained, and that such abuse, neglect, or improper maintenance was the direct cause of the need for the repair or replacement of the part.

WARRANTY

CALIFORNIA CONSUMER NOTICE / NOTIFICACIÓN PARA LOS CLIENTES DE CALIFORNIA

Notification requirements in California. INDIAN MOTORCYCLE and your INDIAN MOTORCYCLE dealer place a high priority on your satisfaction with our performance. If you are not satisfied with our resolution of a warranty concern and you would like to seek a civil penalty from INDIAN MOTORCYCLE, you must follow these steps under California law (Cal. Code Civ. Proc., §871.24(a)-(d)):

At least 30 days before filing a lawsuit seeking civil penalties (Civ. Code § 1794(c)), you must:

1. Notify INDIAN MOTORCYCLE of your name and the name(s) of any other vehicle owner(s), the accurate Vehicle Identification Number (“VIN”) of your motorcycle, and a brief summary of the repair history and problems with your motorcycle, and
2. Demand that INDIAN MOTORCYCLE repurchase or replace your motorcycle.

When you submit the notice to INDIAN MOTORCYCLE, you must have possession of your motorcycle.

Your notice to INDIAN MOTORCYCLE must be in writing and must be sent either by email to calnotice@indianmotorcycle.com or by certified or registered mail, return receipt requested, to:

Indian Motorcycle LLC

ATTN: California Written Notice

6325 Sandburg Road, Suite 800

Golden Valley, MN 55427

Requisitos para la notificación en California. INDIAN MOTORCYCLE y su distribuidor INDIAN MOTORCYCLE dan alta prioridad a su satisfacción con nuestro desempeño. Si no está satisfecho con nuestra resolución de cualquier problema de garantía y desea exigir sanciones civiles para INDIAN MOTORCYCLE, debe seguir estos pasos establecidos por la ley de California (Código de procedimiento civil de California §871.24(a)-(d)):

Al menos con 30 días de antelación a la presentación de una demanda exigiendo sanciones civiles (Código civil § 1794(c)), debe:

1. Notificar a INDIAN MOTORCYCLE su nombre y el nombre o los nombres de cualquier otro propietario o propietarios del vehículo, el número preciso de identificación del vehículo ("VIN") de su motocicleta y un breve resumen del historial de reparaciones y problemas con su motocicleta, y
2. Exigir que INDIAN MOTORCYCLE recompre o reemplace su motocicleta.

Cuando presente la notificación a INDIAN MOTORCYCLE, debe tener posesión de su motocicleta.

Su notificación a INDIAN MOTORCYCLE debe ser por escrito y debe enviarse o por correo electrónico a calnotice@indianmotorcycle.com o mediante correo certificado o registrado, con solicitud de acuse de recibo, a:

Indian Motorcycle LLC

ATTN: California Written Notice

6325 Sandburg Road, Suite 800

Golden Valley, MN 55427 EE. UU.

MAINTENANCE LOG
MAINTENANCE LOG

MAINTENANCE PERFORMED	MILES / KM	NOTES	PERFORMED BY

A

About the Rider's Manual	19
Accelerating	103
Accessories	24
AGM Battery Charger	
Recommendations	186
AGM Battery Charging	
Recommendations	186
AGM Battery Maintenance Tips	187
Air Filter	
Inspection and Replacement	132
Anti-Lock Brake System (ABS) Tone	
Ring / Sensor Inspection	163
Average Fuel Economy	46

B

Battery	180
Battery Care	200
Battery Charge Port / Heated Gear	
Plug	50
Battery Charging and Maintenance	185
Battery Removal / Installation	180
Battery Voltage	46
Brake Disc Inspection / Cleaning	162
Brake Fluid	230
Brake Fluid Precautions	158
Brake Hoses/Connections	158
Brake Light Replacement	179
Brake Pads	161

Brake Pedal	
Adjustment	86
Braking	102
Break-In Maintenance	95

C

Care and Maintenance	62
Carrying a Passenger	23
Carrying Cargo	23
Changing Your Security System PIN	
Analog Gauge Equipped Models	191
Ride Command Equipped Models	191
Checking Oil Level	83
Cleaning Products	197
Clock	48
Club Fairing	
Removal / Installation	173
Clutch Lever	51
Cold Weather Operation	99
Component Identification	
Scout Bobber	32
Scout Classic	31
Component Locations	
Console	33
Control	
Right Control	35
Controls	
Left Control	34
Cooling System	130, 200
Crankcase Breather Hoses	153

Cruise Control	103
Accelerate	104
Cruise Control Tips	103
Cruise Control, Cancel	104
Decelerate	104
Resume Speed	104
Set Speed	104

D

Diagnostic Functionality	49
Display Units (Standard / Metric)	48
Drive Belt Maintenance	
Drive Belt Alignment	143
Drive Belt Tension Adjustment	141
Drive Belt Tension Check	140
Lifting the Motorcycle	140

E

Electrical Inspections	81
Electrical Precautions	189
Elevating the Motorcycle	192
Engine Break-In	95
Engine Identification Number	8
Engine Oil Recommendation	230
Engine Protection	200
Engine Speed	46

INDEX

Evaporative Emission Control System (If Equipped)	153
Exhaust System Inspection	192

F

Fastener Inspection	193
Fastener Torques	193
Feeler Pegs	51
FOB Battery Disposal	188
Fork Oil	230
Front Brake Fluid	160
Front Brake Fluid Level	85
Front Brake Lever	59, 159
Front Fork Adjustment Guide	152
Front Fork / Suspension Inspection	151
Front Suspension Inspection	90
Front Wheel Installation	165
Fuel and Exhaust Safety	26
Fuel Filter	134
Fuel Level	91
Fuel Recommendation	230
Fuel Stabilizer	199
Fuel System Depressurization	134
Fuel System Components	154
Fuel Tank Installation	139
Removal	134

Fueling	96
Fuse Replacement	188

G

Gear Indicator	46
Gear Shift Lever	52
Gloss Clear Coat Finish Care	198
Gross Vehicle Weight Rating (GVWR)	28

H

Headlight Aim Adjustment	179
Headlight Aim Inspection	178
Headlight Lamp Replacement	179
Headlight Nacelle Removal / Installation	176

I

Identification Number Record	7
Idle Timer Shutdown Notification	98
Ignition / Light Key Switch	39
Indicator Lamps	43
Instrument Cluster	42, 46

J

Jump Starting the Vehicle	187
---------------------------------	-----

K

Key Fob Battery Life	187
Keyless Ignition	41

M

Maintenance During Storage	200
Maintenance Intervals	110
Maintenance Log	249
Maintenance, Major	108
Marquardt Labels	13
Matte Clear Coat Finish Care	198
Mechanical Clutch Cable Lubrication	157
Inspection	88
Lever Freeplay	155
Lever Lubrication	156
MFD Tell-Tales	45
Mirrors	51
Misfire Detection	49
Modifications	25
Multi-Function Display (MFD) Modes	46
Music	70

O

Odometer	46
Oil and Filter Change	128
Oil Change	
Checking Oil Level.....	83
Oil Level	
Check	83
Operating Motorcycle Outside the U. S.A.	7
Operating Speeds and Gears	96
Operation	95
Outside Temperature.....	46
Over Temperature Display and Warning Indicator.....	49

P

Park and Cover the Motorcycle	200
Parking	105
Parking on a Slope	105
Parking on a Soft Surface	105
Parking the Motorcycle	25
Periodic Maintenance	109
Maintenance Intervals.....	110
Severe Use Definition.....	109
Pre-Ride Inspection	
General Inspection.....	82
Pre-Ride Inspections.....	81
Brake Lines	88
Coolant Level Inspection	92, 131

Fasteners	91
Front Brake Lever, Inspection	86
Rear Brake Pedal, Inspection.....	86
Throttle	90
Tire Condition	85
Tires	84, 167, 231
Priming the Fuel System.....	97
Protective Apparel	22

R

Radio Compliance Statements.....	9
Rear Brake Fluid	158
Rear Brake Fluid Level	87
Rear Brake Pedal.....	60, 158
Rear Drive Belt	
Inspection.....	91
Rear Drive Belt Cleaning	145
Rear Drive Belt Condition.....	145
Rear Drive Belt Wear Analysis	146
Rear Shock	
Adjustment Guide	149
Rear Shock Preload (Ride Height)	
Adjustment	148
Rear Shock Preload (Ride Height)	
Inspection	147
Rear Suspension	
Inspection.....	90
Removal From Storage	201
Reporting Safety Defects	29

Reporting Safety Defects (Canada)	29
Ride Command	
App Tray	73
Bike Information	68
Bluetooth® Pairing	75
Buttons	64
Controls	70
Display Screen	66
Icon Bar	65
Indicator Lamps	63
Maps and Navigation	69
Over the Air Updates	76
Overview.....	61-62
Ride Information	68
Ride Modes.....	71
Settings	72
Update Maps	77
Update Software.....	76
RIDE COMMAND+	79
Ride Modes (If Equipped).....	47
Road Test	192
Road Tests	108
Rodents	200

S

Saddlebags	24
Saddlebags (Sport Scout RT Models)	
Removal / Installation	55
Saddlebags (Super Scout Models)	
Removal / Installation	52

INDEX

Safe Riding Practices	19
Motorcycling Has Inherent Risks.....	19
Safety and Information Labels	30
Safety During Service Procedures.....	108
Safety Maintenance	27
Safety Symbols	4
Seat	
Removal / Installation (1-Up	
Models)	169
Removal / Installation (2-Up	
Models)	170
Security System	191
Unlocking (Analog Gauge Equipped	
Models)	189
Unlocking (Ride Command Equipped	
Models)	190
Service and Warranty Information.....	7
Service Intervals	
Maintenance	110
Service Procedures	107
Shift Pedal	
Adjustment	89
Shift Points	
Recommended	102
Shifting Gears.....	100
Shifting Gears While Driving	101
Shifting Gears While Stationary	100
Sidestand.....	58
Sidestand Lubrication	154
Sidestand, Inspection	91
Signal Words	4
Spark Plugs.....	168

Specifications	230
101 Scout	218
Scout Bobber.....	206
Scout Classic.....	203
Scout Sixty Bobber	224
Scout Sixty Classic	221
Sport Scout	212
Sport Scout RT	215
Sport Scout Sixty	227
Super Scout.....	209
Speedometer	42
Starting the Engine.....	97
Steering Head Inspection	152
Steering Lock (If Equipped)	59
Stopping the Engine	103
Storage Area Preparation	199
Suspension Adjustment	
Front Fork	152
Rear Shock.....	149
Swing Arm/Rear Axle Inspection	150
Switch	
5-Way Toggle	74
Switches	
Engine Stop / Run / Start Switch.....	39
High / Low Headlight Beam Switch....	37
Horn Switch	38
Switch Symbols.....	35
Turn Signal / Hazard Signal.....	38
SwitchTrigger Switch.....	75

T

Taillight Replacement	179
Throttle Control Grip	50
Throttle Control Inspection	154
Tire Condition	167
Tire Inflation.....	199
Tire Pressure	84, 167
Tire Pressure Chart	168
Tire Replacement.....	167
Tire Tread Depth.....	85, 168
Tires	84, 167, 231
Traction Control (If Equipped)	47
Trademarks	2
Transporting the Motorcycle	27
Trip Odometer	46
Troubleshooting	193
Anti-Lock Brake Light Remains	
Illuminated or Illuminates	
Intermittently	195
Battery Charging Rate Low or Battery	
Discharges	195
Brake Noise / Poor Brake	
Performance	195
Engine Cranks But Will Not Start.....	193
Engine Overheating	194
Engine Starts But Misses or Runs	
Poorly.....	194
Shifting Difficulties or Hard to Find	
Neutral	194
Starter Motor Clicks, Does Not Turn or	
Turns Slowly	193

U

USB Port 78

W

Warning Symbols..... 4

Warranty

California Consumer Notice /

Notificación para los clientes de

California.....246

Coverage and Exclusions234

Exported Vehicles.....237

How to Obtain236

Limitations of Warranties and

Remedies.....234

Limited Warranty233

Lubricants and Fluids.....235

Motorcycle Noise Regulation237

Noise Emission238

Notice237

Registration233

Washing the Motorcycle.....197

Wheel Alignment164

Wheel Inspection164

Windshield (If Equipped) 56

Windshield Care (if equipped).....198

To locate your nearest dealer,
visit www.indianmotorcycle.com

INDIAN MOTORCYCLE LLC
6325 Sandburg Road, Suite 800
Golden Valley, MN 55427
Phone: 1-877-204-3697
French: 1-800-268-6334



Part No. 9942051 Rev 02
Printed in U.S.A.

